### **Final**

# Post-Construction Stormwater Management in New Development and Redevelopment Program Manual



State of Hawaii
Department of Transportation
Harbors Division
Hale Awa Ku Moku Building
79 South Nimitz Highway
Honolulu Hawaii 96813-5898

October 2021

Version 8.0

### **Final**

# Post-Construction Stormwater Management in New Development and Redevelopment Program Manual

State of Hawaii
Department of Transportation
Harbors Division
Hale Awa Ku Moku Building
79 South Nimitz Highway
Honolulu, Hawaii 96813-4898



October 2021

Version 8.0

#### **RECORD OF REVISION**

Revision No.	Revision Date	Description	Sections Affected
1.0	January 2013	Initial Release	All
2.0	June 2013	Version 2.0	All
3.0	October 2013	Version 3.0	All
4.0	December 2013	Version 4.0	All
5.0	February 2014	Version 5.0	All
6.0	May 2014	Version 6.0	All
7.0	May 2014	Version 7.0	5
8.0	October 2021	Version 8.0	All

#### **TABLE OF CONTENTS**

1.0	INT	RODUCTION	1
1.1	Co	MPONENT OVERVIEW	1
1.2	EXE	EMPTIONS	3
2.0	IMF	PLEMENTATION PROCESS	4
2.1	Res	SPONSIBILITIES	4
2.2	HAI	RBORS PROJECT	5
2.3	TEN	NANT IMPROVEMENT PROJECT	6
3.0	ВМ	P REQUIREMENTS AND SELECTION PROCEDURE	8
3.1	IDE	NTIFYING POLLUTANTS OF POTENTIAL CONCERN AND RECEIVING WATER BODIES	8
3.2	DR	AINAGE STUDY AND IDENTIFICATION OF CONDITIONS OF CONCERN	9
3.3	Pos	ST-CONSTRUCTION STORMWATER BMP SELECTION	10
3.4	FEA	ASIBILITY CRITERIA AND LIMITATIONS	13
	3.4.1	Infiltration BMPs	
	3.4.2	Harvest/Reuse	
	3.4.3 3.4.4	Vegetated Biofilters	
	3.4.4	Green RoofDry Swales	
	3.4.6	Vegetated Swales or Vegetated Filter Strips	
3.5		ST-CONSTRUCTION STORMWATER MITIGATION PLAN DEVELOPMENT	
	3.5.1	Introduction of Low Impact Development	
	3.5.2	LID Site Design Strategies	
	3.5.3	Source Control BMPs	
	3.5.4	Treatment Control BMPs	
4.0	3.5.5	Numeric Sizing CriteriaST-CONSTRUCTION BMP INSTALLATION	
<b>4.0</b> 4.1	_	TALLATION INSPECTION DURING CONSTRUCTION PHASE	
4. I 5.0			24
5.0		ST-CONSTRUCTION BMP MAINTENANCE, INVENTORY AND CORDKEEPING	25
5.1		INTENANCE REQUIREMENTS	
5.1			
5.2 5.3		RIFICATION MECHANISMSST-CONSTRUCTION BMP INSPECTION	
5.4		ST-CONSTRUCTION BMP INVENTORY AND RECORDKEEPING	
6.0			_
6.1		DPE OF AUTHORITY	
6.2		FORCEMENT ACTIONS	
7.0		AINING	
8.0	RE	FERENCES	31

i

#### LIST OF TABLES

Number	Title
2-1	Responsibilities for Post-Construction Program Implementation – Harbors Project
2-2	Responsibilities for Post-Construction Program Implementation – Tenant
	Improvement Project
3-1	Pollutants of Potential Concern
3-2	Post-Construction Best Management Practices
3-3	Fundamental Components of a PSMP for Regulated for Regulated Project
3-4	List of Source Control Categories (taken from CCH Storm Water BMP Guide)
3-5	Runoff Coefficients for Water Quality Flow Calculations (taken from CCH Storm
	Water BMP Guide)

#### **LIST OF FIGURES**

Number	Title
1-1	General Post-Construction Project Requirements Flow Chart
3-1	Post-Construction BMP Selection Procedure Flow Chart
3-2	BMP Selection Process for Pollutants of Potential Concern

#### **LIST OF APPENDICES**

Number	Title
Appendix A	HDOT Harbors Division Administrative Organizational Chart
Appendix B	Permanent Post-Construction Best Management Practices Plan Checklist
Appendix C	CCH Storm Water BMP Guide
Appendix D	CCH Rules Relating to Water Quality
Appendix E	A Sample of CDS Unit Operation and Maintenance Guideline
Appendix F	HDOT Harbors Division Construction and Post-Construction Program Brochures

#### LIST OF ACRONYMS AND ABBREVIATIONS

% Percent

ACR Annual Compliance Report
AMS Asset Management System
BMP Best Management Practice

CASQA California Stormwater Quality Association

CCH City and County of Honolulu

DA Drainage Area

ELD Environmental Liquidated Damages

HAR Hawaii Administrative Rules

HAR-E Harbors Division Engineering Branch

HAR-EC Harbors Division Engineering Branch Construction Section
HAR-ED Harbors Division Engineering Branch Design Section

HAR-EE Harbors Division Engineering Branch Environmental Section
HAR-EM Harbors Division Engineering Branch Maintenance Section
HAR-EP Harbors Division Engineering Branch Planning Section

HAR-PM Harbors Division Property Management Section
HDOT State of Hawaii Department of Transportation

HRS Hawaii Revised Statutes
HSG Hydrologic Soil Group
L&M Labor and Materials

LID Low Impact Development

MS4 Municipal Separate Storm Sewer System

NAV Notice of Apparent Violation

NFVO Notice and Finding of Violation Order

NPDES National Pollutant Discharge Elimination System

NRCS Natural Resources Conservation Service

O&M Operation and Maintenance

PjM Harbors Division Project Manager POPC Pollutants of Potential Concern

PSWP Post-Construction Stormwater Mitigation Plan

SWO Stop Work Order

TMDL Total Maximum Daily Loads

USDA United States Department of Agriculture

USEPA United States Environmental Protection Agency

WQF Water Quality Flow Rate WQV Water Quality Volume

#### **GLOSSARY**

**Best Management Practices (BMPs)** means schedules of activities, prohibitions of practices, maintenance procedures, and other management practices to prevent or reduce the pollution of "waters of the United States." BMPs also include treatment requirements, operating procedures, and practices to control plant site runoff, spillage or leaks, sludge or waste disposal, or drainage from raw material storage.

**Clean Water Act** is an act passed by the United States Congress to control water pollution. It was formerly referred to as the Federal Water Pollution Control Act of 1972 or Federal Water Pollution Control Act Amendments of 1972 (Public Law 92-500), 33 U.S.C. 1251 et seq., as amended by Public Law 96-483, Public Law 97-117, and Public Laws 95-217, 97-117, 97-440, and 100-04. Requirements of the NPDES program are defined under Sections 307, 402, 318 and 405 of the CWA.

**Code of Federal Regulation** codified all rules of the executive departments and agencies of the federal government. It is divided into fifty volumes, known as titles. Title 40 of the CFR (referenced as 40 CFR) lists all environmental regulations.

**Discharge** is a release or flow of stormwater or other substance from a conveyance system or storage container. Broader discharges include release to storm drains, etc.

**Disturbance of Land** refers to the penetration, turning, or moving of soil or resurfacing of pavement with exposure of the base course or the exposure of bare soil or ground surface, including the land surface exposed by construction of roads, buildings, utilities, baseyards, staging areas, demolition, headquarters, and parking areas. It does not include grass or weed cutting, bush or tree trimming or felling that leaves soil or ground intact. It includes "grubbing" in its normal meaning of the use of equipment to knock down and push vegetation out of the way, typically uprooting vegetation and disturbing the ground surface.

**Erosion** is the wearing-away of land surface by wind or water. Erosion occurs naturally from weather or runoff but can be intensified by land-clearing practices related to farming, new development, redevelopment, road building, or timber cutting.

**Grading** is any excavation or fill, or combination thereof.

**Illicit Discharge** is a non-storm water discharge that poses a risk to the environment.

**Impervious Surface** is a surface covering or pavement of a developed parcel of land that prevents the land's natural ability to absorb and infiltrate rainfall/stormwater. Impervious surfaces include, but are not limited to, rooftops; walkways; patios; driveways; parking lots; storage areas; impervious concrete and asphalt; and any other continuous watertight pavement or covering.

Landscaped soil and pervious pavement, underlain with pervious soil or pervious storage materials, are not impervious surfaces.

**LID Site Design Strategy** combines a hydrologically functional site design with pollution prevention measures to compensate for land development impacts on hydrology and water quality. They mimic the predevelopment site hydrology by using site design techniques that store, infiltrate, evaporate, and detain runoff to reduce off-site runoff and ensure adequate groundwater recharge. LID aims to preserve, restore, and create green space using soils, vegetations, and rain harvest techniques.

**MS4** is conveyance or system of conveyances that is owned by a state, city, town, village, or other public entity that discharges to waters of the United States. It is designed or used to collect or convey stormwater (e.g., storm drains, pipes, ditches). It is usually not a combined sewer and not part of a sewage treatment plant or publicly owned treatment works. It is categorized as either "small," "medium," or "large," by USEPA. The Phase I regulation covers medium and large MS4s, serving a population of 100,000 or more. The Phase II regulation covers a subset of small MS4s in urbanized area (as defined by the Bureau of the Census) and non-traditional MS4s such as public universities, departments of transportation, hospitals, and prisons. Other small MS4s located outside these areas may be designated on a case-by-case basis by the NPDES permitting authority.

**New Development** is any action that is undertaken to alter the natural condition of real property or improvement on real property if a building, electric, grading, grubbing, plumbing, stockpiling or trenching permit would be required for the project, that may result in different or increased pollutant discharges to (Small) MS4 or receiving waters. New Development usually does not include work that does not involve any land disturbing activity, the installation of signs and traffic control devices, the installation of temporary BMPs, emergency work necessary to repair surfaces that are in immediate need of stabilization, the marking of improved surfaces with striping or signage, and minor and ordinary repairs to existing improvements, provided that the work will not increase the impervious surface area of the project site.

**Post-Construction BMP** refers to practices or control measures used to mitigate stormwater impacts from new development and redevelopment site. It includes LID site design strategies, source control BMPs, and treatment control BMPs. These practices treat, store, or infiltrate runoff onsite before it can affect water bodies downstream. Innovative site designs that reduce imperviousness and smaller-scale low impact development practices dispersed throughout a site are also ways to achieve the goals of reducing flows and improving water quality.

**Pretreatment** is treatment of waste stream before it is discharged to a collection system.

**Redevelopment** shall mean development that would create or add impervious surface area on an already developed site. Redevelopment includes, but is not limited to, any construction project that requires demolition or complete removal of existing structures or impervious surfaces at a site and replacement with new impervious surfaces. Maintenance activities such as top-layer grinding, repaving (where all pavement is not removed), and reroofing are not considered to be redevelopment. Interior remodeling projects and improvements are also not considered to be redevelopment.

**Secondary Containment** is structure, usually dikes or berms, surrounding tanks or other storage containers, designed to catch spilled materials from the storage containers.

**Sediments** are soil, sand, and minerals washed from land into water, usually after rain, that collect in reservoirs, rivers, and harbors, destroying fish nesting areas and clouding the water, thus preventing sunlight from reaching aquatic plants. Farming, mining, and building activities without proper implementation of BMPs will expose sediment materials, allowing them to be washed off the land after rainfalls.

**Source Control Best Management Practice** is any practice designed to prevent pollutants from contacting stormwater runoff or to prevent discharge of contaminated runoff into storm drainage system.

**State Waters** means all waters, fresh, brackish, or salt, around and within the State of Hawaii, including, but not limited to, coastal waters, streams, rivers, drainage ditches, ponds, reservoirs, canals, ground waters, and lakes; provided that drainage ditches, ponds, and reservoirs required as a part of a water pollution control system are excluded.

**Treatment Control** means measures that treat stormwater and non-stormwater that has come into contact with pollutants.

#### 1.0 INTRODUCTION

The **Post-Construction Stormwater Management Program** is intended for the following audiences: (1) State of Hawaii Department of Transportation [HDOT] Harbors Division (hereinafter referred to as the "Harbors") staff whose primary duties involving plan review and approval for Harbors capital projects (hereinafter referred to as the "Harbors Project") and Tenant<sup>1</sup> Improvement projects (hereinafter referred to as the "Tenant Improvement Project," (2) Harbors staff tasked with construction project oversight, (3) Harbors staff tasked with inspection of post-construction Best Management Practices [BMPs] during construction phase, and (4) the development community including engineers and architects tasked with creating and submitting construction plans for approval.

This program is complementary to Harbors *Construction Site Runoff Control Program* in that post-construction BMPs are required by Harbors National Pollutant Discharge Elimination System [NPDES] permit, and therefore will be incorporated into site-specific BMP plans consistent with this manual. This manual defines requirements and provides guidance for the project specific planning, selection, and design of post-construction BMPs to minimize pollutants in post-construction runoff and to minimize the amount of potentially polluted runoff leaving the site.


New development and redevelopment projects that result in a land disturbance of one (1) acre or more (hereinafter referred to as "Regulated Project"), are subject to Harbors Post-Construction Stormwater Management Program. All Regulated Projects must implement post-construction BMPs, unless the project is exempted according to Section 1.2. BMPs shall be designed and installed in accordance with the criteria, guidelines, and design standards described in this manual. Harbors has adopted City and County of Honolulu [CCH] Storm Water BMP Guide for New and Redevelopment (CCH, 2017; Appendix C) and Rules Relating to Water Quality (CCH, 2018; Appendix D) to guide both Harbors and Tenant Improvement Projects, when applicable and practical.

#### 1.1 Component Overview

Sections 2 to 5 of this manual describe the planning, design, construction, inspection, and long-term maintenance requirements for post-construction BMPs. The post-construction general requirements for Harbors and Tenant Improvement Projects are depicted in Figure 1-1. General requirements for Harbors reviewers and inspectors are depicted in Attachment 1 of *Construction Site Runoff Control Program* manual.

<sup>&</sup>lt;sup>1</sup> "Tenant" shall mean a person, group, partnership, corporation, or any other entity that has an executed lease, revocable permit or disposition instrument under chapter 171, Hawaii Revised Statutes [HRS] to use or occupy land, a building, structure, or other property owned by Harbors. This term also includes Harbors' approved sub-tenants and entities using container or terminal facilities.

Figure 1-1:
General Post-Construction Project Requirements Flow Chart



#### In **Design** Phase:

- Incorporate post-construction BMP into project design Section 2.0 and CCH Storm Water BMP Guide for New and Redevelopment
- 2. Submit Permanent Post-Construction BMP Plan Checklist Appendix B
- Apply for necessary permits (consult with appropriate agencies) Attachments 1 and 2 of Construction Site Runoff Control Program Manual
- 4. Submit plans including PSMP for review Section 3.0
- 5. Submit O&M Plan, if applicable, for review Section 5.1
- 6. Wait for concurrence and Notice to Proceed.

#### In Construction Phase:

- 1. Install Post-Construction BMP according to approved PSMP Section 3.0
- Inspection during installation and inventory Attachment 4 of Construction Site Runoff Control Program Manual
- Enforcement if necessary Section 7.0 of Construction Site Runoff Control Program
- Submit O&M Plan for review Section 5.1

#### In **Post-Construction** Phase:

- 1. Conduct long-term O&M of post-construction BMP, If applicable Section 5.0
- 2. Inspect post-construction BMP regularly Section 5.3
- 3. For Tenant Project, tenant may submit annual O&M and inspection report to Harbors, if applicable Section 5.2
- 4. Enforcement if necessary Section 6.0

The following lists the major components covered under the Harbors **Post-Construction Stormwater Management Program.** 

- BMP requirements for Regulated Projects, including Low Impact Development [LID] Site Design Strategies, Source Control BMPs, and Treatment Control BMPs. These BMPs are to be included and described in a Post-Construction Stormwater Mitigation Plan [PSMP].
- CCH Rules Relating to Water Quality (CCH, 2018).
- Plan and permit application review to ensure that a Regulated Project is incorporating post-construction BMPs in accordance with the program.
- Inspections during construction phase to ensure that post-construction BMPs are installed and maintained properly.
- Enforcement when BMPs are not installed or maintained properly.
- Recordkeeping and references to support and facilitate compliance with the program, including, but not limited to:
  - Storm Water BMP Guide for New and Redevelopment (CCH, 2017), providing the minimum requirements needed to achieve compliance with LID Site Design Strategies, Source Control BMPs, and Treatment Control BMPs.
  - Post-Construction BMP GIS and database (e.g., Citywork<sup>©</sup> powered Access Management System [AMS]) to keep track of Harbors owned post-construction stormwater BMPs.
- Training for plan and permit application reviewers, inspectors, and maintenance personnel.
  - Education for project applicants, contractors, developers, designers, and other responsible parties.

#### 1.2 Exemptions

Harbors may exempt certain types of projects (posing no to minimum risk of stormwater pollution) from this program, including, but not limited to:

- Maintenance activities such as top-layer grinding, repaving (where all pavement is not removed) and reconfiguring surface parking lots.
- Reroofing.
- Interior remodeling and improvement.
- Routine maintenance to maintain original line and grade, hydraulic capacity, or other original purpose of facility.
- Trenching and resurfacing associated with utility work or fence installation.
- Replacement of damaged pavement.
- Emergency construction activities required to immediately protect public health and safety.

All new and redevelopment projects under Harbors jurisdiction undergo an environmental review during planning phase. The project review and approval process are a critical point at which the Harbors can introduce applicable conditions or standards that will minimize the impacts of urban runoff on adjacent state waters. Project developers must address the potential impacts of stormwater discharges derived from development activities in the project planning and design phases. Regulated Projects that have the potential to negatively impact stormwater runoff to the Honolulu and Kalaeloa Barbers Point Harbors Small MS4s, will be required to identify post-construction BMPs that will be included in the project design, constructed as part of the project, and maintained in the long-term.

PSMP and the *Permanent Post-Construction BMP Plan Checklist* (Appendix B) must be included in the submittal package and completed properly for the project during design phase for Harbors approval.

Development projects are segregated by two major categories – (1) Harbors Projects and (2) Tenant Improvement Projects. Harbors has different project review and approval processes for Harbors Projects (Section 2.2) and Tenant Improvement Projects (Section 2.3). Personnel responsibilities for design, plan review, and approval of PSMP are outlined in Section 2.1 (Tables 2-1 and 2-2).

#### 2.1 Responsibilities

General responsibilities involved in the implementation of Harbors **Post-Construction Stormwater Management Program** are listed in Table 2-1 for Harbors Projects and Table 2-2 for Tenant Improvement Projects. Harbors Engineering Branch consists of Construction Section [HAR-EC], Design Section [HAR-ED], Environmental Section [HAR-EE], Maintenance Section [HAR-EM], and Planning Section [HAR-EP]. A *Harbors Environmental Group Organization Chart* is enclosed in Attachment A.

For Harbors Projects, HAR-EP initiates the planning of the project including budgeting. HAR-ED, HAR-EE, and HAR-EM each review project plans and specifications on different aspects. Additionally, HAR-EE reviews the submitted PSMP and other program forms. The inspectors from HAR-EC conduct inspections during construction phase to ensure structural post-construction BMPs installed according to the approved plans. HAR-EE also verifies that the post-construction BMPs proposed in the PSMP are installed according to approved plans. Harbors Oahu District staff is responsible for the proper operation and maintenance [O&M] of the installed post-construction BMPs.

For Tenant Projects, HAR-PM will forward construction plans, specifications, and PSMP to HAR-E for review and comment. Each section under HAR-E will review and provide their comments. During the construction phase, HAR-EE will inspect and verify that the post-construction BMPs

proposed in the PSMP are installed properly. Tenants will be responsible for long-term O&M of the installed post-construction BMPs. HAR-EE will inspect these BMPs during regular tenant inspections, at the frequency identified in Harbors *Tenant Inspection Manual* (HDOTb, 2021).

Table 2-1
Responsibilities for Post-Construction Program Implementation
- Harbors Project

	Hark	Harbors Engineering Branch				Oahu
	EC	ED	EE	EM	EP	District
Harbors Project Planning					Χ	
Harbors Project Design		X		X		
Harbors Project Review		X	Χ	Χ		Χ
Harbors Project Approval	Х					
PSMP Review and Approval			Χ			
Inspection during Construction	Х		Χ			
Inspection after Construction			Χ			Χ
Harbors Project O&M						Х
Provide Training			Х			
Enforcement	Х		Χ			

Table 2-2
Responsibilities for Post-Construction Implementation
- Tenant Project

	Tonout	Harbors Engineering Branch					DM
	Tenant	EC	ED	EE	EM	EP	PM
Tenant Project Planning	X						Х
Tenant Project Review			Х	Χ	Х		Х
PSMP Review and Approval				Χ			
Tenant Project Approval							Х
Inspection during Construction				Χ			
Inspection after Construction	X			Χ			
Tenants Project O&M	X						
Provide Training	Х			Χ			
Enforcement				Χ			Х

#### 2.2 Harbors Project

Personnel from Harbors Engineering Branch Environmental Section [HAR-EE] initiates the review process by evaluating whether post-construction requirements are applicable to the projects. The key criteria for determining the need for post-construction BMPs are (a) the acreage of the project and (b) whether it can be exempt (Section 1.2).

When post-construction requirements are applicable, as described in Section 3.1 of the *Construction Site Runoff Control Program* Manual, HAR-EE will exchange the program requirement(s) with Harbors Project Manager [PjM] at the **Preliminary Design Phase** to discuss the *Construction Site Design Review Checklist* (HDOTa, 2021), as well as the *Permanent Post-Construction BMP Plan Checklist* (include in Attachment B). The PjM may convene a Pre-Design meeting with HAR-EE for further consultation. *Construction Design Review Checklist* discussions may continue into the **Design Phase**. These discussions and meetings will allow the PjM and HAR-EE to discuss applicable site-specific post-construction BMPs.

HAR-EE will advise PjM that a PSMP, describing how the project would meet Harbors **Post-Construction Stormwater Management** program requirements, must be submitted during design phase. At this stage, project-specific environmental mitigation measures are developed and a submittal package (including plans, specifications, designs, and PSMP) is forwarded to HAR-EE for review and comment.

HAR-EE reviews the PSMP document and final design plans to verify that post-construction program requirements are met. HAR-EE will then notify PjM when the PSMP is complete and contains necessary BMPs (refer to Sections 3.2 to 3.4), utilizing an interoffice memorandum. Once this memo has been issued (and placed in the project file), Harbors can proceed with putting the project out for bid. This process ensures that Harbors Post-Construction Stormwater Management program requirements are incorporated into the project design and shown on the plans prior to bidding for construction contractors or completion of construction work by Harbors itself. The process for Harbors plan reviewers is depicted in Attachment 1 of *Construction Site Runoff Control Program* manual (HDOTa, 2021).

#### 2.3 Tenant Improvement Project

Harbors tenants who wish to perform new construction, reconstruction, modification, or demolition, must submit a request to HDOT or Harbors for review and approval. As described in Section 4.2.2 of the *Construction Site Runoff Control Program* manual, HAR-EE will review the request received from the tenant and assess whether the tenant improvement project is subject to Harbors **Post-Construction Stormwater Management Program** requirements. If post-construction requirements are applicable, HAR-EE will advise Harbors Property Management Staff [HAR-PM] of the assessment results and require that the tenant prepare and submit a PSMP, *Construction Site Design Review Checklist* (HDOTa, 2021), as well as the *Permanent Post-Construction BMP Plan Checklist* (include in Attachment B) during the design phase. At this stage, project-specific stormwater pollution mitigation measures are developed and submittal package (including design plans and specifications, forms, and PSMP) is forwarded to HAR-EE for review and comment.

HAR-EE reviews the PSMP document and final design plans to verify that PSMP requirements are met. HAR-EE will notify HAR-PM when the PSMP is complete and contains necessary BMPs

(refer to Sections 3.2 to 3.4), utilizing an interoffice memorandum. Once this memo has been issued (and placed in the project file), HAR-PM can notify the tenant that the project is approved.

This process ensures that Harbors **Post-Construction Stormwater Management Program** requirements are incorporated into the project design and shown on the plans prior to approval. Any mitigation measures required by the environmental review process, such as implementation and maintenance of post-construction BMPs, become part of the lease or revocable permit and are inspected by tenants regularly as outlined in the PSMP.

To comply with its NPDES permit requirements and to minimize water quality impacts from new development and redevelopment, all Regulated Projects shall consider and apply post-construction BMPs, as appropriate.

This section provides a procedure for selecting post-construction BMPs for Regulated Projects. It includes identifying a list of pollutants of potential concern [POPC] and developing a PSMP to minimize water quality impacts through LID Site Design, Source Control, and Treatment Control BMPs. The procedure for determining the combination of these BMPs and their respective sizing is based on the *CCH Rules Relating to Water Quality* (Appendix D; CCH, 2018). It is also recommended that *CCH Storm Water BMP Guide* be used as a guide for post-construction BMP design and implementation (Appendix C; CCH, 2017). A flow chart summarizing the BMP selection procedure is depicted in Figure 3-1.

Figure 3-1
Post-Construction BMP Selection Procedure Flow Chart



#### 3.1 Identifying Pollutants of Potential Concern and Receiving Water Bodies

Two major water bodies under Harbors jurisdiction are Honolulu Harbor and Kalaeloa Barbers Point Harbor. Hawaii Department of Health [HDOH] lists Honolulu Harbor as impaired water for NH<sub>4</sub> and trash (HDOH, 2020). Kalaeloa Barbers Point Harbor has not been fully assessed. No state Total Maximum Daily Loads [TMDL] have been established for either harbor.

Urban runoff from a developed site can be potentially contaminated by pollutants (including trash, oil and grease, suspended solids, metals, gasoline, pesticides, and pathogens) prior to discharging into the stormwater conveyance system and receiving waters. The types of pollutant that may be generated at a site are related to land use and activities conducted on-site. A list of POPC is provided in Table 3-1. The *CCH Storm Water BMP Guide* provides a general guideline for a list of post-construction BMPs and targeted POPC.

Table 3-1
Pollutants of Potential Concern

		General Pollutant Categories							
Priority Project Categories	Sediment	Trash & Debris	Metals	Organic Compounds	Nutrients	Oxygen Demanding	Oil & Grease	Bacteria & Viruses	Pesticides
Commercial Development > 1 acre	P <sup>1</sup>	Р	Р	P <sup>2</sup>	P <sup>1</sup>	P <sup>5</sup>	Р	P <sup>3</sup>	₽5
(Heavy) Industry Development	Р	Р	Р	Р		Р	Р		
Automotive Repair Shops		Р	Р	P <sup>4,5</sup>			Р		
Restaurants		Р				Р	Р	Р	$P^1$
Parking Lots	P <sup>1</sup>	Р	Р		$P^1$	P <sup>1</sup>	Р		P <sup>1</sup>
Fueling Facility		Р	Р	Р		Р	Р		
Driveways	Р	Р	Р	P <sup>4</sup>	$P^1$	P <sup>5</sup>	Р		$P^1$

P: Potential

#### 3.2 Drainage Study and Identification of Conditions of Concern

Common impacts to the regional hydrology resulting from development typically include increased runoff volume and velocity; reduced infiltration; increased flow frequency, duration, and peak; shorter time to reach peak flow; and water quality degradation. These changes have the potential to negatively impact receiving water bodies, habitat integrity, and downstream channels (if any). A change to Regulated Project site's hydrology would be considered a condition of concern. To mitigate these potential impacts, the project proponent must prepare the following supporting documentation:

<sup>1:</sup> A potential pollutant if landscaping exists on-site.

<sup>2:</sup> A potential pollutant if the project includes uncovered parking areas.

<sup>3:</sup> A potential pollutant if land use involves food or animal waste projects.

<sup>4:</sup> Including petroleum hydrocarbons.

<sup>5:</sup> Including solvents.

- Evaluate the project's conditions of concern in a drainage study as part of the PSMP. The drainage study and the PSMP shall be prepared by a registered civil engineer in the State of Hawaii, with experience in drainage design and water resources management. The report shall consider the project location (from the larger watershed perspective), topography, soil and vegetation conditions, percent impervious area, natural and infrastructure drainage features, wet season groundwater depth, and any other relevant hydrologic and environmental factors to be protected specific to the nearest watershed.
- Field reconnaissance including observations of the site and upstream and downstream conditions. Existing conditions, such as undercutting erosion, slope stability, vegetative stress, and areas susceptible to erosion and/or habitat alteration as a result of altered flow regimes should be pointed out.
- Existing hydrologic conditions including description of the location, type, and percent
  cover of onsite vegetation, description of existing impervious features, description of
  existing stormwater conveyance features, description of distance to downstream water
  bodies, description of soil type (Natural Resources Conservation Service [NRCS]
  hydrologic soil classification and types), description of depth to groundwater during the
  wet season, description of offsite vegetation types, location, and percent cover.
- **Drainage study** information including, at a minimum, existing and post-construction descriptions of impervious area and percentages, rainfall intensities, geotechnical conditions regarding any planned uses of infiltration techniques (slope stability, expansive soils, compressive soils, seepage, groundwater depth, loss of foundation or pavement sub-grade strength), site constraints (impermeable soils, high groundwater, groundwater pollution or contaminated soils, steep slopes, high-intensity land use, vehicular traffic, restricted right-of-way, or safety concerns), flow rates, velocities, and/or durations for a peak rainfall intensity of 0.4 inches per hour and Water Quality Volume of one (1) inch. The drainage study must also include an analysis of proposed post-construction LID Site Design Strategies, Source Control, and/or Treatment Control BMPs to mitigate (downstream) impacts and attempt to maintain or improve pre-project hydrologic conditions.

#### 3.3 Post-Construction Stormwater BMP Selection

Post-construction BMPs shall be considered during the planning and design phases of a project. Each applicable project shall provide an account of how each drainage area's runoff is managed and treated. The entire project area can be divided into individual/discrete Drainage Areas [DA].

Post-construction BMPs include LID Site Design Strategies, Source Control, and Treatment Control BMPs.

Table 3-2
Post-Construction Best Management Practices

Eler	nent	Description				
LID Site Des	sign	Reducing the hydrologic impact of development and incorporating				
Strategies		techniques that maintain or restore the site's hydrologic and				
		hydraulic functions.				
Source Control		Preventing pollutants from coming into contact with runoff and preventing polluted runoff from discharging into small MS4.				
LID		Retaining runoff on-site with no off-site discharge by infiltration,				
	Retention	evapotranspiration, and harvesting/reuse.				
Treatment Control	LID Biofiltration	Removing pollutants from runoff by filtering stormwater through vegetation and soils.				
	Other Treatment	Removing pollutants from runoff by detention, settling, filtration, and vortex separation.				

To comply with this manual and be consistent with the *CCH Rules Relating to Water Quality*, the following criteria shall be met for all Regulated Projects where applicable:

- Incorporate appropriate LID Site Design Strategies Either retain the developing site Water Quality Volume with appropriate ID Retention Treatment Control BMPs, or biofilter the Water Quality Volume with appropriate LID Biofiltration Treatment Control BMPs, or a combination of the two, unless determined to be infeasible due to infiltration issues.
- 2. Incorporate appropriate Source Control BMPs.
- 3. If it is determined to be infeasible to retain and/or biofilter the Water Quality Volume then treat and discharge with appropriate Treatment Control BMPs any portion of the water that is not retained on-site or biofiltered using the CCH guidance in § 20-3-58 of the *Rules Relating to Water Quality* (CCH, 2018), unless a waiver is granted based on the infeasibility of all Treatment Control BMPs.

Consistent with the *CCH Storm Water BMP Guide* and based on collected precipitation data, 1 inch (or 1.5 inches) is the depth for all volume-based BMPs and a peak rainfall intensity of 0.4 inches per hour shall be used for flow-based BMPs. A flow chart summarizing the BMP selection process is provided in Figure 3-2 below.

LID Retention BMPs rely on the soil's ability to infiltrate stormwater runoff. Due to its proximity to ocean water, groundwater underneath Harbors property is relatively shallow and tidally influenced. Therefore, it is recognized that LID Retention BMPs may prove infeasible for majority of Regulated Projects. However, broader LID Site Design Strategies must be considered. For a

detailed discussion on infiltration requirements, please refer to General Infiltration Requirements outlined in Section 3 of *CCH Storm Water BMP Guide*.

Selection of Treatment Control BMPs must prioritize and maximize the removal of pollutants of potential concern. Treatment Control BMP design must also consider any impacts caused by tidal influence, which is particularly relevant to subsurface filtration systems, hydrodynamic separator systems, detention or infiltration basins, and wet ponds/wetlands.

Figure 3-2
BMP Selection Process for Pollutants of Potential Concern

#### **Implement LID Site Design Strategies**

- Conserve natural areas, soils and vegetation retain functions of predevelopment hydrology, including rainfall interception, evapotranspiration, and infiltration and therefore reduce runoff.
- Minimize disturbances to natural drainages and optimize the site layout preserve natural drainage features and design buildings and circulation to minimize roofs and paving.
- Minimize Soil Compaction retain existing beneficial hydrologic function.
- Minimize Impervious Surface allow natural processes to filter and reduce non-point sources of pollution.
- Direct runoff to landscaped areas and reduce directly connected impervious surfaces move runoff from impervious surfaces on to adjacent pervious surfaces (e.g., direct a roof downspout to disperse runoff onto a lawn).



## Landscaped areas Automatic irrigation Storm drain inlets (stenciling and signage) Vehicle/equipment fueling Loading docks Outdoor trash storage Outdoor material storage Outdoor work areas

- Vehicle/equipment maintenance/repair •
- Vehicle/equipment washing/cleaning

Outdoor work areasOutdoor process equipment operations

Parking areas



Implement Treatment Control BMPs that Maximize Removal of Pollutant(s) of Potential									
	Concern								
Considering Numeric Sizing Criteria a	and General Infiltration Requirements for	or:							
Retention BMPs	Biofiltration BMPs	Alternative Compliance BMPs							
<ul> <li>Infiltration basin/trench</li> <li>Subsurface infiltration system</li> <li>Dry well</li> <li>Bioretention basin</li> <li>Permeable pavement</li> <li>Harvest/Reuse</li> </ul>	<ul> <li>Green roof</li> <li>Vegetated bio-filter</li> <li>Dry Swale</li> <li>Vegetated swale</li> <li>Vegetated buffer strip</li> </ul>	<ul> <li>Manufactured treatment device</li> <li>Detention basin</li> <li>Sand filter</li> </ul>							

#### 3.4 Feasibility Criteria and Limitations

Different treatment control BMPs have their own limitations. This section is focused on the discussion of their feasibility criteria and limitations.

#### 3.4.1 Infiltration BMPs

Infiltration BMPs are considered infeasible and must not be used if any of the following conditions are met:

- 1) Soil beneath the BMP invert have measured infiltration rates of less than 0.5 inch/hour or are United States Department of Agriculture [USDA] Hydrologic Soil Group [HSG] "C" or "D" as reported by the USDA NRCS;
- The seasonally high groundwater table is within 3 feet from the BMP invert;
- 3) There is a documented concern that there is a potential onsite for soil pollutants, groundwater pollutants, or pollutants associated with industrial activities to be mobilized;
- 4) There are geotechnical concerns at the site;
- 5) Excavation for the installation of the BMP would disturb any archeological resources;
- 6) The BMP cannot be built within the following setbacks:
  - a. 50 feet from the nearest drinking water wells;
  - b. 35 feet from the nearest septic system;
  - c. 10 feet from the nearest private property line;
  - d. 20 feet from the nearest building foundation at the project site;
  - e. 100 feet from the nearest down-gradient building foundation; or
- 7) Infiltration facilities would conflict with the location of existing or proposed underground utilities or easements, or would result in their placement on top of underground utilities, or otherwise oriented to underground utilities, such that they would discharge to the utility trench, restrict access, or cause stability concerns.

#### 3.4.2 Harvest/Reuse

Harvest/Reuse is considered infeasible for any of the following reasons:

- 1) The demand is inadequate to reuse the required volume of water;
- The technical requirements cause the harvesting system to exceed 2 percent of the total project cost;
- 3) The site where a cistern must be located is at a slope greater than 10 percent;
- 4) There is no available space to locate a cistern of adequate size to harvest and use the required amount of water;
- 5) The cistern cannot be built within the following setbacks:
  - a. 10 feet from the nearest septic system;
  - b. 5 feet from the nearest private property line;
  - c. 5 feet from the nearest building foundation at the project site; or

6) The project includes a reclaimed water system and demand for a harvest/reuse system cannot be met.

#### 3.4.3 Vegetated Biofilters

Vegetated biofilters are infeasible for any of the following reasons:

- 1) Excavation would disturb any archaeological resources;
- 2) The invert of underdrain layer is below seasonally high groundwater table;
- 3) The site does not receive enough sunlight to support vegetation;
- 4) The site lacks sufficient hydraulic head to support BMP operation by gravity; or
- 5) Unable to operate off-line with bypass and unable to operate in line with safe overflow mechanism:

#### 3.4.4 Green Roof

Green roofs are infeasible for any of the following reasons:

- Roof space is unavailable dur to renewable energy, electrical, and/or mechanical systems; or
- 2) Slope on roof exceeds 25 percent (14 degrees)

#### 3.4.5 Dry Swales

Dry swales are infeasible for any of the following reasons:

- 1) Excavation would disturb any archaeological resources;
- 2) The invert of underdrain layer is below seasonally high groundwater table;
- 3) The site lacks sufficient hydraulic head to support BMP operation by gravity; or
- 4) Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.

#### 3.4.6 Vegetated Swales or Vegetated Filter Strips

Vegetated swales are infeasible for any of the following reasons:

- 1) The excavation would disturb any archaeological resources;
- 2) The site does not receive enough sunlight to support vegetation; or
- 3) Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.

#### 3.5 Post-Construction Stormwater Mitigation Plan Development

In order to ensure that a PSMP is adequately designed and integrated into each Regulated Project, project proponents are required to prepare a PSMP by a licensed civil engineer, registered in State of Hawaii. In general, the PSMP must clearly convey the process used to identify pollutants of potential concern, conditions of concern, selected BMPs for the project as well as identifying BMP long-term maintenance requirements. The fundamental components in preparation of PSMP are provided in Table 3-3. The CCH Storm Water BMP Guide provides a more complete list of LID Site Design Strategies, Source Control BMPs, and Treatment Control BMPs and must be utilized by project proponents. Additionally, project proponents must comply with all applicable requirements by Harbors **Post-Construction Stormwater Management Program** and not rely solely on the outline in Table 3-3.

PSMPs must contain a table of contents to assist reviewers in finding required parts of the document. PSMPs must contain a vicinity map (in scale) containing major roadways, geographic features or landmarks, the project site perimeter, general topography, downstream receiving water body, and north arrow. In addition, PSMPs must also contain a site map (including the entire property on one map or using a key map if multiple sheets are required), scale, north arrow, and legend, impervious features (including location of proposed impervious areas such as paved areas, buildings, covered areas, etc.), potential pollutant source areas (such as fueling area, garage, outdoor storage area, waste container area, wash-rack, potentially hazardous substance storage area). PSMP should contain the information specified in Table 3-3.

Table 3-3
Fundamental Components of a Post-Construction Stormwater Mitigation Plan for Regulated Project

Major Components	Descriptions			
Organization & Content	Table of contents			
	Vicinity map			
	Project description			
	Narrative of project activities			
Site Map	Entire property included on one map (use key map if multi-sheets)			
	Drainage areas and direction of stormwater flow			
	Private storm drain system(s)			
	Nearby water bodies and other municipal storm drain inlets			
	Location of stormwater conveyance systems (ditches, inlets, storm			
	drains, etc.)			
	<ul> <li>Location of existing and proposed stormwater controls</li> </ul>			
	• Location of "impervious" areas (i.e., paved areas, buildings, and			
	covered areas)			
	Locations where materials would be directly exposed to stormwater			

Major Components	Descriptions
	<ul> <li>Location of building and activity areas (e.g., fueling area, garages, waste container area, wash racks, potential hazardous substance storage areas, etc.)</li> <li>Areas of potential soil erosion (including areas downstream of project)</li> </ul>
Pollutants of Potential Concern	<ul> <li>Pollutants based upon land use</li> <li>Impaired water bodies downstream of the project</li> </ul>
Drainage Study and Conditions of Concern*	<ul> <li>Site-specific drainage analysis indicating pre- and post-development runoff calculations.</li> <li>Impacts to hydrologic regime (hydromodification evaluation, as applicable)</li> </ul>
Types of Post- Construction BMPs*	LID and Site Design BMP Examples  Conserve natural areas, soils, and vegetation Minimize impervious surface Direct runoff to landscaped areas  Source Control BMP Examples Covered trash storage Covered and bermed vehicle wash areas  Treatment Control BMP Examples Subsurface infiltration Manufactured treatment device
Post-Construction	O&M Plan
BMP Maintenance	Access Agreement

<sup>\*</sup> Refer to CCH Rules Relating to Water Quality and CCH Storm Water BMP Guide

#### 3.5.1 Introduction of Low Impact Development

LID is a stormwater management strategy concerned with maintaining or restoring the natural hydrologic functions of a site to achieve natural resource protection objectives and fulfill environmental regulatory requirements (CCH, 2017). It utilizes a variety of natural and built features that reduce the rate of runoff, filter out pollutants, and facilitate the infiltration of water into the ground. By reducing water pollution and increasing groundwater recharge, it helps sustain the quality of receiving waters and stabilize the flow rates of nearby surface waters. The goal of LID site design is to reduce the hydrologic impact of development and to incorporate techniques that maintain or restore the site's hydrologic and hydraulic functions. The optimal LID site design minimizes runoff volume and preserves existing flow paths.

LID employs principles such as preserving and recreating natural landscape features, minimizing effective imperviousness to create functional and appealing site drainage that treat stormwater as a resource rather than a waste product. Many practices have been used to adhere to these principles such as bioretention facilities, rain gardens, vegetated rooftops, rain barrels, and permeable pavements. By implementing LID principles and practices, water can be managed in

a way that reduces the impact of developed areas and promotes the natural movement of water within an ecosystem or watershed. The Harbors approach will consist of specific elements that are represented in Table 3-3.

#### 3.5.2 LID Site Design Strategies

Consideration of LID Site Design Strategies are required for each Regulated Project. A Regulated Project shall be designed to minimize directly connected impervious surfaces and to promote infiltration using LID techniques. A Regulated Project shall minimize the introduction of POPCs generated from site runoff to the stormwater conveyance system. A Regulated Project can address these objectives through the creation of a hydrologically functional project design that attempts to mimic the natural hydrologic regime. These techniques are outlined in Section 3.2 of *CCH Storm Water BMP Guide* (Appendix C; CCH 2017).

Mimicking a site's natural hydrologic regime can be pursued by:

- Reducing imperviousness, conserving natural resources and areas, maintaining and using natural drainage courses in the stormwater conveyance system, and minimizing clearing and grading.
- Providing runoff storage measures dispersed throughout a site's landscape with the use of bioretention facilities and detention, retention, and infiltration practices.
- Implementing on-lot hydrologically functional landscape design and management practices.

These design principles offer an innovative approach to urban stormwater management, one that does not rely on the conventional end-of-pipe or in-the-pipe structural methods but instead uniformly or strategically integrates stormwater controls throughout the urban landscape.

The following five LID components, taken from *CCH Storm Water BMP Guide*, must be considered for each Regulated Project.

#### Conserve Natural Areas, Soils, and Vegetation

This design strategy helps retain numerous functions of predevelopment hydrology, including rainfall interception, evapotranspiration, and infiltration. Maximizing these functions will thereby reduce the amount of runoff that must be treated. Protection of mature trees and vegetation provides habitat, prevents erosion, captures significant rainfall, provides summer shading, and reduces runoff volume and velocity, which protects and enhances downstream water quality.

#### **Minimize Disturbances to Natural Drainages**

Natural drainages offer a benefit to stormwater management as the soils and habitat already function as a natural filtering/infiltrating swale. Minimizing disturbances to natural drainage patterns preserves the predevelopment timing, rate, and duration of runoff as well as

preserving streamside habitats. When determining the development footprint of the site, natural drainages should be avoided. By keeping the development envelope set back from natural drainages, the drainage can retain its water quality benefit to the watershed.

#### Minimize Soil Compaction

Clearing, grading, and compaction by construction traffic reduces the natural absorption and infiltration capacities of the native soils. Soil compaction damages soil structure, reduces infiltration rates, limits root growth and plant survivability, and destroys soil organisms. Subsequent tilling and/or addition of soil amendments such as compost can help, but may not restore the original infiltration capacity of the soils. By protecting native soils and vegetation in appropriate areas during the clearing and grading phase of development, the site can retain some of its existing beneficial hydrologic function.

#### <u>Direct Runoff to Landscaped Areas and Reduce Directly Connected Impervious Areas</u>

Any impervious surface that drains into a catch basin, area drain, or other conveyance structure is a "directly connected impervious area." As stormwater runoff flows across parking lots, roadways, and paved areas, the oil, sediment, metals, and other pollutants are collected and concentrated. If this runoff is collected by a drainage system and carried directly along impervious gutters or in closed underground pipes, it has no opportunity for filtering by plant material or infiltration into the soil. It also increases in speed and volume, which may cause higher peak flows downstream, and may require larger capacity storm drain systems, increasing flood and erosion potential. Solutions that reduce "directly connected impervious areas" prevent runoff, detain or retain surface water, attenuate peak runoff rates, benefit water quality and convey stormwater.

#### **Minimize Impervious Surfaces**

The increased volume, increased velocity, and discharge duration of stormwater runoff from developed areas has the potential to accelerate downstream erosion and impair stream habitat in natural drainages. Studies have demonstrated a direct correlation between the degree of imperviousness of an area and the degradation of its receiving waters. Impervious surfaces (such as pavement and concrete) can neither absorb water nor remove pollutants, and thus the natural purification characteristics are lost. Reducing impervious surfaces to the minimum amount needed retains the permeability of the project site, allowing natural processes to filter and reduce non-point sources of pollution.

#### 3.5.3 Source Control BMPs

Source control BMPs are required for each Regulated Project. Proactively controlling POPC at their source is fundamental to effective stormwater quality management. Design of BMPs to minimize or prevent pollutant generation is guided by two general principles:

 Prevent stormwater from contacting operation and storage areas. These areas should be designed to prevent stormwater runoff from passing through shipping areas, vehicle

- maintenance yards, and other work places before it reaches storm drains. The objective is to prevent the discharge of water laden with grease, oil, heavy metals and process fluids to surface waters or sensitive resource areas.
- Prevent pollutants from contacting surfaces that mingle with stormwater runoff.
   Precautionary measures should be employed to keep POPC from coming into contact with storm or wash water runoff.

In preparation of PSMP, following items need to be provided:

- All potential sources of stormwater pollutants that can be potentially generated at the site.
- Corresponding post-construction BMPs that need to be shown on the site map included in the PSMP.
- A brief narrative description of the source control BMPs to be used including a discussion of the project applicant will ensure their continued operation.

Justification of why a particular source control could not be implemented for this project because of any special condition or situation, shall also be provided. Fact Sheets for applicable source control BMPs may be obtained from Appendix A of the *CCH Storm Water BMP Guide* (CCH, 2017) and/or the *California Stormwater Quality Association [CASQA] Stormwater Quality Handbooks* (CA, 2003). Descriptions of each Source Control Category (taken from *CCH Storm Water BMP Guide*) are summarized in Table 3-4.

Table 3-4
List of Source Control Categories
(taken from CCH Storm Water BMP Guide)

Source Control Category	General Description/Approach		
Landscaped Areas	Landscape planning should couple consideration of land suitability for urban uses with consideration of community goals and projected growth. Project plan designs should conserve natural areas to the maximum extent possible, maximize natural water storage and infiltration opportunities, and minimized project slopes and channels.		
Automatic Irrigation Systems	Irrigation water provided to landscaped areas may result in excess irrigation water being conveyed into storm water drainage systems. Project plan designs for development and redevelopment should include application methods of irrigation water that minimize runoff of excess irrigation water into the storm water conveyance system.		
Storm Drain Inlets	Storm drain signs and stencils are highly visible source controls that are placed directly adjacent to storm drain inlets. The stencil or affixed sign contains a brief statement that prohibits dumping of improper materials into the urban runoff conveyance system.		

Source Control Category	General Description/Approach			
	Stencils and signs alert the public to the destination of pollutants discharged to the storm drain.			
Vehicle/Equipment Fueling	Fueling areas have the potential to discharge oil and grease, solvents, car battery acid, coolant and gasoline to the storm drain. Spills can be a significant source of pollution because fuels contain toxic materials and heavy metals that are not easily removed by storm water treatment devices.			
Vehicle/Equipment Repair	Several measures can be taken to prevent operations at maintenance bays from contributing a variety of toxic compounds, oil and grease, heavy metals, nutrients, suspended solids, and other pollutants to the storm water conveyance system. In designs for maintenance bays containment is encouraged. Preventive measures include overflow containment structures are dead-end sumps.			
Vehicle/Equipment Washing & Cleaning	Vehicle/equipment washing, and steam cleaning may contribute high concentrations of pollutants to wash waters that drain to storm water conveyance systems. Wash water may not be conveyed to a sewer without a sewer connection permit.			
Loading Docks	Several measures can be taken to prevent operations at loading docks from contributing a variety of toxic compounds, oil and grease, heavy metals, nutrients, suspended solids, and other pollutants to the storm water conveyance system. In designs for loading docks, containment is encouraged. Preventive measures include overflow containment structures and dead-end sumps.			
Outdoor Trash Storage	Storm water runoff from areas where trash is stored or disposed of can be polluted. In addition, loose trash and debris can be easily transported by water or wind into nearby storm drain inlets, channels, and/or streams. Preventive measures including enclosures, containment structures, and impervious pavements to mitigate spills, should be used to reduce the likelihood of contamination.			
Outdoor Material Storage	Proper design of outdoor storage areas for materials reduces opportunity for pollutants to enter the storm water conveyance system. Materials may be in the form of raw products, by-products, finished products, and waste products. In outdoor storage areas, containment is encouraged.			
Outdoor Work Areas	Proper design of outdoor work areas (such as grinding, painting, coating, sanding, parts cleaning, etc.) reduces opportunity for pollutants to enter the storm water conveyance system. In outdoor work areas, infiltration and discharge to the storm drain are			

Source Control Category	General Description/Approach		
	discouraged; collection and conveyance to the sanitary sewer are encouraged.		
Outdoor Process Equipment Operation	Outdoor process equipment operations such as rock grinding or crushing, painting or coating, grinding or sanding, degreasing or parts cleaning, may contribute a variety of pollutants to the storm conveyance system. In outdoor process equipment areas, containment is encouraged, accompanied by collection and conveyance.		
Parking Areas	Parking lots and storage areas can contribute polluting substances, such as trash, suspended solids, hydrocarbons, oil and grease, and heavy metals that can enter receiving waters through storm water runoff or non-storm water discharge. The protocols in this fact sheet are intended to prevent or reduce the discharge of pollutants from parking/storage areas.		

#### 3.5.4 Treatment Control BMPs

When a site cannot retain all or portion of the Water Quality Volume on-site, the remaining portions of the water must be treated using Treatment Control BMPs specified in §20-3-58 of the *CCH Rules Relating to Water Quality* (Appendix D; CCH, 2018). Treatment Control BMPs are engineered technologies designed to remove pollutants from storm water runoff prior to being discharged to the storm drain system or receiving waters. Details on BMP numeric sizing criteria and general requirements for infiltration BMPs are further discussed in Section 3.5.5. Individual fact sheets for various treatment control BMPs may be found in Appendix B of the *CCH Storm Water BMP Guide* (Appendix C; CCH, 2017) and/or *CASQA Stormwater Quality Handbooks*.

Engineering details and specifications shall be included in the PSMP for the selected Treatment Control BMPs. Alternative post-construction BMPs not identified in the *CCH Storm Water BMP Guide* may be acceptable at the discretion of the Harbors, provided the alternative BMP is as effective in removal of pollutants of concern as other feasible BMPs.

#### 3.5.5 Numeric Sizing Criteria

This section presents the methodology for calculating the Water Quality Volume [WQV] and Water Quality Flow Rate [WQF], which are used to size the majority of the Treatment Control BMPs.

#### Water Quality Volume

The WQV is calculated using this equation:  $WQV = PCA \times 3630$ , where:

WQV = water quality design volume (in cubic feet)

P = design storm runoff depth (in inches)

C = volumetric runoff coefficient

A = total drainage area (in acres)

As specified in the CCH's Rules (CCH, 2018), a design storm runoff depth of **1 inch** shall be used for LID retention BMPs. A design storm runoff depth of **1.5 inches** shall be used for volume-based Biofiltration and Alternative Compliance BMPs. The volumetric runoff coefficient shall be calculated using the following equation as developed by USEPA for smaller storms in urban areas: C = 0.05 + 0.009I, where:

C = volumetric runoff coefficient

I = percent of impervious cover (expressed as a percentage)

#### **Water Quality Flow Rate**

The WQF is calculated using this equation:  $WQF = 1.5 \times CiA$ , where:

WQF = water quality design flow rate (in cubic feet per second)

C = volumetric runoff coefficient

*i* = peak rainfall intensity (in inches per hour)

A = total drainage area (in acres)

As specified in the CCH's Rules (CCH, 2018), a peak rainfall intensity of **0.4 inches per hour** shall be used. The runoff coefficient shall be determined from Table 3-5 below, based on the drainage area, and shall be, at a minimum, the midpoint of the given range of values. The higher value should be used if soil conditions indicate that pervious areas will have little infiltration/interception potential. For drainage areas containing multiple land uses, the following formula may be used to compute a composite weighted runoff coefficient:

$$C_C = (\sum_{i=1}^n C_i A_i)/A_t$$
, where:

 $C_c$  = composite weighted runoff coefficient

 $C_{1,2,...,n}$  = runoff coefficient for each land use cover type

 $A_{1,2,...,n}$  = drainage area of each land use cover type (in acres)

 $A_t$  = total drainage area (in acres)

#### **Drainage Areas**

The entire area of applicable project shall be divided into individual, discrete DAs and clearly presented in a site map. DAs may be defined using grade breaks and roof ridge lines. Separate DAs shall be used for each surface type (e.g., landscaping, pervious paving, or roofs). Each type of DA surface has a unique runoff factor that estimates how much rainfall will produce effective rainfall, or runoff from that drainage area. A list of runoff coefficient for surfaces draining to BMPs is included in Table 3-5 of this manual and Subchapter 7 §20-3-58 of the *CCH Rules Relating to Water Quality* (CCH, 2018; Appendix D).

Table 3-5
Runoff Coefficients for Water Quality Flow Calculations

Type of Surface	Runoff Coefficient ( <i>C</i> )	Type of Surface	Runoff Coefficient ( <i>C</i> )
Roof	0.90	Gravel over Porous Plastic	0.05
Concrete	0.80	Pervious Concrete	0.10
Stone, brick, or concrete pavers with mortared joints and bedding	0.80	Stone, brick, or concrete pavers with sand joints and bedding	0.70
Asphalt	0.70	Porous asphalt	0.10
Permeable interlocking concrete pavement	0.10	Grid pavements with grass or aggregate surface	0.10
Grass	0.10	Grass over Porous Plastic	0.05
Crushed aggregate	0.10	orm treatment design and should not be	used for flood control

Note: These runoff coefficients are only appropriate for small storm treatment design and should not be used for flood control sizing.

#### 4.1 Installation Inspection during Construction Phase

Inspections will be conducted at multiple stages of construction to ensure the proper installation of all LID Site Design Strategies, Source and Treatment Control BMPs. For Harbors Projects, these inspections shall coincide with the site-specific construction site BMP inspections described in Sections 3.4.1 to 3.4.3 of Harbors *Construction Site Runoff Control Program* manual. For Tenant projects, these inspections shall coincide with the site-specific construction site BMP inspections described in Sections 4.4.1 to 4.4.3 of Harbors *Construction Site Runoff Control Program* manual. In either case, inspections shall include:

- Initial BMP Inspection prior to commencement of construction;
- Recurring BMP Inspection during active construction to ensure selected post-construction BMP is installed in accordance with accepted plan; and
- Final BMP Inspection upon completion of construction to ensure proper installation and maintainability.

The BMP inspections may be combined with other inspections provided that they will be conducted by trained personnel, as identified in Section 7. The findings from these inspections will be recorded on the *Construction Site Best Management Practices Inspection Checklist* contained in Attachment 4 of the *Construction Site Runoff Control Program* (or its equivalent form in AMS). Each inspection will be reported in the Annual Compliance Report [ACR] and shall be clearly linked to the referenced project and note the stage of the project and the dates of inspections.

Once built, post-construction stormwater BMPs must be properly maintained to make sure they are operating as designed and intended.

- For Harbors project, O&M will be conducted by Oahu District following the plan that was submitted and approved as part of the project review and approval process.
- For Tenant projects, O&M and inspection requirements are documented in an O&M plan
  that must be submitted to the Harbors prior to completion of construction. All O&M
  activities will be the responsibility of the tenant and shall be conducted following the O&M
  plan that was submitted and approved as part of the project review process and recorded
  with the lease, revocable permit, or other contractual document provisions. The tenant
  O&M plan shall be consistent with the requirements in Section 5.1 below.

Harbors will verify that appropriate mechanisms, including O&M plans, are in-place for all projects under Harbors jurisdiction that have post-construction BMPs. Maintenance requirements identified below are required by Harbors **Post-Construction Stormwater Management Program**.

#### **5.1** Maintenance Requirements

#### Operation & Maintenance Plan:

For a Regulated Project, Harbors will require that a copy of a satisfactory O&M plan, monitoring plan where applicable (for example, a sample O&M and Inspection Checklist for a CDS unit is enclosed in Appendix E), and a process for ongoing maintenance verification of installed controls be included in the design submittal package. The O&M Plan must contain the following major components:

- The designated responsible party to manage the post-construction stormwater BMP(s).
- Post-Construction operating schedule, maintenance frequency, specific maintenance activities.
- Any necessary employee training and duties.
- Recordkeeping and reporting on inspecting and servicing of all post-construction BMPs (on source/treatment control) at least annually, which are documented using the form(s) in the O&M plan.

Access Agreement: The Harbors maintains rights to access tenant properties as part of lease or revocable permit provisions. These rights extend to any access required related to post-construction BMPs. An example of the access agreement is included in Attachment 2 of Harbors *Tenant Inspection Manual* (HDOTb, 2021).

#### 5.2 Verification Mechanisms

Annual O&M record of each approved post-construction BMP by the responsible party (e.g., contractor, consultant, or tenant) is required to be submitted to the Harbors.

- For Harbors Projects, HAR-E will verify that post-construction BMPs reflected in the approved PSMP be implemented at the completion of construction. District office will be responsible for long-term O&M of post-construction BMPs and related recordkeeping. Records will be reported in the ACR.
- For Tenant Project, HAR-EE and HAR-PM will verify that post-construction BMPs in the approved PSMP be implemented at the completion of construction. The tenant will be responsible for long-term O&M of post-construction BMPs by conducting routine inspections, documenting all maintenance requirements, submitting annual reports (to Harbors), and retaining records for at least three years. These documents shall be made available to the Harbors for inspection upon request at any time.

#### **5.3** Post-Construction BMP Inspection

To ensure that post-construction stormwater BMPs are being operated and maintained in accordance with the approved O&M plan, all LID Site Design, Source and Treatment Control BMPs in the O&M plan will be inspected no less than once a year. Additionally, some BMPs may be inspected more frequently as recommended in *CCH Storm Water BMP Guide* (CCH, 2017; Appendix C) or manufacturer's manual. When possible, inspections shall occur after a storm event to allow an evaluation of the BMP's effectiveness, identification of any damage that may have occurred, and a determination if any additional maintenance may be required. Specifically, O&M inspections shall be performed and documented as following:

- For Harbors Projects, Oahu District will inspect the post-construction stormwater BMPs as specified in the O&M plan but no less than annually.
- For Tenant Projects, the tenant is to conduct inspections per the approved O&M plan and submit an annual report to Harbors when specified in the lease agreement and revocable permit. HAR-EE inspectors will check the post-construction BMP O&M records at a frequency determined by Harbors *Tenant Inspection Program* (i.e., every six months, annually, or every five years).
- Inspection should be documented using the Inspection Checklist included as part of the O&M plan. Relevant records will be retained in the AMS. All deficiencies noted during the inspections shall be conveyed to the responsible party and HAR-EE will conduct timely follow-up to ensure deficiencies are rectified.

#### 5.4 Post-Construction BMP Inventory and Recordkeeping

Harbors has been utilizing the AMS to keep track of approved post-construction BMPs (i.e., LID Site Design Strategies, Source Control, and Treatment Control BMPs) and the related O&M,

which serves as the basis for the maintenance, inspection, enforcement, and reporting elements of the program. This inventory includes the BMPs for Harbors project(s) and Tenants project(s) (subject to Lease Agreement and Revocable Permit) that discharge into the Honolulu and Kalaeloa Barbers Point Harbors Small Municipal Separate Storm Sewer Systems [MS4s].

All known post-construction BMPs at Honolulu and Kalaeloa Barbers Point Harbors have been logged into the electronic inventory. All new post-construction BMPs, as reflected in the approved PSMP will be added to the AMS following construction project acceptance. The construction project review, submittal requirements, and procedures, detailed in Section 4.3 of the *Construction Site Runoff Control Program*, provide information about the new post-construction BMPs. General site information includes:

- Project Identifier, Owner Information
- Project Location (Harbor, Pier Number, Tax Map Key Number, Latitude/Longitude coordinates)
- Acreage
- Control Type and Description of post-construction BMPs
- Photographs of BMPs during construction (if available) and at acceptance
- Date of Acceptance/Construction
- Date of Agreement
- O&M plan
- Maintenance Records
- Inspection Dates and Summary
- Corrective Actions
- Replacement or Repair Date

#### 6.0 ENFORCEMENT

A detailed discussion on enforcement is presented in the Harbors **Enforcement Response Plan** (HDOT, 2020). Enforcement of tenant construction projects will be undertaken by the HAR-EE, HAR-PM, and/or other staff who possess enforcement authority through established policies and procedures as described in Harbors Enforcement Response Plan. There are several enforcement mechanisms and penalties to ensure compliance with local ordinances, permits, and contract documents. The enforcement actions proceed along different routes depending upon whether the project is a Harbors Project or a Tenant Project.

When post-construction stormwater BMP inspections reveal improper installation or maintenance, Harbors will undertake appropriate enforcement action. The level of enforcement (summarized in Section 6.2) and associated penalty are typically issued by designated personnel after considering all relevant circumstances regarding the violation. Records of all inspections and follow-up activities for deficiencies are to be retained for a minimum of five years.

#### 6.1 Scope of Authority

The enforcement options available to Harbors range from administrative actions (including verbal/written warnings) to the termination of agreements, such as leases, revocable permits, and construction contracts. In addition to applicable federal, state, and county laws, rules, and regulations, Harbors regulatory and enforcement authority is found in:

- Hawaii Revised Statutes [HRS] Chapter 266 authorizes Harbors to issue citations and summons for violations of its rules and have its actions enforced through the district courts by verdict of a misdemeanor or fine.
- Hawaii Administrative Rules [HAR] Title 19 Chapters 41 to 44 establishes uniform safety measures, operational standards and requirements, and the conduct for all tenants at State of Hawaii harbors.
- The construction contracts that provide Harbors with the right of entry to conduct inspections and authority to issue a Stop Work Order [SWO] and/or withhold Contractor payments.
- The tenant lease agreement, revocable permit, or other occupancy agreements that provides Harbors with the right of entry to conduct inspection and authority to terminate the agreements, through the processes, as applicable, identified in HRS Title 12 Chapter 171 and Title 15 Chapter 266, and HAR Title 19 (Chapters 41 through 44).

#### **6.2** Enforcement Actions

The levels of enforcement actions to be utilized, in order of increasing severity, are as follows:

- Oral or Verbal Warning
- Written Warning (e.g., Tenant Inspection Report or Letter with Tenant Inspection Report)

- Notice of Apparent Violation [NAV]
- Notice and Finding of Violation Order [NFVO]
- Stop Work Order
- Assessment of Environmental Liquidated damages [ELD]
- Cost of Labor and Materials [L&M]
- Withholding of Payments
- Termination of Agreements

Detailed discussion of these enforcement actions could be found in the Harbors **Enforcement Response Plan** (HDOT, 2020).

There are two types of violations – Class I Violation and Class II Violation, which are based on potential to discharge or cause environmental harm, magnitude of the violation (e.g., failure to apply for Industrial General Permit Coverage), duration of the violation, and violator's compliance history. A range of issues, which could result in enforcement (either informal or formal) in terms of post-construction BMP, includes:

- Failure to maintain a BMP specified in the submitted PSMP,
- Failure to maintain a BMP consistent with O&M Plan,
- Failure to address deficiencies.
- Failure to conduct annual inspection,
- Failure to submit required inspection documentation.

In the event that an enforcement action is required, the designated staff will identify the appropriate enforcement response to achieve compliance. If the violator cannot achieve compliance by implementing the appropriate corrective action, the designated staff will "escalate" the enforcement response as outlined in Harbors **Enforcement Response Plan**.

#### 7.0 **TRAINING**

Training is a vital component of any successful stormwater program. Harbors will adopt *CCH Rules Relating to Water Quality* and *CCH Storm Water BMP Guide* as a reference for those parties who apply for project approvals on selection, design, installation, O&M of stormwater BMPs via the state website and handouts.

Harbors provides training so that employees have the knowledge and skills necessary to perform their functions effectively and efficiently. Related training courses provide a comprehensive review of post-construction stormwater BMPs, introduce LID practices, and provide updates on the relevant requirements of the Harbors SWMP.

Appropriate Harbors staff whose primary job duties are related to implementing post-construction BMPs will be trained to have a clear understanding of their responsibilities. The post-construction BMPs training will consist of overall program goals and implementation. The content of the training will include:

- Post-Construction Technical Standards and use of the Post-Construction BMP Checklist including the existing and CCH Rules Relating to Water Quality and CCH Storm Water BMP Guide
- Content and Requirements of PSMP and O&M Plans
- Inspection Procedures
- Implementing the Enforcement Response Plan
- Recordkeeping

## <u>Annual Training for Designers, Plans Reviewers, Inspectors, Construction managers, and</u> Contractors

This training course for HAR-E engineers and available to other Harbors employees and consulting engineers, construction consulting professionals, and contractors will cover planning and design considerations for the proper selection, design, installation, operation, and maintenance of post-construction stormwater BMPs. It also includes an introduction to LID stormwater management practices.

#### **Training for Operations and Maintenance**

This course for Oahu District and available to other Harbors employees, will cover proper O&M of post-construction BMPs owned and operated by Harbors.

Training effectiveness will be evaluated through a survey of the participants. All participants will be required to sign in. Feedback from the survey will be collected and evaluated and used for the development of future training session. Relevant training records will be included in the ACR.

#### 8.0 REFERENCES


- CA, 2003a, *California Stormwater BMP Handbooks* Industrial and Commercial): State of California, January 2003.
- CA, 2003b, California Stormwater BMP Handbooks New Development and Redevelopment: State of California, January 2003.
- CCH, 2011, Best Management Practices Manual for Construction Sites in Honolulu: City and County of Honolulu, Department of Environmental Services, November 2011.
- CCH, 2017, Stormwater BMP Guide for New and Redevelopment: City and County of Honolulu, Department of Planning and Permitting, July 2017.
- CCH, 2018, *Rules Relating to Water Quality*: City and County of Honolulu, Department of Facility Maintenance, December 24, 2018.
- CSD, 2007, Low Impact Development Handbook Stormwater Management Strategies: County of San Diego, Department of Planning and Land Use, December 31, 2007.
- Edward, 2001, Honolulu International Airport Stormwater Pollution Control Plan and Related Stormwater Management Program Components: Edward K. Noda and Associates, Inc. November 2001.
- HDOH, 2014, *Hawaii Administrative Rules, Chapters 11-54*: State of Hawaii, Department of Health. November 2014.
- HDOH, 2019, *Hawaii Administrative Rules, Chapters 11- 55 Appendix B*: State of Hawaii, Department of Health. February 2019.
- HDOH, 2020, 2020 State of Hawaii Water Quality Monitoring and Assessment Report: Integrated Report to the U.S. Environmental Protection Agency and the U.S. Congress Pursuant to §303(d) and §305(b), Clean Water Act (P.L.97-117), State of Hawaii, Department of Health, June 30, 2020.
- HDOT, 2020, *Enforcement Response Plan*, State of Hawaii, Department of Transportation, Harbors Division, April 2020.
- HDOTa, 2021, *Construction Site Runoff Control Program*, Version 11.0: State of Hawaii, Department of Transportation, Harbors Division, September 2021.
- HDOTb, 2021, *Tenant Inspection Manual, Version 10.0*: State of Hawaii, Department of Transportation, Harbors Division, September 2021.

- USEPA, 2006, National Summary of Impaired Waters and TMDL Information Listed Waters for Reporting Year 2006 Hawaii, Oahu: Environmental Protection Agency, <a href="http://iaspub.epa.gov/tmdl">http://iaspub.epa.gov/tmdl</a> waters10/attains watershed.control
- USEPA, 2012, Stormwater Discharges (applicable to State NPDES Programs: Environmental Protection Agency, Code of Federal Regulations, Title 40, §122.26.

## **Appendix A**

# HDOT Harbors Division Administrative Organizational Chart

#### State of Hawaii Department of Transportation Harbors Division Administrative Organizational Chart



## **Appendix B**

## Permanent Post-Construction Best Management Practices Plan Checklist





#### **Permanent Post-Construction Best Management Practice Plan Checklist**

For a Harbors Project, please fill in this section

Project Title:	
Project Location:	
Acreage of Site:	Harbors Project No.:
Name of Design Firm:	Halbors Froject No
Email:	Phone No.:
ETHOR.	i none no
For a Tenant Improvement or other no	on-Harbors Project, please fill in this section
Tenant Business Name:	Date:
Project Title:	
Project Location:	
Acreage of Site:	TMK No. (if any):
Applicant Name:	Job Title:
Email:	Phone No.:
0:	and One (Cont.)
	and Certifications
best of my knowledge.	curate, and addresses the items on this checklist to the
Print Name:	Job Title:
Signature:	Date:
Review: HDOT Harbors Project/Property Manage	er and Environmental Section.
Harbors Project/Property Manager Signature:	
	Print Name:
	Date:
Harbors Environmental Section Signature:	Print Namo:
	Print Name:
	Date:



Part One - Low Impact Development Site Design Strategies				
The following checked strategies will be	incorporated and area(s) is denot	ed on the map:		
☐ Conserve natural areas, soils, and vegetation ☐ Minimize soil compaction				
☐ Minimize disturbances to natural	drainages	pervious surface		
☐ Direct Runoff to Landscaped Area	as None (all infe	easible)		
If "None" is checked, please provide	justification here:			
F	Part Two – Source Control			
The following checked Source Control E	3MP(s) will be incorporated and are	ea(s) is denoted on the map:		
☐ Automatic irrigation systems	☐ Landscaped areas	☐ Loading docks		
☐ Vehicle/Equipment fueling	☐ Vehicle/Equipment repair	☐ Vehicle/Equipment washing		
☐ Outdoor work areas	Outdoor material storage	Outdoor trash storage		
☐ Outdoor process operations	☐ Parking areas	Others		
If "Others" is checked, please describ	be here (attach separate sheets if	f needed):		
Pa	rt Three – Treatment Control			
The following checked Treatment Control				
☐ Infiltration basin	Infiltration trench	Subsurface Infiltration		
☐ Dry well	☐ Bioretention basin	☐ Permeable pavement		
Green roof	☐ Bioretention filter	☐ Dry swale		
☐ Downspout dispersion	☐ Vegetated swale	☐ Vegetated buffer strip		
☐ Tree box filter	vegetated swate	vegetated bullet strip		
Alternative Compliance. The following a	alternative compliance is proposed	and area(s) is denoted on the map:		
☐ Incorporate the following alternati		und drou(o) to deficited on the map.		
☐ Detention basin	Sand filter	☐ Rain barrel		
	☐ Manufactured treatment device			
Other (specify):	device			
☐ Source Control BMPs are designed with	reference to the City and County of H	Ionolulu Storm Water BMP Guide.		
☐ Treatment Control BMPs are designed w				

# Appendix C CCH Storm Water BMP Guide




## STORM WATER BMP GUIDE FOR NEW AND REDEVELOPMENT

for the City and County of Honolulu Permit No. HI S000002

**July 2017** 

Prepared by
City and County of Honolulu,
Department of Planning and Permitting






## **Table of Contents**

TAB	LE OF	CONTE	NTS	i
LIST	Γ OF TA	BLES		v
LIST	r of fic	GURES		vii
LIST	Γ OF AP	PENDIC	CES	ix
LIST	Γ OF AC	CRONYN	AS AND ABBREVIATIONS	xi
GLC	SSARY			xiii
ACK	KNOWL	EDGEM	ENTS	xix
1.	INT	RODUC'	TION	1-1
	1.1.	Purpos	se and Scope	1-1
	1.2.	Users	of the Manual	1-1
	1.3.	Organ	ization of the Manual	1-2
	1.4.	Low I	mpact Development and Storm Water Quality	1-2
	1.5.	Regula	atory Requirements	1-6
		1.5.1.	Federal Programs	1-6
		1.5.2.	State Programs	1-6
		1.5.3.	Other Relevant Regulatory Programs	1-7
		1.5.4.	Total Maximum Daily Loads	1-7
		1.5.5.	Endangered Species Act	1-7
		1.5.6.	Clean Water Act Section 404 Dredge and Fill Permits	1-7
		1.5.7.	Clean Water Act Section 401 Water Quality Certification	1-8
2.			ON OF PERMANENT BMP REQUIREMENTS IN THE CITY A	
			F HONOLULU	
	2.1.	-	nd County of Honolulu Plan Review Requirements	
		2.1.1.	Storm Water Quality Strategic Plans	
		2.1.2.	Storm Water Quality Reports	
		2.1.3.	Storm Water Quality Checklists	
		2.1.4.	Operations and Maintenance Plan	
		2.1.5.	BMP Certification and Recording	
		2.1.6.	Variances	2-6


3.		STORM WATER QUALITY PLANNING FOR NEW DEVELOPMENT AND REDEVELOPMENT			
	3.1.		Site Conditions.		
		3.1.1.			
	3.2.		esign Strategies		
			Conserve Natural Areas, Soils, and Vegetation		
		3.2.2.	Minimize Disturbances to Natural Drainages		
		3.2.3.	Minimize Soil Compaction		
		3.2.4.	Direct Runoff to Landscape Areas and Reduce Directly Connected		
			Impervious Areas	3-5	
		3.2.5.	Minimize Impervious Surfaces	3-6	
	3.3.	Contro	l Sources of Pollutants	3-10	
	3.4.	Treat F	Runoff	3-12	
4.	SITE		ACILITY DESIGN FOR WATER QUALITY PROTECTION		
	4.1.	Infiltra	tion	4-1	
	4.2.	Retenti	ion and Detention	4-3	
	4.3.	Biofilte	ers	4-4	
	4.4.	Street Design			
	4.5.	Street Trees			
	4.6.	Parking	g Lots	4-7	
		4.6.1.	Hybrid Parking Lots	4-7	
		4.6.2.	Parking Grove	4-9	
		4.6.3.	Overflow Parking		
		4.6.4.	Porous Pavement with Subsurface Infiltration	4-10	
	4.7.	Driveways			
	4.8.	Landscape and Open Space			
	4.9.	Multip	le Small Basins	4-12	
	4.10.	Plannii	ng Development Strategies in Practice	4-13	
5.	TREA	ATMEN	Γ CONTROL BMP DESIGN	5-1	
	5.1.	Best M	Ianagement Practices Selection		
		5.1.1.	Determine Drainage Management Areas	<i>5-1</i>	
		5.1.2.	Evaluate Pollutants of Concern		
		5.1.3.	Identify Candidate BMPs	5-2	
		<i>5.1.4</i> .	Consider Operation and Maintenance Requirements	5-5	
		5.1.5.	Other Considerations	5-7	
	5.2.	Numer	ric Sizing Criteria		
		5.2.1.	Volume-Based Best Management Practice Design		
		5.2.2.	Flow-Based BMP Design		
		<i>5.2.3</i> .	Combined Volume-Based and Flow-Based BMP Design	5-10	

	5.3.	Infiltration Requirements	5-10
		5.3.1. Soil Types and Textures	
		5.3.2. Field Investigations	
		5.3.3. Design Infiltration Rates	
	5.4.	Technology Certification	
	5.5.	Feasibility Criteria	
		5.5.1. Infiltration Feasibility	
		5.5.2. Harvest/Reuse Feasibility	
		5.5.3. Biofiltration Feasibility	5-15
6. 7.		SIDERATIONS FOR CONSTRUCTION TREATMENT CONTROL E	
<b>/•</b>	7.1.	Consideration when Selecting Treatment BMPs	
		7.1.1. Sediment and Oil Removal and Disposal	
		7.1.2. Maintenance Costs	
	7.2.	Developing the O&M Plan	7-2
	7.3.	Maintenance Agreements, Certification, and Modifications	
	7.4.	Inspection Requirements	
	7.5.	Minimum Maintenance Requirements	7-3
R	REFI	FRENCES	8-1



## **List of Tables**

Table 1.1: Pollutants and Impacts on Water Quality	1-5
Table 2.1: Summary of Post-Construction Requirements for New and Redevelopment	2-3
Table 3.1: Estimated C-Factor for Various Surfaces during Small Storms	3-8
Table 3.2: Conventional Paving Surface Small Storm C-Factor versus Alternative Paving C-Fa	ictors 3-10
Table 4.1: Comparison of Three Alternatives	4-16
Table 5.1: Typical Pollutants Associated with Priority Projects	5-3
Table 5.2: Treatment Control BMP Categories	5-3
Table 5.3: Treatment Control BMP Expected Pollutant Removals	5-4
Table 5.4: Recommended Selection of Permanent BMPs	5-5
Table 5.5: Summary of Operation and Maintenance Effort for BMPs	5-5
Table 5.6: Maintenance Rank Definition	5-6
Table 5.7: Runoff Coefficients for Water Quality Flow Calculations	5-9
Table 5.8: Typical Soil Infiltration Rates <sup>a</sup>	5-11
Table 5.9: Test Pit/Boring Requirements for Infiltration	5-13



## **List of Figures**

Figure 1.1: Document Organization	1-3
Figure 1.2: Impacts of Urbanization	1-4
Figure 2.1: Implementation of the CCH Water Quality Rules	2-2
Figure 3.1: Project Life Cycle	3-1
Figure 3.2: Hydraulic Altercation after Certain BMPs are Implemented	3-3
Figure 3.3: Directly Connected Impervious Area versus Directing Runoff to Landscaped Areas	3-5
Figure 3.4: Parking Lot Directing Runoff to Landscape Areas	3-6
Figure 3.5: Use of Self-Mitigating Areas	3-9
Figure 3.6: Self-Mitigating Areas Treatment Volume	3-9
Figure 3.7: Example of Source Control Design for Outdoor Material Storage	3-11
Figure 4.1: Infiltration Basin.	4-1
Figure 4.2: Typical Infiltration Facility Schematic	4-2
Figure 4.3: Typical Bioretention Schematic	4-2
Figure 4.4: Simple Detention System	4-3
Figure 4.5: Retention System	4-3
Figure 4.6: Vegetated Swale	4-4
Figure 4.7: Schematic of Planter Box with Down Spout Connection and Underdrain	4-5
Figure 4.8: Comparison of Street Cross-Section (Two-Way, Residential Access Streets)	4-6
Figure 4.9: Hybrid Parking Lot.	4-8
Figure 4.10: Hybrid Parking Lot (Honolulu, HI).	4-8
Figure 4.11: Turf Blocks	4-8
Figure 4.12: Permeable Joints	4-8
Figure 4.13: Parking Grove 1.	4-9
Figure 4.14: Parking Grove 2.	4-9
Figure 4.15: Overflow Parking	4-9
Figure 4.16: Subsurface Infiltration System	4-10
Figure 4.17: Unit Pavers	4-11
Figure 4.18: Crushed Aggregate	4-11
Figure 4.19: Paving only under Wheels	4-11
Figure 4.20: Alternative 1 - Conventional	4-14

#### List of Figures

Figure 4.21: Alternative 2 - Hybrid/Best Practices	4-15
Figure 4.22: Alternative 3 - Neo-Traditional	4-15
Figure 5.1: DMA Delineation	5-1
Figure 5.2: Unit Water Quality Volume for 1 and 1.5 inch Runoff Depth	5-8
Figure 5.3: Unit Water Quality Flow	5-10
Figure 5.4: USDA Soils Textural Triangle	5-11

## **List of Appendices**

APPENDIX A: SOURCE CONTROL BMP FACT SHEETS	A-1
SC-01: Landscaped Areas	A-3
SC-02: Roof Runoff Controls	A-7
SC-03: Automatic Irrigation System	
SC-04: Storm Drain Inlet	A-15
SC-05: Alternative Building Materials	A-19
SC-06: Vehicle/Equipment Fueling	A-23
SC-07: Vehicle/Equipment Repair	A-27
SC-08: Vehicle/Equipment Cleaning	A-29
SC-09: Loading Dock	A-33
SC-10: Outdoor Trash Storage	A-37
SC-11: Outdoor Material Storage	A-41
SC-12: Outdoor Work Areas	A-45
SC-13: Outdoor Process Equipment Operations	A-49
SC-14: Parking Areas	A-53
APPENDIX B: TREATMENT CONTROL BMP FACT SHEETS	B-1
TC-01: Infiltration Basin	B-3
TC-02: Infiltration Trench	B-9
TC-03: Subsurface Infiltration	B-15
TC-04: Dry Well	B-17
TC-05: Bioretention Basin	B-21
TC-06: Permeable Pavement	B-27
TC-07: Green Roof	B-33
TC-08: Vegetated Bio-Filter	B-37
TC-09: Enhanced Swale	B-43
TC-10: Vegetated Swale	B-49
TC-11: Vegetated Buffer Strip	B-55
TC-12: Harvest/Reuse	B-59
TC-13: Detention Basin	B-67
TC-14: Manufactured Treatment Device	D 73
10 1 11 1/14/14/14/14/14 11 (44/14/14/14/14/14/14/14/14/14/14/14/14/1	B-/3

#### List of Appendices

APPENDIX C: O&M FACT SHEETS	
OM-01: Bio-Retention Basin	
OM-02: Detention Basin	
OM-03: Green Roof	
OM-04: Infiltration Trench/Basin	
OM-05: Manufactured Treatment Device	
OM-06: Pervious Pavement	
OM-07: Rainwater Harvesting	
OM-08: Sand Filter	
OM-09: Vegetated Biofilter	
OM-10: Vegetated Swale/Strip.	

## List of Acronyms and Abbreviations

§	Section	DLNR	State of Hawaii, Department of Land and Natural
%	Percent		Resources
ACQ	Ammoniacal Copper Quarentary	DMA	Drainage Management Area
BMP	Best Management Practice	DOFAW	Division of Forestry and Wildlife, Department of Land and Natural Resources, State
CASQA	California Stormwater Quality Association		of Hawaii
CCA	Chromated Copper Arsenate	DOH	Department of Health, State of Hawaii
City	City and County of Honolulu (or CCH)	DPP	Department of Planning and Permitting, City and County
COE	See USACE		of Honolulu
CORP	See USACE	ft	foot (or feet)
cu-ft	Cubic Feet (or feet³)	HAR	Hawaii Administrative Rules
CWA	Clean Water Act	HDPE	High-Density Polyethylene
CWB	Clean Water Branch,	hr	Hour
52	Department of Health, State of Hawaii	HSG	Hydrologic Soil Group
CWPPP	Certified Water Pollution Plan	in	Inch (or inches)
01111	Preparer	IPM	Integrated Pest Management
CZMA	Coastal Zone Management Act	LID	Low Impact Development
DCIA	Directly Connected	MEP	Maximum Extent Practicable
DCIA	Impervious Area	min	Minute
DFM	Department of Facility Maintenance, City and County of Honolulu	mph	Miles per Hour

MS4	Municipal Separate Storm Sewer System	SWPCP	Storm Water Pollution Control Plan
NJCAT	New Jersey Department of Environmental Protection, New Jersey Corporation for Advanced Technology	SWQ	Storm Water Quality Branch, Department of Facility Maintenance, City and County of Honolulu
NJDEP	New Jersey Department of Environmental Protection	SWQR	Storm Water Quality Report
	Protocols	TAPE	Washington State Department
NOC	Notice of Cessation		of Ecology, Technology Assessment Protocol - Ecology
NOI	Notice of Intent		-
NPDES	National Pollutant Discharge	TMDL	Total Maximum Daily Load
	Elimination System	TSS	Total Suspended Solids
O&M	Operations and Maintenance	UIC	Underground Injection Control
PCB	Polychlorinated Biophenyls		
POC	Pollutants of Concern	USACE	United States Army Corporation of Engineers (also CORP or COE)
RV	Recreational Vehicle		CORF of COE)
SC	Source Control	USDA	United States Department of Agriculture
sec	second (or seconds)	USEPA	United States Environmental Protection Agency
SPCC	Spill Prevention Control and		
	Countermeasure	USFWS	United States Fish & Wildlife Services
sq-ft	Square Feet (of feet <sup>2</sup> )		
SSBMP	Site-Specific Best Management Practice Plan	Water Quality Rules	City and County of Honolulu, Rules Relating to Water Quality (or WQR)
State	State of Hawaii	WQF	Water Quality Flow
Strategic Plan	Storm Water Quality Strategic Plan	WQMP	Water Quality Management Plan
SUSMP	Standard Urban Stormwater Mitigation Plan	WQV	Water Quality Volume
SWMPP	Storm Water Management Program Plan		

### Glossary

As used in this document, the following definitions shall apply unless the context indicates otherwise:

**303(d)** Listed: Water bodies listed as impaired as per Section 303(d) of the 1972 Clean Water Act.

**Best Management Practices or BMPs:** means schedules of activities, prohibitions of practices, maintenance procedures, management practices, treatments, and temporary or permanent Structures or devices that are intended and designed to eliminate and Minimize the discharge of pollutants, directly or indirectly, to receiving waters, to the maximum extent practicable.

**Biofiltration:** A pollution control technique that uses living material to capture, and absorb or biologically degrade pollutants.

**Catch Basin (Also known as Inlet):** Box-like underground concrete structure with openings in curbs and gutters designed to collect runoff from streets and pavement.

**Check Dams:** Small temporary dams constructed across a swale or drainage ditch. Check dams reduce the velocity of concentrated storm water flows, thereby reducing erosion of the swale or ditch. The dams also decrease water velocity to increase sediment capture.

Clean Water Act (CWA): (33 U.S.C. 1251 et seq.) Requirements of the NPDES program are defined under Sections 307, 402, 318 and 405 of the CWA.

**Construction Activity:** Includes clearing, grading, excavation, and contractor activities that result in soil disturbance. Construction activities are regulated by the NPDES General Permit Coverage Hawaii Administrative Rules (HAR) Chapter 11-55 Water Pollution Control, Appendix C-Storm Water Associated with Construction Activities, effective October 22, 2007.

**Denuded:** Land stripped of vegetation or land that has had its vegetation worn down due to the impacts from the elements or humans

**Detention:** The capture and subsequent release of storm water runoff from the site at a slower rate than it is collected, the difference being held in temporary storage.

**Development:** The sum of any and all actions that are undertaken to alter the natural or existing condition of real property or improvements on real property if a building, electric, grading, grubbing, plumbing, stockpiling or trenching permit is required for the Project. Development also includes Redevelopment and changes in land use that may result in different or increased Pollutant discharges to the MS4 or Receiving Waters. Development does not include work that does not involve any Land Disturbing Activity, the installation of signs and traffic control devices, the construction of individual bus shelters, the installation of temporary BMPs, emergency work necessary to repair surfaces that are in immediate need of stabilization, the marking of improved surfaces with striping or signage, and minor and ordinary repairs to

existing improvements in the City's right of way, provided that the work will not increase the impervious surface area of the Project Site or involve replacing 50 percent or more of the on-Site impervious surfaces area.

**Discharge:** A release or flow of storm water or other substance from a conveyance system or storage container. Broader discharges includes release to storm drains, etc.

**Disturbed Area:** Any and all portions of Project Site affected by Land Disturbing Activities. Disturbed Areas include, but are not limited to, soils and surface areas affected by excavation, areas that are graded, grubbed, or clearing by uprooting vegetation, areas affected by the demolition of foundations, areas used for equipment staging, materials, or staging, and areas affected by heavy pedestrian or vehicular traffic that disrupts ground covers or surface soil conditions.

**Effluent Limits:** Limitations on amounts of pollutants that may be contained in a discharge. Can be expressed in a number of ways including as a concentration, as a concentration over a time period (i.e., 30-day average must be less than 20 milligram/liter), or as a total mass per time unit, or as a narrative limit.

**Erosion:** The wearing-away of land surface by wind or water. Erosion occurs naturally from weather or runoff but can be intensified by land-clearing practices related to farming, new development, redevelopment, road building, or timber cutting.

**Evapotranspiration:** The combined loss of water into the atmosphere by evaporation (water changing from a liquid to a vapor from soil, water, or plant surfaces) and transpiration (water that is taken up by plant roots and transpired through plant tissue and leaves).

**Facility:** Is a collection of industrial processes discharging storm water associated with industrial activity within the property boundary or operational unit.

**Flood or Flooding:** The inundation to a depth of three inches or more of any property not ordinarily covered by water. The terms do not apply to inundation caused by tsunami wave action.

**Grading:** Any excavation or fill, or combination thereof.

**Hazardous Waste:** A waste or combination of wastes that, because of its quantity, concentration, or physical, chemical or infectious characteristics, may either cause or significantly contribute to an increase in mortality or an increase in serious irreversible illness; or pose a substantial present or potential hazard to human health or the environment when improperly treated, stored, transported, disposed of or otherwise managed. Possesses at least one of four characteristics (ignitability, corrosivity, reactivity, or toxicity) or appears on special USEPA or state lists. Regulated under the federal Resource Conservation and Recovery Act and the California Health and Safety Code.

**Illicit Discharges:** Any discharge to a municipal separate storm sewer that is not in compliance with applicable laws and regulations as discussed in this document.

**Impervious Surface:** A surface covering or pavement of a developed parcel of land that prevents the land's natural ability to absorb and infiltrate rainfall/storm water. Impervious surfaces include, but are not limited to, rooftops; walkways; patios; driveways; parking lots; storage areas; impervious concrete and asphalt; and any other continuous watertight pavement or covering. Landscaped soil and pervious pavement, underlain with pervious soil or pervious storage material, are not impervious surfaces.

xiv

**Industrial General Permit:** A National Pollutant Discharge Elimination System (NPDES) Permit issued by the State of Hawaii Department of Health Clean Water Branch for discharge of storm water associated with industrial activity.

**Industrial Park:** A land development that is set aside for industrial development. Industrial parks are usually located close to transport facilities, especially where more than one transport modalities coincide: highways, railroads, airports, and navigable rivers. It includes office parks, which have offices and light industry.

**Infiltration:** Practices which capture and temporarily store a design storm volume of water before allowing it to infiltrate into the soil.

**Inlet:** An entrance into a ditch, storm drain, or other waterway.

**Integrated Pest Management (IPM):** An ecosystem-based strategy that focuses on long-term prevention of pests or its damage through a combination of techniques such as: biological control, habitat manipulation, modification of cultural practices, and use of resistant varieties. Pesticides are used only after monitoring indicates they are needed according to established guidelines, and treatments are made with the goal of removing only the target organism.

Land Disturbing Activity or Land Disturbance: Any action, activity, or land use that alters the integrity, structure, texture, density, permeability, contents, or stress conditions of soil or ground surfaces if a building, electric, grading, grubbing, plumbing, stockpiling or trenching permit is required for the Project. Land disturbing activities include, but are not limited to actions that result in the turning, penetration, or moving of soil, the resurfacing of pavement that involves the exposure of the base course or subsurface soils, and the use of portions of a Project Site as staging areas or base yards.

Low Impact Development or "LID": Systems and practices that use or mimic natural processes that result in the infiltration, evapotranspiration or use storm water in order to protect water quality and the aquatic habitat. At both site and regional scales, LID aims to preserve, restore, and create green space using soils, vegetation, and rain harvest techniques.

Maximum Extent Practicable or MEP: Economically achievable measures for the control of the addition of pollutants from existing and new categories of nonpoint sources of pollution, which reflect the greatest degree of pollutant reduction achievable through the application of the best available nonpoint source pollution control practices, technologies, processes, siting criteria, operating methods or other alternatives.

Municipal Separate Storm Sewer System (MS4): The City's drainage infrastructure that is designed or intended to collect and convey storm water and includes, but is not limited to, City roads with drainage improvements, City streets, catch basins, curbs, gutters, ditches, man-made channels, and storm drains.

National Pollutant Discharge Elimination System Permit or "NPDES Permit": The permit issued to the City pursuant to *Title 40, Code of Federal Regulations, Part 122*, Subpart B, Section 122.26(a) (1) (iii), for storm water discharge from the City's separate storm sewer systems; or the permit issued to a person or property owner for a storm water discharge associated with industrial activity pursuant to *Title 40, Code of Federal Regulations, Part 122*, Subpart B, Section 122.26(a) (1) (ii), or other applicable section of Part 122; or the permit issued to a person or property owner for the discharge of any pollutant from a point source into the state waters through the City's separate storm sewer system pursuant to Hawaii Administrative Rules, Chapter 11-55, "Water Pollution Control."

**New Development:** Land disturbing activities; structural development, including construction or installation of a building or structure, the creation of impervious surfaces; and land subdivision.

**Non-Storm Water Discharge:** Any discharge to municipal separate storm sewer that is not composed entirely of storm water.

**Nonpoint Source Pollution:** Pollution that does not come from a point source. Nonpoint source pollution originates from aerial diffuse sources that are mostly related to land use.

**Notice of Intent (NOI):** A formal notice to the State of Hawaii Clean Water Branch submitted by the owner of an industrial site or construction site that said owner seeks coverage under a General Permit for discharges associated with industrial and construction activities. The NOI provides information on the owner, location, type of project, and certifies that the owner will comply with the conditions of the construction General Permit.

**Notice of Cessation (NOC):** Formal notice to the State of Hawaii Clean Water Branch submitted by owner/developer that a construction project is complete.

**Outfall:** The end point where storm drains discharge water into a waterway.

**Point Source:** Any discernible, confined, and discrete conveyance from which pollutants are or may be discharged. This term does not include return flows from irrigated agriculture or agricultural storm water runoff.

**Pollutant:** Any dredge, spoil, solid refuse, incinerator residue, sewage, garbage, sewage sludge, munitions, chemical waste, biological materials, radioactive materials, heat, wrecked or dismantled equipment, rock, sand, soil, sediment, dirt, industrial, municipal, or agricultural waste and substances of similar nature.

**Pollution Prevention:** Practices and actions that reduce or eliminate the generation of pollutants.

**Precipitation:** Any form of rain.

**Pretreatment:** Treatment of waste stream before it is discharged to a collection system.

**Reclaim (Water Reclamation):** Planned use of treated effluent that would otherwise be discharged without being put to direct use.

**Redevelopment:** The creation, addition, and/or replacement of impervious surface on improved real property. Redevelopment does not include trenching and resurfacing associated with utility work, resurfacing and reconfiguring existing impervious surfaces, the repair of sidewalks or pedestrian ramps, pothole repair, ordinary road maintenance, or the marking of vehicular or pedestrian lanes on existing roads.

**Retail Mall:** One or more buildings that house or form a complex of retail stores with interconnecting walkways. Retail and Commercial malls include, but are not limited to, mini-malls, strip malls, retail complexes, and enclosed shopping malls or shopping centers.

**Retention:** The storage of storm water to prevent it from leaving the development site.

Reuse (Water Reuse): (see Reclaim)

**Runoff:** Water originating from rainfall and other sources (i.e., sprinkler irrigation) that flows over the land surface to drainage facilities, rivers, streams, springs, seeps, ponds, lakes, and wetlands.

Run-on: Offsite storm water surface flow or other surface flow which enters your site.

**Scour:** The erosive and digging action in a watercourse caused by flowing water.

**Secondary Containment:** Structures, usually dikes or berms, surrounding tanks or other storage containers, designed to catch spilled materials from the storage containers.

**Sedimentation:** The process of depositing soil particles, clays, sands, or other sediments that were picked up by runoff.

**Sediments:** Soil, sand, and minerals washed from land into water, usually after rain, that collect in reservoirs, rivers, and harbors, destroying fish nesting areas and clouding the water, thus preventing sunlight from reaching aquatic plants. Farming, mining, and building activities without proper implementation of BMPs will expose sediment materials, allowing them to be washed off the land after rainfalls.

**Self-Mitigating Area:** A natural or landscaped area, including green roofs, which retains and/or treats rainfall within its perimeter without accepting runoff from other areas. Self-Mitigating Areas must retain all collected storm water or drain directly to the MS4.

**Significant Materials:** Includes, but not limited to, raw materials; fuels; materials such as solvents, detergents, and plastic pellets; finished materials such as metallic products; raw materials used in food processing or production; hazardous substances designed under Section 10 1(14) of CERLCA; any chemical the facility is required to report pursuant to Section 313 of Title III of SARA; fertilizers; pesticides; and waste products such as ashes, slag, and sludge that have the potential to be released with storm water discharges.

**Significant Quantities:** The volume, concentrations, or mass of a pollutant in storm water discharge that can cause or threaten to cause pollution, contamination, or nuisance that adversely impact human health or the environment and cause or contribute to a violation of any applicable water quality standards for receiving water.

**Site Design Strategies:** LID design techniques that are intended to maintain or restore the site's hydrologic and hydraulic functions with the intent of minimizing runoff volume and preserving existing flow paths.

**Source Control BMPs:** Low-technology practices designed to prevent pollutants from contacting storm water runoff or to prevent discharge of contaminated runoff to the storm drainage system.

**Source Reduction (also Source Control):** The technique of stopping and/or reducing pollutants at their point of generation so that they do not come into contact with storm water.

**Storm Drains:** Above- and below-ground structures for transporting storm water to streams or outfalls for flood control purposes.

**Storm Water:** Storm water runoff, surface runoff, street wash, or drainage and may include discharges from fire fighting activities.

**Storm Water Discharge Associated with Industrial Activity:** Discharge from any conveyance which is used for collecting and conveying storm water from an area that is directly related to manufacturing, processing, or raw materials storage activities at an industrial plant.

**Storm Water Hotspots:** Storm water hotspots are areas where land use or activities generate highly contaminated runoff, with concentrations of pollutants exceeding those typically found in storm water.

**Storm Water Pollution Control Plan (SWPCP):** A written plan that documents the series of phases and activities that, first, characterizes your site, and then prompts you to select and carry out actions which prevent the pollution of storm water discharges. For construction activities NOI, the Department of Health Clean Water Branch has renamed SWPCP to site-specific BMPs plan.

**Storm Water Retrofit:** A storm water retrofit is a storm water management practice (usually structural) put into place after development has occurred, to improve water quality, protect downstream channels, reduce flooding, or meet other specific objectives.

**Treatment Control BMPs:** Engineered technologies designed to remove pollutants from storm water runoff prior to discharge to the storm drain system or receiving waters.


**Toxicity:** Adverse responses of organisms to chemicals or physical agents ranging from mortality to physiological responses such as impaired reproduction or growth anomalies.

xviii

## Acknowledgements

The Storm Water Best Management Practice (BMP) Manuals are adaptations of products of the California Stormwater Quality Association (CASQA) and other municipalities and guidance documents.

The development of the City Storm Water BMP Guide was guided by Technical Contributions from representatives of regulatory agencies (water quality and health), industry, transportation, and consulting. The quality of this manual is a result of the diverse expertise and experience of the committee and the workgroup.



#### 1. Introduction

Storm water runoff is part of a natural hydrologic process. However, human activities particularly urbanization and agriculture, can alter natural drainage patterns and add pollutants to lakes, and streams as well as coastal bays and estuaries, and ultimately, the ocean. Numerous studies have shown urban runoff to be a significant source of water pollution, causing declines in fisheries, restrictions on swimming, and limiting our ability to enjoy many of the other benefits that water resources provide. Urban runoff in this context includes all flows discharged from urban land uses into storm water conveyance systems and receiving waters and includes both dry weather non-storm water sources (i.e., runoff from landscape irrigation, etc.) and wet weather storm water runoff. In this manual, urban runoff and storm water runoff are used interchangeably.

For many years the effort to control the discharge of storm water focused on quantity (i.e., drainage and flood control) and only to a limited extent on quality of the storm water (i.e., sediment and erosion control). However, in recent years awareness of the need to improve water quality has increased. With this awareness, Federal, State, and City programs have been established to pursue the ultimate goal of reducing pollutants contained in storm water discharges to our waterways. The emphasis of these programs is to promote the concept and the practice of preventing pollution at the source, before it can cause environmental problems (United States Environmental Protection Agency [USEPA], 1992). Other BMPs to reduce or eliminate post-project runoff should also be implemented. However, where further controls are needed, treatment of polluted runoff may be required.

#### 1.1. Purpose and Scope

The City and County Rules Relating to Water Quality (*Water Quality Rules* or WQR) specifies that regulated new development and redevelopment projects include Low Impact Development (LID) Site Design Strategies, Source Control BMPs (best management practices), and Post-Construction Treatment Control BMPs to reduce the pollution associated with storm water runoff. This document provides planning and design guidelines to support implementation of the *Water Quality Rules*. Presented in this manual are the minimum design and technical criteria for the analysis and design of storm drainage facilities and water quality. This document also provides guidance for storm water quality during the planning phase and Operations and Maintenance (O&M) guidance. Implementing structural and operational controls that go beyond the minimum is encouraged.

#### 1.2. Users of the Manual

This manual provides guidance suitable for use by individuals involved in development or redevelopment site water pollution control and planning. Each user of the manual is responsible for working within their capabilities obtained through training and experience, and for seeking the advice and consultation of appropriate experts at all times.

The target audience for this manual includes:

- Developers (including their planners and engineers);
- Contractors and subcontractors (including their engineers, superintendents, foremen, and construction staff);
- City agencies involved in site development and redevelopment (including their engineers, planners, and construction staff);
- Regulatory agencies (including permit and planning staff); and
- General public with an interest in storm water pollution control.

This manual also references the necessary forms and worksheets that developers, designers, consultants, contractors, and other applicants need to complete and have approved by the City and County of Honolulu (City or CCH).

#### 1.3. Organization of the Manual

The manual is organized to assist the user in selecting and implementing BMPs to reduce impacts of storm water and non-storm water discharges on receiving waters. Sections of this manual are displayed in **Figure 1.1**.

#### 1.4. Low Impact Development and Storm Water Quality

When rain falls in natural, undeveloped areas, the water is absorbed and filtered by soil and plants. However, for the past decades, typical urban development and storm drain systems have been designed using impermeable materials to convey storm water away from developed areas as quickly and efficiently as possible. Excess rainfall, or the portion of rainfall that is not abstracted by interception, infiltration, or depression storage, becomes surface runoff. Large areas of connected impervious cover and changes in land use often found in urban environments dramatically increase the volume and rate of storm water discharges.

Under natural and undeveloped conditions, surface runoff can range from 10 to 30 percent (%) of the total annual precipitation (**Figure 1.2**). Depending on the level of development and the site planning methods used, the alteration of physical conditions can result in a significant increase of surface runoff to over 50% of the overall precipitation. Alteration in site runoff characteristics can cause an increase in the volume and frequency of runoff flows (discharge) and velocities that cause flooding, accelerated erosion, and reduced groundwater recharge and contribute to degradation of water quality and the ecological integrity of streams.

Additionally, storm water runoff naturally contains numerous constituents, however, urbanization and urban activities including development and redevelopment typically increase constituent concentrations to levels that impact water quality. Urban activities can also result in the generation of new dry-weather runoff that may contain many of the pollutants listed in **Table 1.1**.

Pollutants associated with storm water include sediment, nutrients, bacteria and viruses, oil and grease, metals, organics, pesticides, and trash (floatables). In addition, nutrient-rich storm water runoff is an attractive medium for vector production when it accumulates and stands for more than 72 hours (hrs).

1-2

#### **Section 1: Introduction**

This section provides a general review of the Regulatory Background and an overview of LID.

## Section 2: Application of Permanent BMP Requirements in the City and County of Honolulu

• This section provides an overview of the requirements for New and Redevelopment projects to comply with the City and County of Honolulu, Department of Planning and Permitting's, "Rules Relating to Water Quality."

#### Section 3: Storm Water Quality Planning for New Development and Redevelopment

• This section describes planning principles for New and Redevelopment projects including site assessment, site design strategies, and source control design.

#### **Section 4: Site and Facility Design for Water Quality Protection**

• This section describes how infiltration BMPs, retention/detention basins, biofilters, and structural controls can be incorporated into common site features.

#### **Section 5: Treatment Control BMP Design**

• This section describes BMP selection, feasibility criteria, numerical sizing criteria, and infiltration testing for the design of Treatment Control BMPs.

#### **Section 6: Considerations for Construction Treatment Control BMPs**

 This section outlines construction sequencing and considerations to protect permanent BMPs during construction.

#### **Section 7: Operations and Maintenance of BMPs**

• This section provides guidance for the operation and maintenance of BMPs to ensure BMP effectiveness.

#### **Section 8: References**

This section provides a list of reference documents.

Figure 1.1: Document Organization

LID reduces peak runoff and improves water quality by allowing rainwater to infiltrate into the ground, allowing rainwater to evaporate and transpire, or collecting rainwater as a resource for irrigation and other methods of reuse. Rather than moving storm water off-site through a conveyance system, the goal of LID is to restore the natural ability of a developed site to absorb storm water, resulting in an area more closely resembling pre-development hydrology. Importantly, the LID strategy seeks to control storm water quality at its source, using a range of small-scale, economical devices such as native landscaping and constructed green spaces, bioretention facilities, vegetated swales, infiltration through permeable pavement, and green roofs.




Figure 1.2: Impacts of Urbanization

**Table 1.1: Pollutants and Impacts on Water Quality** 

Pollutant	Impact
Sediment	Sediment is a common component of storm water, and can be a pollutant. Sediment can be detrimental to aquatic life (primary producers, benthic invertebrates, coral reefs and fish) by interfering with photosynthesis, respiration, growth, reproduction, and oxygen exchange in water bodies. Sediment can transport other pollutants that are attached to it including nutrients, trace metals, and hydrocarbons. Sediment is the primary component of total suspended solids (TSS), a common water quality analytical parameter.
Nutrients	Nutrients including nitrogen and phosphorous are the major plant nutrients used for fertilizing landscapes, and are often found in storm water. These nutrients can result in excessive or accelerated growth of vegetation, such as algae, resulting in impaired use of water in lakes and other sources of water supply.
Bacteria and Viruses	Bacteria and viruses are common contaminants of storm water. For separate storm drain systems, sources of these contaminants include animal excrement and sanitary sewer overflow. High levels of indicator bacteria in storm water have led to the closure of beaches, lakes, and streams to contact recreation such as swimming.
Oil and Grease	Oil and grease includes a wide array of hydrocarbon compounds, some of which are toxic to aquatic organisms at low concentrations. Sources of oil and grease include leakage, spills, cleaning and sloughing associated with vehicle and equipment engines and suspensions, leaking and breaks in hydraulic systems, restaurants, and waste oil disposal.
Metals	Metals including lead, zinc, cadmium, copper, chromium, and nickel are commonly found in storm water. Many of the artificial surfaces of the urban environment (i.e., galvanized metal, paint, automobiles, or preserved wood) contain metals, which enter storm water as the surfaces corrode, flake, dissolve, decay, or leach. Over half the trace metal load carried in storm water is associated with sediments. Metals are of concern because they are toxic to aquatic organisms, can bioaccumulate (accumulate to toxic levels in aquatic animals such as fish), and have the potential to contaminate drinking water supplies.
Organics	Organics may be found in storm water in low concentrations. Often synthetic organic compounds (adhesives, cleaners, sealants, solvents, etc.) are widely applied and may be improperly stored and disposed. In addition, deliberate dumping of these chemicals into storm drains and inlets causes environmental harm to waterways.
Pesticides	Pesticides (including herbicides, fungicides, rodenticides, and insecticides) have been repeatedly detected in storm water at toxic levels, even when pesticides have been applied in accordance with label instructions. As pesticide use has increased, so too have concerns about adverse effects of pesticides on the environment and human health. Accumulation of these compounds in simple aquatic organisms, such as plankton, provides an avenue for biomagnification through the food web, potentially resulting in elevated levels of toxins in organisms that feed on them, such as fish and birds.
Gross Pollutants	Gross Pollutants (trash, debris, and floatables) may include heavy metals, pesticides, and bacteria in storm water. Typically resulting from an urban environment, industrial sites and construction sites, trash and floatables may create an aesthetic "eye sore" in waterways. Gross pollutants also include plant debris (such as leaves and lawn-clippings from landscape maintenance), animal excrement, street litter, and other organic matter. Such substances may harbor bacteria, viruses, vectors, and depress the dissolved oxygen levels in streams, lakes, and estuaries sometimes causing fish kills.

### 1.5. Regulatory Requirements

The Federal Water Pollution Control Act of 1972 also known as the Clean Water Act (CWA), as amended in 1987, is the principal legislation for establishing requirements for the control of storm water pollutants from urbanization and related activities. However, other Federal, State, and City requirements deal directly or indirectly with controlling storm water discharges. Requirements for storm water under some of these programs are evolving: Coastal Zone Management Act (CZMA), State of Hawaii Administrative Rules (HAR), City Ordinances, Total Maximum Daily Loads (TMDLs), 401 Water Quality Certifications and Endangered Species Act. The user is advised to contact local regulatory and/or City officials for further information.

### 1.5.1. Federal Programs

In 1972, provisions of the CWA were amended so that discharge of pollutants to waters of the United States from any point source is effectively prohibited, unless the discharge is in compliance with a National Pollutant Discharge Elimination System (NPDES) permit. The 1987 amendments to the CWA added Section 402(p), which established a framework for regulating municipal, industrial, and construction storm water discharges under the NPDES program. On November 16, 1990, USEPA published final regulations that established application requirements for storm water permits for municipal separate storm sewer systems (MS4s) serving a population of over 100,000 (Phase I communities) and certain industrial facilities, including construction sites greater than five (5) acres.

On December 8, 1999, USEPA published the final regulations for communities under 100,000 (Phase II MS4s) and operators of construction sites between one (1) and five (5) acres.

### 1.5.2. State Programs

The statutory framework for the NPDES program requires that all point sources that discharge pollutants in the waters of the United States must obtain an NPDES permit from the USEPA or an authorized State (Hawaii is a delegated state). Storm water is regulated under the NPDES program. There has been a phased approach to regulation of storm water. Phase I, in 1990, regulated discharges from Medium and Large MS4s, industrial activity, and construction sites greater than or equal to five (5) acres. Phase II became effective March 10, 2003 and regulated discharges from Small MS4s and construction sites from one (1) acre to five (5) acres. Large, Medium, and Small MS4s were defined by the size of the population that the system serves. The regulations required the issuance of permits to regulated dischargers.

In Hawaii, Small MS4s, industrial facilities, and construction activities greater than or equal to one acre are normally covered by general permits. However if such facilities discharge storm water into sensitive water bodies designated as Class AA marine, or Class 1 inland State waters, or areas restricted in accordance with the State's "No Discharge" policy, then those facilities must be covered by an individual permit. Also, Small MS4s and industrial facilities could be covered under an individual permit issued to a Large MS4.

Regulatory emphasis is placed on pollution prevention by regulating "end of pipe" discharges in lieu of setting effluent limits. Prevention is accomplished through the development and implementation of plans such as the MS4 Storm Water Management Program Plan (SWMPP), Industrial Storm Water Pollution Control Plans (SWPCPs), and erosion control plans and Site-Specific BMP Plans (SSBMPs) for construction sites.

Projects designated by the City as "Priority Projects" have been identified to have a greater potential for activities which may contribute sources for pollutants. These projects, described in Section 2, have been developed to reduce the risk of pollutant sources exposure to storm water runoff.

### 1.5.3. Other Relevant Regulatory Programs

In addition to meeting City storm water program requirements under CWA section 402(p), municipalities are increasingly subject to other regulatory drivers that relate to the protection of surface water quality and beneficial uses of water bodies in their communities. Several other regulatory programs that can significantly affect new development and redevelopment planning and design are:

- TMDLs
- Endangered Species Act
- CWA Section 404 Dredge and Fill Permits
- Section 401 Water Quality Certification (regulated under HAR, Chapter 11-54)

In the coming years, these regulatory drivers will likely have at least as much impact on the design and implementation of municipal storm water programs and BMP selection and maintenance as current storm water regulations.

### 1.5.4. Total Maximum Daily Loads

TMDLs are a regulatory mechanism to identify and implement additional controls on both point and non-point source discharges in water bodies that are impaired from one or more pollutants and are not expected to be restored through normal point source controls. States identify impairments and pollutants by putting impaired water bodies on a list as required under Section 303(d) of the CWA.

Storm water or urban runoff is listed as a suspected source for many of the water body pollutant combinations in the current 303(d) list. Storm water programs must be designed not only to be in compliance with the storm water NPDES permit regulations, but they must also be designed to implement TMDLs in which storm water or urban runoff is named as a source.

### 1.5.5. Endangered Species Act

Like TMDLs, Endangered Species Act (Hawaii Revised Statutes Title 12) issues are becoming increasingly important to storm water program design and implementation. The presence or potential presence of an endangered species impacts storm water management programs and the selection and maintenance of BMPs. The Department of Land and Natural Resources (DLNR) Division of Forestry and Wildlife (DOFAW) and the US Fish & Wildlife Service (USFWS) provides information on the designation of critical habitat in Hawaii.

The developers or public agency intending to conduct activities in or discharge to an area that serves as a critical habitat must contact resource agencies such as DLNR, DOFAW, and the USFWS to learn about specific compliance requirements and actions.

### 1.5.6. Clean Water Act Section 404 Dredge and Fill Permits

Storm Water BMP Guide for New and Redevelopment

In 1972, Section 404 of the CWA was passed prohibiting the discharge of dredged or filled material into U.S. waters without a permit from the Army Corps of Engineers (USACE or CORP or COE). Subsequent

Revised: July 2017

court rulings and litigation further defined "Waters of the U.S." to include virtually all surface waters, including wetlands. Activities in waters of the United States that are regulated under this Act include fills for development, water resource projects (such as dams and levees), infrastructure development (such as highways and airports), and conversion of wetlands to uplands for farming and forestry.

The basic premise of the CWA is that no discharge of dredged or fill material is permitted if a practicable alternative exists that is less damaging to the aquatic environment or if the nation's waters would be significantly degraded. When applying for a permit, it must be shown that:

- Steps have been taken to avoid wetland impacts where practicable.
- Potential impacts to wetlands have been minimized.
- Compensation for any remaining, unavoidable impacts through activities has been provided to restore or create wetlands.

An individual permit is usually required for potentially significant impacts. However, for most discharges that will have only minimal adverse effects, the USACE often grants up-front general permits. These may be issued on a nationwide or state basis for particular categories of activities (for example, minor road crossings, utility line backfill, and bedding) as a means to expedite the permitting process.

### 1.5.7. Clean Water Act Section 401 Water Quality Certification

Anyone proposing to conduct a project that requires a Federal permit (404) or involves dredge or fill activities that may result in a discharge to U.S. surface waters and/or "Waters of the State" is required to obtain a CWA Section 401 Water Quality Certification and/or Waste Discharge Requirements (Dredge/Fill Projects) from the State of Hawaii (State) Department of Health (DOH) Clean Water Branch (CWB), verifying that the project activities will comply with state water quality standards (HAR Chapter 11-54). The rules and regulations apply to all "Waters of the State," including isolated wetlands and stream channels that may be dry during much of the year, have been modified in the past, look like a depression or drainage ditch, have no riparian corridor, or are on private land.

Section 401 of the CWA grants each state the right to ensure that the state's interests are protected on any federally permitted activity occurring in or adjacent to "Waters of the State." In Hawaii, the CWB is the agency mandated to ensure protection of the State's waters. If a proposed project requires a USACE, CWA Section 404 permit and has the potential to impact Waters of the State, the CWB through HAR Chapter 11-54 will regulate the project and associated activities through a Water Quality Certification determination (Section 401), as part of the 404 process.

# 2. Application of Permanent BMP Requirements in the City and County of Honolulu

According the *Water Quality Rules*, the following projects are required to implement post-construction BMPs for water quality:

### **Priority A**

 All new development and redevelopment, including any incremental development, that proposes land disturbing activities of 1 acre or more.

### **Priority B**

- Any project that may have significant water quality impacts due to its location or associated land use activities, including but not limited to the development or redevelopment of:
  - Retail gas outlets
  - Automotive repair shops
  - Restaurants
  - Parking lots with 20 stalls or more
  - Buildings greater than 100 feet in height
  - Retail malls
  - Industrial park

Priority B is further divided into Priority B1 and Priority B2. Priority B1 is any Priority Project with 5,000 square feet (sq-ft) or greater of impervious area. Priority B2 is any Priority Project with less than 5,000 sq-ft of Impervious Area.

The Water Quality Rules criteria must be met for Priority A, B1, and B2 projects as follows:

- 1. Incorporate appropriate LID Site Design Strategies to the maximum extent practicable (MEP).
- 2. Incorporate appropriate Source Control BMPs to the MEP.

In addition, the following criteria must be met for Priority A and B1 projects as follows:

- 1. Retain on-site by infiltration, evapotranspiration or harvest/reuse, as much of the Water Quality Volume (WQV) as feasible, with appropriate LID Retention Post-Construction Treatment Control BMPs.
- 2. Biofilter the remaining portion of the WQV that is not retained on-site with appropriate LID Biofiltration Post-Construction Treatment Control BMPs as much as feasible.
- 3. If it is demonstrated to be infeasible to retain and/or biofilter the WQV, one of the following alternative compliance measures is required:
  - a. Treat (by detention, filtration, settling, or vortex separation) and discharge with appropriate Alternative Compliance Post-Construction Treatment Control BMPs, any portion of the WQV that is not retained on-site or biofiltered.
  - a. Retain or biofilter at an offsite location, the volume of runoff equivalent to the difference between the project's WQV and the amount retained on-site or biofiltered. Offsite mitigation projects must be submitted for City approval.

A flowchart of implementation of the CCH Water Quality Rules is shown in Figure 2.1.

Site Design, Source Control, and Treatment Control BMPs are discussed throughout this document. **Table 2.1** summarizes the requirements of the *Water Quality Rules* and objectives of each requirement.




Figure 2.1: Implementation of the CCH Water Quality Rules

Table 2.1: Summary of Post-Construction Requirements for New and Redevelopment

BMP Category		Applicable Projects	Pollution Prevention Objective	
LID Site Design		Required for all Priority projects; recommended for all others. See Section 3.2.	Strategies integrated into the facility design to maintain or restore the natural hydrologic functions of a site to reduce the rate of runoff, filter out its pollutants, and facilitate the infiltration of water into the ground.	
Source Con	trol	Required for all Priority projects; recommended for all others. See Source Control BMPs in Section 3.3 and <b>Appendix A</b> .	Low-technology practices designed to prevent pollutants from contacting storm water runoff or to prevent discharge of contaminated runoff to the storm drainage system.	
	LID Retention	Required for Priority A and B1 projects if feasible; recommended for all others if feasible. See Treatment Control BMPs in Section 5 and Appendix B.	Engineered technologies designed to retain runoff on-site by infiltration, evapotranspiration, or reuse.	
Treatment Control	LID Biofiltration	Required for Priority A and B1 projects if LID Retention is infeasible; recommended for all others if feasible. See Treatment Control BMPs in Section 5 and <b>Appendix B</b> .	Engineered technologies designed to remove pollutants from runoff by filtration, adsorption, and biological uptake.	
	Alternative Compliance BMPs	Required for Priority A and B1 projects when retention and biofiltration are infeasible. See Treatment Control BMPs in Section 5 and Appendix B.	Engineered technologies designed to remove pollutants from runoff by detention, filtration, settling, or vortex separation.	

### 2.1. City and County of Honolulu Plan Review Requirements

The City's Water Quality Rules requires several documents to be prepared and submitted prior to permit issuance.

### 2.1.1. Storm Water Quality Strategic Plans

Storm Water Quality Strategic Plans (Strategic Plans) should be submitted with or within the Master Development Plan. This requirement ensures that project developers, planners, and designers are considering storm water management early in the planning process. The Strategic Plan must include a written description of the proposed development, expected activities and pollutants that will be generated by activities at the site, and LID site design strategies that will be used to comply with the *Water Quality Rules*. The Strategic Plan must also include a development schedule.

### 2.1.2. Storm Water Quality Reports

An effective mechanism for documenting the incorporation of storm water quality controls into new development and redevelopment projects on a site or watershed basis is to develop a written plan known as a Storm Water Quality Report (SWQR). An effective SWQR clearly sets forth the means and methods

for long-term storm water quality protection. The SWQR will also prove to be useful during ownership transitions to convey critical storm water quality control information to subsequent owners.

SWQRs must be submitted with either a building permit application or, for projects which require a grading, grubbing, stockpiling or trenching permit, the SWQR must be submitted with construction plans for review. SWQRs must be prepared by a Certified Water Pollution Plan Preparer (CWPPP). A CWPPP must be an Architect, Engineer, Land Surveyor, or Landscape Architect licensed in the State of Hawaii. Certification can be obtained from the DPP by the successful completion of an on-line training and test.

A template is provided by the City on the Department of Planning and Permitting (DPP) website. SWQRs must contain the following information:

- 1. Project Name;
- 2. Master Plan Development Name;
- 3. Project Address;
- 4. Project Size (acres);
- 5. Tax Map Key;
- 6. The name, address, and telephone number of the owner(s)/developers of the property;
- 7. A description of site characteristics including drainage patterns, soils, vegetation, and steep or unstable slopes that may be of concern;
- 8. A description of the future activities at the site including those that would require Source Control BMPs
- 9. A description of the pollutants of concern (POC) expected to be generated at the site; and
- 10. A description of the BMPs that will be implemented including Site Design and Self-mitigating Areas, Source Control, Retention, Biofiltration, and Alternative Compliance and which POCs are addressed by those BMPs.

The following reports and plans should be included as attachments as applicable.

- 1. Location Map and Site Plans;
- 2. Existing and Proposed Drainage Plans;
- 3. Permanent BMP Plan including locations of all Source Control and Treatment Control BMPs and a clear and definite delineation of areas covered by vegetation or trees that will be saved;
- 4. Treatment Control BMP Sizing Spreadsheets;
- 5. Infiltration Testing Results/Geotechnical Reports;
- 6. Operation and Maintenance Plan;
- 7. Proprietary Treatment Device Information; and/or
- 8. Evidence or explanation for any infeasibility criteria claimed in order to comply with the requirements for infiltration, harvest/reuse, and biofiltration. Infeasibility criteria is discussed more in Section 5.5 and must be documented on the form provided by DPP which can be accessed on their website.

### 2.1.3. Storm Water Quality Checklists

Storm Water Quality Checklists (SWQCs) are required for Priority B2 Projects. An SWQC is similar to an SWQR but requires less information. A template is provided by on the DPP website.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017 SWQCs must contain the following information:

- 1. Project Name;
- 2. Master Plan Development Name;
- 3. Project Address;
- 4. Project Size (acres of square feet);
- 5. Impervious Area; ;
- 6. Tax Map Key
- 7. The name, address, and telephone number of the owner(s)/developers of the property;
- 8. BMPs that will be implemented including Site Design Strategies, Self Mitigating Areas, and Source Control BMPs.

The following reports and plans shall be included as attachments:

- 1. Permanent BMP Plan including locations of all Site Design Strategies, Source Control BMPs and vegetated or landscaped areas; and
- 2. Operations and Maintenance Plan.

### 2.1.4. Operations and Maintenance Plan

The Water Quality Rules require new development and redevelopment projects that implement Source Control and Treatment Control BMPs to regularly inspect and maintain installed BMPs to ensure they operate as designed. Permanent BMPs are also subject to annual inspections by the City's Department of Facility Maintenance (DFM). The owner/developer is required to keep records of inspection and maintenance activities for a minimum of five (5) years and be made available to the City upon request.

The owner of the property on which a permanent structural BMP is located must submit a BMP maintenance plan with the SWQR for all permanent structural BMPs. Modifications to the O&M Plan after DPP acceptance are permitted before closing applicable building and/or grading, grubbing, stockpiling, or trenching permits.

A template has been provided by the City and is available on the DPP website. O&M Plans shall include:

- 1. Name, phone number, and mailing address for the owner of the property.
- 2. Name and phone number for the individual(s), association, or management company responsible ensuring maintenance is being performed.
- 3. Maintenance activities for each BMP.
- 4. Inspection frequencies for each BMP.
- 5. A post-construction BMP plan showing the location of each BMP with a summary of the maintenance activities and inspection schedule for each BMP.

### 2.1.5. BMP Certification and Recording

Approved post-construction record drawings and the accepted O&M Plan must be recorded with the drainage connection permit in the deed for the real property on which the permanent BMP will be located. One copy of the drainage connection permit and recorded O&M Plan shall be submitted to the Director of DFM prior to closing the building and/or grading, grubbing, stockpiling, or trenching permits.

Revised: July 2017

A CWPPP shall inspect to confirm that the permanent post-construction BMPs have been installed in conformance with the approved construction plans and submit the signed Certificate of Completion form prior to closing the building and/or grading permits. The certification of completion form is available on the DPP website.

### 2.1.6. Variances

Whenever there are practical difficulties involved in carrying out the LID Regulations, the DPP Director has the authority to grant modifications to the provisions for individual cases. These must be filed for individually and the applicant must demonstrate that the situation is unique, not caused by their own actions, and will not result in unreasonable threat of Pollutant Discharges to the MS4 or State Waters.

## 3. Storm Water Quality Planning for New Development and Redevelopment

The City's program requires BMPs to be implemented by developers, property owners, and public agencies engaged in new development or redevelopment activities. Understanding new development and redevelopment in the context of the project life cycle is important for proper selection and implementation of BMPs as shown in **Figure 3.1**. The concept, planning, and design phases of a project may be spread over a period of months to many years. BMPs incorporated into the concept, planning, and design phase are much more cost-effective than the retrofit of developed projects with BMPs.




Figure 3.1: Project Life Cycle

Planning for storm water quality protection employs a multi-level strategy. To comply with the *Water Quality Rules*, the strategy consists of: 1) Site design strategies to reduce or eliminate post-project runoff; 2) Controlling sources of pollutants; and 3) Treating the remaining storm water runoff before discharging it to the storm drain system or to receiving waters.

This section describes how Elements 1 and 2 of the strategy can be incorporated into the site and facility planning and design process, and by doing so, eliminating or reducing the amount of storm water runoff that may require treatment at the point where storm water runoff ultimately leaves the site. It also describes considerations when selecting treatment to achieve Element 3.

**Element 1** is referred to as a "site design strategy" because it utilizes strategies during site design to reduce or eliminate runoff

**Element 2** may be referred to as "source controls" because they emphasize reducing or eliminating pollutants in storm water runoff at their source through runoff reduction and by keeping pollutants and storm water segregated.

**Element 3** of the strategy is referred to as "treatment control" because it utilizes treatment mechanisms to remove pollutants that have entered storm water runoff. Treatment controls integrated into and throughout the site usually provide enhanced benefits over the same or similar controls deployed only at the "end of the pipe" where runoff leaves the project site.

These principles are consistent with the permit and the program requirements for Priority Projects that require a combination of site design, source control BMPs (that reduce or eliminate runoff and control pollutant sources) and treatment control BMPs with specific quantitative standards. The extent to which projects can incorporate site design strategies that reduce or eliminate post project runoff will depend upon the land use and local site characteristics of each project. Reduction in post project runoff offers a direct benefit by reducing the required size of treatment controls to meet the numeric standard included in the *Water Quality Rules*. Therefore, project developers can evaluate tradeoffs between the incorporation of alternative site design and source control techniques that reduce runoff and pollutants, and the size of required treatment controls.

### 3.1. Assess Site Conditions

Site and watershed assessment includes assessing and describing the pre- and post-development site conditions and how the site fits into the overall watershed or drainage area. The assessment should include sufficient detail to allow for assessment of the need for and application of storm water BMPs. Information typically required is listed below and can be refined during the detailed design process.

### **Site Information:**

- Historic features
- Existing features and vegetation
- Planned features and activities
- Topography and drainage patterns
- Discharge locations
- Soil types
- Subsurface hydrology characterization
- General climate including average precipitation and microclimates including areas of full or partial shade
- Setbacks and buffer requirements

### **Vicinity Information:**

- Major roadways
- Geographic features or landmarks
- Area surrounding the site
- General topography
- Area drainage

### Watershed or Drainage Area Information:

- Receiving waters
- Watershed drainage
- Depth to groundwater

### 3.1.1. Understand Hydrologic Conditions of Concern

Development of impervious areas changes the landform and therefore the runoff hydrograph. Modifications to the runoff hydrograph change downstream hydrology. New development typically results in more runoff volume and higher rates of runoff. Many BMPs, such as detention basins, which

Storm Water BMP Guide for New and Redevelopment Revised: July 2017 detain volume, effectively remove the top part of the hydrograph, but extend the duration of flow. See **Figure 3.2**.

Recent findings indicate that while such actions mitigate peak flows, the increased duration associated with these actions has impacts as well. Problems include washing out habitat, eroding streambed and banks, and changing downstream ecosystems. In addition to volume, rate, and duration, other factors such as the amount of energy in the water and peak flow impact downstream conditions.

A comprehensive understanding of these factors is necessary to develop meaningful storm water management plans. To be effective, these solutions must be done on an individual watershed basis.

Ideally, the runoff hydrograph that exists after construction would parallel the pre-construction hydrograph. It is difficult to ask upstream developers to be concerned about what is happening several miles below them in a watershed. On the other hand, storm water planners and policy makers must ask what can be done to make the watershed more stable, and what enhancements are needed to balance impacts to the watershed from development. Storm water quality planning for new development and redevelopment can be used to make qualitative predictions concerning channel impacts due to changes in runoff or sediment loads from the watershed.

The best way to resolve the watershed stability and balance issues is through a comprehensive drainage water master plan. A formal drainage study considers the project area's location in the larger watershed, topography, soil and vegetation conditions, percent impervious area, natural and infrastructure drainage features, and any other relevant hydrologic and environmental factors. A drainage study is typically prepared by a licensed civil engineer. As part of the study, the drainage report includes:

- Field reconnaissance to observe downstream conditions.
- Computed rainfall and runoff characteristics including a minimum of peak flow rate, flow velocity, runoff volume, time of concentration and retention volume.
- Establishment of site design, source control and treatment control measures to be incorporated and maintained to address downstream conditions of concern.




Figure 3.2: Hydraulic Altercation after Certain BMPs are Implemented

### 3.2. Site Design Strategies

The goal of LID Site Design is to reduce the hydrologic impact of development and to incorporate techniques that maintain or restore the site's hydrologic and hydraulic functions. The optimal LID site design minimizes runoff volume and preserves existing flow paths.

The City requires five (5) Site Design strategies:

- 1. Conserve natural areas, soils, and vegetation.
- 2. Minimize disturbances to natural drainages.
- 3. Minimize soil compaction.
- 4. Direct runoff to landscaped areas and reduce directly connected impervious areas (DCIA).
- 5. Minimize impervious surfaces.

### 3.2.1. Conserve Natural Areas, Soils, and Vegetation

The conservation of natural areas, soils, and vegetation helps to retain numerous functions of predevelopment hydrology, including rainfall interception, evapotranspiration, and infiltration. Maximizing these functions will thereby reduce the amount of runoff that must be treated. Protection of mature trees and vegetation provides habitat, prevents erosion, captures significant rainfall, provides summer shading, and reduces runoff volume and velocity which protects and enhances downstream water quality. Specific measures are:

- Preserve/protect riparian buffers.
- Preserve/protect wetlands.
- Preserve/protect natural flow pathways.
- Preserve/protect steep slopes.
- Preserve/protect sensitive environmental areas.
- Preserve/protect undisturbed vegetated areas/corridors.
- Preserve native trees and restrict disturbance of soils beneath tree canopies.
- Limit construction activities and disturbances to areas with previously disturbed soils.
- Avoid disturbing vegetation and soil on slopes and near surface waters.
- Leave an undisturbed buffer along both sides of natural streams.

Refer to Section 6 regarding considerations and sequencing practices to preserve existing vegetation during construction.

### 3.2.2. Minimize Disturbances to Natural Drainages

Natural drainages offer a benefit to storm water management as the soils and habitat already function as a natural filtering/infiltrating swale. Minimizing disturbances to natural drainage patterns preserves the predevelopment timing, rate, and duration of runoff as well as preserving streamside habitats. When determining the development footprint of the site, natural drainages should be avoided. By keeping the development envelope set back from natural drainages, the drainage can retain its water quality benefit to the watershed. Specific measures are:

- Limit site disturbance, clearing, and grading to the smallest areas necessary.
- Maintain surface flow patterns of undeveloped sites.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

- Maintain existing water body alignments, sizes, and shapes.
- Minimize and control construction traffic areas.
- Minimize and control construction stockpiling and storage areas.
- Use construction fencing to mark where no disturbances will be allowed.

### 3.2.3. Minimize Soil Compaction

Clearing, grading and compaction by construction traffic reduces the natural absorption and infiltration capacities of the native soils. Soil compaction damages soil structure, reduces infiltration rates, limits root growth and plant survivability, and destroys soil organisms. Subsequent tilling and/or addition of soil amendments such as compost can help, but will not restore the original infiltration capacity of the soils. By protecting native soils and vegetation in appropriate areas during the clearing and grading phase of development the site can retain some of its existing beneficial hydrologic function. Specific measures are:

- Protect soils against compaction and rutting in areas where traffic is unavoidable.
- Minimize the size of construction easements and material storage areas.
- Limit areas of heavy equipment.
- Prohibit working on wet soils with heavy equipment.
- Restore compacted open space areas with tilling and soil amendments.
- Avoid extensive and unnecessary clearing and stockpiling of topsoil.
- Avoid/minimize soil compaction in open space, landscaped, and proposed LID BMP areas.
- Prepare soil amendments off-site.

### 3.2.4. Direct Runoff to Landscape Areas and Reduce Directly Connected Impervious Areas

Any impervious surface that drains into a catch basin, area drain, or other conveyance structure is a DCIA. Impervious areas directly connected to the storm drain system are the greatest contributor to nonpoint source pollution. The first effort in site planning and design for storm water quality protection is to minimize the DCIA as shown in **Figure 3.3**.




Figure 3.3: Directly Connected Impervious Area versus Directing Runoff to Landscaped Areas

As storm water runoff flows across parking lots, roadways, and paved areas, the oils, sediments, metals, and other pollutants are collected and concentrated. If this runoff is collected by a drainage system and carried directly along impervious gutters or in closed underground pipes, it has no opportunity for filtering by plant material or infiltration into the soil. It also increases in speed and volume, which may cause higher peak flows downstream, and may require larger capacity storm drain systems, increasing flood and erosion potential. Solutions that reduce DCIA prevent runoff, detain or retain surface water, attenuate peak runoff rates, benefit water quality and convey storm water. Specific measures are:

- Design roof drains to flow to vegetated areas.
- Direct flow from paved areas to stabilized landscaped/vegetated areas (See Figure 3.4).
- Grade paved areas to achieve sheet flow to landscaped areas.
- Break up flow directions from large paved surfaces.



Figure 3.4: Parking Lot Directing Runoff to Landscape Areas

### 3.2.5. Minimize Impervious Surfaces

The principle of runoff reduction starts by recognizing that developing or redeveloping land within a watershed inherently increases the imperviousness of the areas and therefore the volume and rate of runoff and the associated pollutant load.

The extent of impervious land covering the landscape is an important indicator of storm water quantity and quality and the health of urban watersheds. Studies have demonstrated a direct correlation between the degree of imperviousness of an area and the degradation of its receiving waters. Impervious land coverage is a fundamental characteristic of the urban and suburban environment; rooftops, roadways, parking areas, and other impenetrable surfaces cover soils that allowed rainwater to infiltrate before development.

Without these impervious coverings, inherent watershed functions would naturally filter rainwater and prevent receiving water degradation. Impervious surfaces associated with urbanization can cause adverse receiving water impacts in four (4) ways:

- 1. Rainwater is prevented from filtering into the soil, adversely affecting groundwater recharge and reducing base stream flows.
- 2. Because it cannot filter into the soil, more rainwater runs off, and runs off more quickly, causing increased flow volumes, accelerating erosion in natural channels, and reducing habitat and other stream values. Flooding and channel destabilization often require further intervention. As a result, riparian corridors are lost to channelization, further reducing habitat values.

- 3. Pollutants that settle on the impervious pavements and rooftops are washed untreated into storm sewers and nearby stream channels, increasing pollution in receiving water bodies.
- 4. Impervious surfaces retain and reflect heat, increasing ambient air and water temperatures. Increased water temperature negatively impacts aquatic life and reduces the oxygen content of nearby water bodies.

These techniques include actions to:

- Manage watershed impervious area.
- Include self-mitigating areas.
- Consider runoff reduction areas.

### Manage Watershed Impervious Area

Land use planning on the watershed scale is a powerful tool to manage the extent of impervious land coverage and is especially applicable to larger scale community development and master planning. First, identify open space and sensitive resource areas and target growth to areas that are best suited to development, and second, plan development that is compact to reduce overall land conversion to impervious surfaces and reliance on land-intensive streets and parking systems.

Water resource protection is becoming more complex. A wide variety of regulatory agencies, diverse sources of non-point source pollution, and a multitude of stakeholders make it difficult to achieve a consistent, easily understandable strategy for watershed protection. Impervious land coverage is a scientifically sound, easily communicated, and practical way to measure the impacts of new development on water quality.

Impervious area reductions also provide additional benefits such as reduced urban heat island effect, resulting in less energy use to cool structures and more efficient irrigation use by plants. Reductions have also been attributed to more human-scale landscaping and higher property values.

Strategies for reducing impervious land coverage include:

- Cluster buildings so that they require less driveways and pathways.
- Taller narrower buildings rather than lower spreading ones.
- Sod or vegetative "green roofs" rather than conventional roofing materials.
- Pervious pavement for light duty roads, parking lots, and pathways.
- Use open space or hybrid street plan instead of grid and curvilinear.
- Maximize utilization of compact car spaces in parking areas.
- Reduce driveway sizes.

Many of these strategies are discussed in Section 3. Two (2) of the strategies to Minimize Impervious Surfaces result in direct benefit to treatment control requirements: Self-Mitigating Areas and Runoff Reduction Areas. These two (2) strategies result in a smaller WQV requiring treatment under the City's Water Quality Rules.

Revised: July 2017

### **Include Self-Mitigating Areas**

Developed areas may provide "self-mitigation" of runoff if properly designed and drained.

A self-mitigating area is a natural or landscape area which retain and/or treat rainfall over the footprint of the self-mitigating area but do not accept runoff from other areas. Self-mitigating areas can drain directly offsite or to the public storm drain system without being treated by a structural BMP.

Self-mitigating areas might include:

- Conserved natural spaces
- Landscaped areas (including parks and lawns)
- Grass/vegetated swales
- Green roofs

The infiltration and biotreatment inherent to such areas provides the treatment control necessary. These areas therefore act as their own BMP, and no additional BMPs to treat runoff are required.

As illustrated in **Figure 3.5**, site drainage designs must direct runoff from self-treating areas away from other areas of the site that require treatment of runoff. Otherwise, the volume from the self-mitigating area will only add to the volume requiring treatment from the impervious area as demonstrated in **Figure 3.6**.

Likewise, under this philosophy, self-mitigating areas receiving runoff from treatment-required areas would no longer be considered self-mitigating, but rather would be considered as the BMPs in place to treat that runoff. These areas could remain as self-mitigating, or partially self-mitigating areas, if adequately sized to handle the excess runoff addition.

### Consider Runoff Reduction Areas

Using alternative surfaces with a lower coefficient of runoff or "C-Factor" can reduce runoff from developed areas. The C-Factor is a representation of the surface's ability to produce runoff. Surfaces that produce higher volumes of runoff are represented by higher C-Factors, such as impervious surfaces. Surfaces that produce smaller volumes of runoff are represented by lower C-Factors, such as more pervious surfaces. See **Table 3.1** for typical C-Factor values for various surfaces during small storms.

**Table 3.1: Estimated C-Factor for Various Surfaces during Small Storms** 

Paving Surfaces	C-Factor	Paving Surfaces	C-Factor
Concrete	0.80	Permeable interlocking concrete pavement	0.10
Stone, brick, or concrete pavers with mortared joints and bedding	0.80	Grid pavements with grass or aggregate surface	0.10
Asphalt	0.70	Crushed aggregate	0.10
Stone, brick, or concrete pavers with sand joints and bedding	0.70	Grass	0.10
Pervious concrete	0.10	Grass over porous plastic	0.05
Porous asphalt	0.10	Gravel over porous plastic	0.05

Note: C-Factors for small storms are likely to differ (be lower) than C-Factors developed for large, flood control volume size storms. The above C-Factors were produced by selecting the lower end of the best available C-Factor range for each paving surface. These C-Factors are only appropriate for small storm treatment design, and should not be used for flood control sizing.





Figure 3.5: Use of Self-Mitigating Areas



**Figure 3.6: Self-Mitigating Areas Treatment Volume** 

Site design techniques that incorporate pervious materials may be used to reduce the C-Factor of a developed area, reducing the amount of runoff requiring treatment. These materials include:

- Pervious concrete
- · Pervious asphalt
- Turf block
- Brick (un-grouted)
- Natural stone
- Concrete unit pavers
- Crushed aggregate
- Cobbles
- Wood mulch

**Table 3.2** compares the C-Factors of conventional paving surfaces to alternative; lower C-Factor paving surfaces. By incorporating more pervious, lower C-Factor surfaces into a development (see **Figure 3.7**); lower volumes of runoff may be produced. Lower volumes and rates of runoff translate directly to lower treatment requirements.

Table 3.2: Conventional Paving Surface Small Storm C-Factor versus Alternative Paving C-Factors

Conventional Paving Surface C-Factors		Reduced C-Factor for Paving Alternatives	
•	Concrete Patio/Plaza (0.80)	•	Decorative unit Pavers on Sand (0.10)
•	Asphalt Parking Area (0.70)	•	Turf Block Overflow Parking Area (0.10)
		•	Pervious Concrete (0.10)
		•	Pervious Asphalt (0.10)
		•	Crushed Aggregate (0.10)

Other site design techniques such as disconnecting impervious areas, preservation of natural areas, and designing concave medians may be used to reduce the overall C-Factor of development areas.

### 3.3. Control Sources of Pollutants

There are a number of items that can be routinely designed into a project that function as source controls once a project is completed. Design of BMPs to control exposure to pollutants is guided by two (2) general principles:

- Prevent water from contacting work areas. Work and storage areas should be designed to prevent storm water runoff from passing through shipping areas, vehicle maintenance yards, and other work places before it reaches storm drains. The objective is to prevent the discharge of water laden with grease, oil, heavy metals and process fluids to surface waters or sensitive resource areas
- 2. Prevent pollutants from contacting surfaces that come into contact with storm water runoff. Precautionary measures should be employed to keep pollutants from contacting surfaces that come into contact with runoff. This means controlling spills and reviewing operational practices and equipment to prevent pollutants from coming into contact with storm or wash water runoff.

Examples of structural source controls include covers, impermeable surfaces, secondary containment facilities, runoff diversion berms, and diversions to wastewater treatment plants. See **Figure 3.7**.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017




Figure 3.7: Example of Source Control Design for Outdoor Material Storage

The *Water Quality Rules* require that Source Control BMPs are required for all Priority A and B projects for the following activities and areas:

Activity or Area Required to Implement Source Control	BMP Fact Sheet (Appendix A)
Landscaped Areas	SD-01
Automatic Irrigation System	SD-03
Storm Drain Inlets	SD-04
Vehicle/Equipment Fueling	SD-06
Vehicle/Equipment Repair	SD-07
Vehicle/Equipment Cleaning	SD-08
Loading Docks	SD-09
Outdoor Trash Storage	SD-10
Outdoor Material Storage	SD-11
Outdoor Work Areas	SD-12
Outdoor Process Equipment Operations	SD-13
Parking Areas	SD-14

Source control fact sheets are provided in **Appendix A**. In addition, fact sheets are provided for Roof Runoff Controls (SD-02) and Alternative Building Materials (SD-05) which are not required by the *Water Quality Rules*.

The following information is provided for each of the above-listed BMPs:

- Brief Description/Approach
- Suitable Applications
- Design Considerations

- Design Guidelines
- Examples
- Operations & Maintenance Recommendations

### 3.4. Treat Runoff

Today's drainage systems must meet multiple purposes: protect property from flooding, control stream bank erosion, and protect water quality. To achieve this, designers must integrate conventional flood control strategies for large, infrequent storms with storm water quality control strategies.

There are several basic water quality strategies for treating runoff:

- Infiltrate runoff into the soil.
- Capture, store, and reuse runoff on site.
- Convey runoff slowly through vegetation.
- Treat runoff on a flow-through basis using various treatment technologies.
- Retain/detain runoff for later release with the detention providing treatment.

Solutions should be based on an understanding of the water quality and economic benefits inherent in construction of systems that utilize or mimic natural drainage patterns. Site designs should be based on site conditions and use these as the basis for selecting appropriate storm water quality controls. The drainage system design process considers variables such as local climate, the infiltration rate and erosivity of the soils, and slope.

Unlike conveyance models, which are assessed by simple quantitative measures (flood control volumes and economics), water quality designs must optimize a complex array of both quantitative and qualitative standards, including engineering worthiness, environmental benefit, horticultural sustainability, aesthetics, functionality, maintainability, economics and safety.

Treatment Control BMPs are discussed in more detail in Section 5.

### 4. Site and Facility Design for Water Quality Protection

Many common site features can achieve storm water management goals by incorporating one or more basic elements, either alone or in combination, depending on site and other conditions. The basic elements include infiltration, retention/detention, biofilters, and structural controls. This section first describes these basic elements, and then describes how these elements can be incorporated into common site features.

### 4.1. Infiltration

Infiltration is the process where water enters the ground and moves downward through the unsaturated soil zone. Infiltration is ideal for management and conservation of runoff because it filters pollutants through the soil and restores natural flows to groundwater and downstream water bodies. See **Figure 4.1**.




Figure 4.1: Infiltration Basin

The infiltration approach to storm water management seeks to "preserve and restore the hydrologic cycle." An infiltration storm water system seeks to infiltrate runoff into the soil by allowing it to flow slowly over permeable surfaces (see **Figure 4.2** and **Figure 4.3**).

The slow flow of runoff allows pollutants to settle into the soil where they are naturally mitigated. The reduced volume of runoff that remains takes a long time to reach the outfall, and when it empties into a natural water body or storm sewer, its pollutant load is greatly reduced.

Infiltration basins can be either open or closed. Open infiltration basins include ponds, swales and other landscape features and are usually vegetated to maintain the porosity of the soil structure and to reduce erosion. Infiltration trenches and dry wells can also fall into this category although not typically vegetated.

Closed infiltration basins can be constructed under the land surface with open graded crushed stone, leaving the surface to be used for parking or other uses. Subsurface closed basins are generally more difficult to maintain and more expensive than open filtration systems, and are used primarily where high land costs demand that the land surface be reclaimed for economic use.

Infiltration systems are often designed to capture the "first flush" storm event and used in combination with a detention basin to control peak hydraulic flows. They effectively remove suspended solids, particulates, bacteria, organics and soluble metals and nutrients through the vehicle of filtration, absorption and microbial decomposition. Groundwater contamination should be considered as a potential adverse effect and should be considered where shallow groundwater is a source of drinking water. In cases where groundwater sources are deep, there is a very low chance of contamination from normal concentrations of typical urban runoff.

Bioretention facilities have the added benefit of aesthetic appeal and small scale applicability. These systems can be placed in parking lot islands, landscaped areas surrounding buildings, perimeter parking lots, and other open space sections. Placing bioretention facilities on land that City regulations require developers to devote to open space efficiently uses the land. An experienced landscape architect can choose plant species and planting materials that are easy to maintain, aesthetically pleasing, and capable of effectively reducing pollutants in runoff from the site.




Figure 4.2: Typical Infiltration Facility Schematic





Figure 4.3: Typical Bioretention Schematic


### 4.2. Retention and Detention

Retention and detention systems differ from infiltration systems primarily in intent. Retention and detention systems may release runoff slowly enough to reduce downstream peak flows to their predevelopment levels, allow fine sediments to settle, and uptake dissolved nutrients in the runoff where wetland vegetation is included. Detention systems are designed to capture and retain runoff temporarily and release it to receiving waters at predevelopment flow rates (see **Figure 4.4**). Permanent pools of water are not held between storm events. Pollutants settle out and are removed from the water column through physical processes. Detention systems are allowed under the *Water Quality Rules* for the portions of the WQV that are infeasible to treat with infiltration, harvest/reuse, and Biofiltration BMPs.

Retention systems capture runoff and retain it between storms as shown in **Figure 4.5**. While infiltration does occur, water held in the system is displaced by the next significant rainfall event. Pollutants settle out and are thereby removed from the water column. Because water remains in the system for a period of time, retention systems benefit from biological and biochemical removal mechanisms provided by aquatic plants and microorganisms.



**Figure 4.4: Simple Detention System** 



**Figure 4.5: Retention System** 

Constructed wetland systems retain and release storm water in a manner that is similar to retention or detention basins. The design mimics natural ecological functions and uses wetland vegetation to filter pollutants. The system needs a permanent water source to function properly and must be engineered to remove coarse sediment, especially construction related sediments, from entering the pond. Storm water has the potential to negatively affect natural wetland functions and constructed wetlands can be used to buffer sensitive resources.

### 4.3. Biofilters

Biofilters can consist of vegetated swales and filter strips, green roofs, and engineered or proprietary biofiltration devices such as planter boxes and tree box filters.

Swales are vegetated slopes and channels designed and maintained to transport shallow depths of runoff slowly over vegetation (see **Figure 4.6**). Swales are generally effective if flows are slow [1 ft/second (sec) maximum] and depths are shallow (4 inch maximum). The slow movement of runoff through the vegetation provides an opportunity for sediments and particulates to be filtered and degraded through biological activity. In most soils, the biofilter can also provide an opportunity for storm water infiltration, which further removes pollutants and reduces runoff volumes.

Swales intercept both sheet and concentrated flows and convey these flows in a concentrated, vegetation-lined channel. Grass filter strips intercept sheet runoff from the impervious network of streets, parking lots, and rooftops and divert storm water to a uniformly graded meadow, buffer zone, or small forest. Typically, the vegetated swale and grass strip-planting palette can comprise a wide range of possibilities from dense vegetation to turf grass. Grass strips and vegetated swales can function as pretreatment systems for water entering bioretention systems or other BMPs. If biofilters are to succeed in filtering pollutants from the water column, the planting design must consider the hydrology, soils, and maintenance requirements of the site.




Figure 4.6: Vegetated Swale

Appropriate plants not only improve water quality, but provide habitat and aesthetic benefits. Selected plant materials must be able to adapt to variable moisture regimes. Turf grass is acceptable if it can be watered in the dry season, and if it is not inundated for long periods.

Biofilters also include engineered or proprietary systems such as planter boxes, tree box filters, or similar. They function as soil and plant-based filtration systems, similar to swales that remove pollutants through a variety or physical, biological and chemical treatment processes. The components normally consist of a ponding area, mulch layer, planting soils, plantings, and either a pervious or impervious bottom layer with underdrain (see **Figure 4.7**). These devices can work hand in hand with down spout disconnections.




Figure 4.7: Schematic of Planter Box with Down Spout Connection and Underdrain

### 4.4. Street Design

Street design is mandated by City standards. More than any other single element, street design has a powerful impact on storm water quality. Street and other transportation-related structures typically can comprise between 60 to 70% of the total impervious coverage in urban areas and, unlike rooftops, streets are almost always directly connected to an underground storm water system.

Recognizing that street design can be the greatest factor in development's impact on storm water quality, it is important that designers and developers employ street standards that reduce impervious land coverage. Directing runoff to biofilters or swales rather than underground storm drains produces a street system that conveys storm water efficiently while providing both water quality and aesthetic benefits.

On streets where a more urban character is desired, or where a rigid pavement edge is required, curb and gutter systems can be designed to empty into drainage swales. These swales can run parallel to the street, in the parkway between the curb and the sidewalk, or can intersect the street at cross-angles, and run between residences, depending on topography or site planning. Runoff travels along the gutter, but instead of being emptied into a catch basin and underground pipe, multiple openings in the curb direct runoff into surface swales or infiltration/detention basins.

In recent years, new street standards have been gaining acceptance that meets the access requirements of local residential streets while reducing impervious land coverage. These standards create a new class of street that is narrower and more interconnected than the current local street standard, called an "access"

street. An access street is at the lowest end of the street hierarchy and is intended only to provide access to a limited number of residences.

A street standard that allows an interconnected system of narrow access streets for residential neighborhoods has the potential to achieve several complimentary environmental and social benefits. A hierarchy of streets sized according to average daily traffic volumes yields a wide variety of benefits: improved safety from lower speeds and volumes, improved aesthetics from street trees and green parkways, reduced impervious land coverage, less heat island effect, and lower development costs. If the reduction in street width is accompanied by a drainage system that allows for infiltration of runoff, the impact of streets on storm water quality can be greatly mitigated.

A comparison of street cross-sections is shown in Figure 4.8.




Figure 4.8: Comparison of Street Cross-Section (Two-Way, Residential Access Streets)

### 4.5. Street Trees

Trees improve water quality by intercepting and storing rainfall on leaves and branch surfaces, thereby reducing runoff volumes and delaying the onset of peak flows. A single street tree can have a total leaf surface area of several hundred to several thousand sq-ft, depending on species and size. This aboveground surface area created by trees and other plants greatly contributes to the water holding capacity of the land. They attenuate conveyance by increasing the soil's capacity to filter rainwater and reduce overland flow rates. By diminishing the impact of raindrops on un-vegetated soil, trees reduce soil erosion. Street trees also have the ability to reduce ambient temperature of storm water runoff and absorb surface water pollutants.

### 4.6. Parking Lots

In any development, storage space for stationary vehicles can consume many acres of land area, often greater than the area covered by streets or rooftops. In a neighborhood of single-family homes, this parking area is generally located on private driveways or along the street. In higher density residential developments, parking is often consolidated in parking lots.

The space for storage of the automobile, the standard parking stall, occupies only 160 sq-ft, but when combined with aisles, driveways, curbs, overhang space, and median islands, a parking lot can require up to 400 sq-ft per vehicle, or nearly one acre per 100 cars. Since parking is usually accommodated on an asphalt or concrete surface with conventional underground storm drain systems, parking lots typically generate a great deal of DCIA.

There are many ways to both reduce the impervious land coverage of parking areas and to filter runoff before it reaches the storm drain system.

### 4.6.1. Hybrid Parking Lots

Hybrid lots work on the principle that pavement use differs between aisles and stalls. Aisles must be designed for speeds between 10 and 20 miles per hour (mph), and durable enough to support the concentrated traffic of all vehicles using the lot. The stalls, on the other hand, need only be designed for the 2 or 3 mph speed of vehicles maneuvering into place. Most of the time the stalls are in use, vehicles are stationary. Hybrid lots reduce impervious surface coverage in parking areas by differentiating the paving between aisles and stalls, and combining impervious aisles with permeable stalls, as shown in **Figures 4.9 and 4.10**.

If aisles are constructed of a more conventional, impermeable material suitable for heavier vehicle use, such as asphalt, stalls can be constructed of permeable pavement. This can reduce the overall impervious surface coverage of a typical double loaded parking lot by 60% and avoid the need for an underground drainage system.

Permeable stalls can be constructed of a number of materials including pervious concrete, unit pavers such as brick or stone spaced to expose a permeable joint and set on a permeable base, crushed aggregate, porous asphalt, turf block, and cobbles in low traffic areas. Turf blocks and permeable joints are shown in **Figures 4.11 and 4.12**.




Figure 4.9: Hybrid Parking Lot



Figure 4.10: Hybrid Parking Lot (Honolulu, HI)




Figure 4.11: Turf Blocks




Figure 4.12: Permeable Joints

### 4.6.2. Parking Grove

A variation on the permeable stall design, a grid of trees and bollards can be used to delineate parking stalls and create a "parking grove." If the bollard and tree grids are spaced approximately 19 ft apart, two (2) vehicles can park between each row of the grid. This 9.5 ft stall spacing is slightly more generous than the standard 8.5 to 9 ft stall, and allows for the added width of the tree trunks and bollards. A benefit of this design is that the parking grove not only shades parked cars, but also presents an attractive open space when cars are absent. Examples of parking groves are shown in **Figures 4.13 and 4.14**.

### 4.6.3. Overflow Parking

Parking lot design is often required to accommodate peak demand, generating a high proportion of impervious land coverage of very limited usefulness. An alternative is to differentiate between regular and peak parking demands, and to construct the peak parking stalls of a different, more permeable, material. This "overflow parking" area can be made of a turf block, which appears as a green lawn when not occupied by vehicles, or crushed stone or other materials (see **Figure 4.15**). The same concept can be applied to areas with temporary parking needs, such as emergency access routes, or in residential applications, recreational vehicle (RV), or trailer parking.




Figure 4.13: Parking Grove 1



Figure 4.14: Parking Grove 2



Figure 4.15: Overflow Parking

### 4.6.4. Porous Pavement with Subsurface Infiltration

In some cases, parking lots can be designed to perform more complex storm water management functions. Constructing a stone-filled reservoir below the pavement surface and directing runoff underground by means of perforated distribution pipes can achieve subsurface storm water storage and infiltration as shown in **Figure 4.16**. Subsurface infiltration basins eliminate the possibilities of mud, mosquitoes and safety hazards sometimes perceived to be associated with ephemeral surface drainage. They also can provide for storage of large volumes of runoff, and can be incorporated with roof runoff collection systems.




Figure 4.16: Subsurface Infiltration System

### 4.7. Driveways

Driveways can comprise up to 40% of the total transportation network in a conventional development, with streets, turn-arounds, and sidewalks comprising the remaining 60%.

Driveway length is generally determined by garage setback requirements and width by city codes and land use ordinances. Driveways to City streets shall have a minimum width of 12 ft excluding flares (reference: City Standard Details for Public Works Construction). If garages are setback from the street, long driveways are required, unless a rear alley system is included to provide garage access. If parking for two vehicles side by side is required, a 20 ft minimum width is required. Thus, if a 20 ft setback and a two-car-wide driveway are required, a minimum of 400 sq-ft of driveway will result, or 4% of a typical 10,000 sq-ft residential lot. If the house itself is compact, and the driveway is long, wide, and paved with an impervious material such as asphalt or concrete, it can become the largest component of impervious land coverage on the lot.

An option to reduce the area dedicated to driveways is to allow for tandem parking (one vehicle in front of another on a narrow driveway). In addition, if shared driveways are permitted, then two (2) or more garages can be accessed by a single driveway, further reducing required land area. Rear alley access to the garage can reduce driveway length, but overall impervious surface coverage may not be reduced if the alleys are paved with impervious materials and the access streets remain designed to conventional city standards.

Alternative solutions that work to reduce the impact of water quality problems associated with impervious land coverage on city streets also work on driveways. Sloping the driveway so that it drains onto an adjacent turf or groundcover area prevents driveways from draining directly to storm drain systems. Use of turf-block or unit pavers on sand creates attractive, low maintenance, permeable driveways that filter storm water (see **Figure 4.17**). Crushed aggregate can serve as a relatively smooth pavement with minimal maintenance as shown in **Figure 4.18**. As shown in **Figure 4.19**, paving only under wheels is a viable, inexpensive design if the driveway is straight between the garage and the street, and repaving temporary parking areas with permeable unit pavers such as brick or stone can significantly reduce the percentage of impervious area devoted to the driveway.




Figure 4.17: Unit Pavers

Figure 4.18: Crushed Aggregate




Figure 4.19: Paving only under Wheels

### 4.8. Landscape and Open Space

In the natural landscape, most soils infiltrate a high percentage of rainwater through a complex web of organic and biological activities that build soil porosity and permeability. Roots reach into the soil and separate particles of clay, insects excavate voids in the soil mass, roots decay leaving networks of macro pores, leaves fall and form a mulch over the soil surface, and earthworms burrow and ingest organic detritus to create richer, more porous soil. These are just a few examples of the natural processes that occur within the soil.

Maintenance of a healthy soil structure through the practice of retaining or restoring native soils where possible and using soil amendments where appropriate can improve the land's ability to filter and slowly release storm water into drainage networks. Construction practices such as decreasing soil compaction, storing topsoil on-site for use after construction, and chipping wood for mulch as it is cleared for the land can improve soil quality and help maintain healthy watersheds. Practices that reduce erosion and help retain water on-site include incorporating organic amendments into disturbed soils after construction, retaining native vegetation, and covering soil during revegetation.

Subtle changes in grading can also improve infiltration. Landscape surfaces are conventionally graded to have a slight convex slope. This causes water to run off a central high point into a surrounding drainage system, creating increased runoff. If a landscape surface is graded to have a slightly concave slope, it will hold water. The infiltration value of concave vegetated surfaces is greater in permeable soils. Soils of heavy clay or underlain with hardpan provide less infiltration value. In these cases, concave vegetated surfaces must be designed as retention/detention basins, with proper outlets or under drains to an interconnected system.

### 4.9. Multiple Small Basins

Biofiltration, infiltration, and retention/detention basins are the basic elements of a landscape designed for storm water management. The challenge for designers is to integrate these elements creatively and attractively in the landscape – either within a conventional landscape aesthetic or by presenting a different landscape image that emphasizes the role of water and drainage.

Multiple small basins can provide a great deal of water storage and infiltration capacity. These small basins can fit into the parkway planting strip or shoulders of street rights-of-way. If connected by culverts under walks and driveways, they can create a continuous linear infiltration system. Infiltration and retention/detention basins can be placed under wood decks, in parking lot planter islands, and at roof downspouts. Outdoor patios or seating areas can be sunken a few steps, paved with a permeable pavement such as flagstone or gravel, and designed to hold a few inches of water collected from surrounding rooftops or paved areas for a few hours after a rain.

All of these are examples of small basins that can store water for a brief period, allowing it to infiltrate into the soil, slowing its release into the drainage network, and filtering pollutants. An ordinary lawn can be designed to hold a few inches of water for a few hours after a storm, attracting birds and creating a landscape of diversity. Grass/vegetated swales can be integrated with landscaping, providing an attractive, low maintenance, linear biofilter. Extended detention basins (dry ponds) store water during storms, holding runoff to predevelopment levels. Pollutants settle and are removed from the water column before discharging to streams. Wet ponds serve a similar purpose and can increase property values by providing a significant aesthetic, and passive recreation opportunity.

Plant species selection is critical for proper functioning of infiltration areas. Proper selection of plant materials can improve the infiltration potential of landscape areas. Deep-rooted plants help to build soil porosity. Plant leaf-surface area helps to collect rainwater before it lands on the soil, especially in light rains, increasing the overall water-holding potential of the landscape.

A large number of plant species will survive moist soils or periodic inundation. These plants provide a wide range of choices for planted infiltration/detention basins and drainage swales. Most inundated plants have a higher survival potential on well-drained alluvial soils than on fine textured shallow soils or clays.

### 4.10. Planning Development Strategies in Practice

The importance of site planning in storm water quality protection is illustrated in the following examples of development strategies: conventional residential subdivision (**Figure 4.20: Alternative 1**), conventional subdivision employing BMPs (**Figure 4.21: Alternative 2**), and a mixed-use transit-oriented development (**Figure 4.22: Alternative 3**). All three (3) examples are intended to accommodate approximately 660 housing units on a 220-acre site adjacent to a stream.

The conventional residential subdivision (**Figure 4.20: Alternative 1**) accommodates 660 single-family homes on individual lots. One-sixth acre lots are accessed by a network of 40 ft wide cul-de-sac streets, with 5 ft sidewalks adjacent to the curb on each side of the street. The street and sidewalks are located within a 60 ft right-of-way, which is covered with a 40 ft wide street and two (2)- 5 ft sidewalks, or 50 ft of pavement, 100% impervious land coverage (streets only), and no room for street trees. No variation exists in housing types (all single-family).

Both the streets and the open space features lack structure or hierarchy. The few direct connections through the neighborhood result in long stretches of overly wide streets that discourage walking.

Conventional development design does not use the recreational or storm water benefits of the available open space and does not respond to natural and topographic features. Preservation of open space is a low priority, and the setback between the development and the stream is minimal. The remaining open space character is remnant space offering residents no stream access or parks. Storm water travels through a 15,000 ft network of drainpipes and in the absence of current permit requirements would discharge untreated runoff directly into the stream. However, applying typical permit requirements, the development would still be required to incorporate runoff treatment for the water quality design volume defined in the local permit or MS4 new development program. For example, if the permit required treatment of the runoff from 0.75 inches of rainfall, the development as planned had an overall percent impervious value of 45%, and the designer was considering the use of an extended detention basin for treatment, this would require a treatment volume of approximately 8.3 acre-ft. Based on typical detention basin design practices, this could result in the need to dedicate approximately 2 to 3 acres of land, or the equivalent of approximately 12 to 18 lots to incorporate the basin into the development near the point where drainage enters the stream. Alternatively, if a watershed master plan for water quality had been adopted in which the development could participate financially, the project would contribute financially based on its required treatment volume and the cost allocation plan for the watershed program.

The hybrid/best practices subdivision (**Figure 4.21: Alternative 2**) illustrates a conventional neighborhood that applies some storm water management practices. This attempt accommodates 660 single-family homes on individual lots. Streets are narrower, with the interior access streets at 28 ft wide, while internal neighborhood collectors are 32 ft wide. All streets have detached sidewalks that accommodate street trees planted between the sidewalk and the curb. This development sets the houses

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

100 ft back from the stream and offers residents 12 acres of access to open space and parks. The overall imperviousness has been reduced to about 41%, thereby reducing the volume to be treated to approximately 7.5 acre-ft. A detention basin has been created in open space within the development. Nearly 25% of the 13,000 ft network of piped storm water drains to a detention pond.

By employing a hierarchy of narrower streets this neighborhood requires 1,475 sq-ft of street per housing unit, a reduction of 19% relative to the conventional sub-division.

The neo-traditional mixed-use neighborhood is illustrated as Alternative 3 (**Figure 4.22**). This neighborhood includes 660 housing units, but also introduces other uses: retail, office, and live-work, within a network of tree-lined streets and open space. The neighborhood drains to an open space park adjacent to the stream, naturally and efficiently filtering storm water before it enters the stream. Bioswales along key streets capture and treat storm water en-route to the stream, providing aesthetic appeal and recreational opportunities. Alternative 3 requires 965 sq-ft of street per housing unit, a reduction of 47% relative to the conventional sub-division. A strategically located transit system stops near shops and higher density housing makes transit feasible. Every dwelling unit in the neighborhood is within a 5-minute (min) walk from shops or transit. The overall imperviousness of this site has been reduced to approximately 36%, further reducing the treatment volume. In addition, there are a variety of opportunities to incorporate treatment for all of the remaining runoff within the open space park without the need to dedicate any additional developable land.

A comparison of the three (3) alternatives is shown in **Table 4.1**.



Figure 4.20: Alternative 1 - Conventional



Figure 4.21: Alternative 2 - Hybrid/Best Practices



**Figure 4.22: Alternative 3 - Neo-Traditional** 

**Table 4.1: Comparison of Three Alternatives** 

	Alternative 1	Alternative 2	Alternative 3
Total Site (acre)	220	220	220
Number of Housing Units	660	660	660
Parks and Open Space (acre)	0	12	12
Stream Setback (feet)	0	100	500
Impervious Land Coverage - Street (acre)	28	22	15
Percentage of Site that is Impervious - Street only	13%	10%	7%
Percentage of Site that is Impervious - Street only (relative to conventional)	100%	81%	53%
Linear feet of Pipe	15,000	13,000	10,000
Linear feet of Swale	0	0	4,700
Width of Major Streets (feet)	40	32	32
Width of Minor Streets (feet)	None	28	28

Typical lots in Alternatives 2 and 3 are illustrated in three (3) forms: street loaded, alley fed and rural. In the street-loaded form, lot size is still approximately 1/6 acre, but the lot is narrower and deeper, thus reducing the amount of street frontage per household. The two-car garage is accessed from a front driveway. This front-loaded street accounts for 63% impervious land coverage in the 60 ft right-of-way.

Looking at a typical street, the traditional residential neighborhood reduces the number of feet of street and sidewalk per housing unit by nearly 40% compared to the conventional subdivision. This is accomplished by two (2) means: a narrower street width (28 ft versus 40 ft), and narrower, deeper lots (60 ft versus 65 ft wide). Narrower lots mean less street frontage per lot.

In the alley-loaded form, the street right-of-way is narrowed to 50 ft, leaving 4 ft for trees between the sidewalk and curb. This form also employs the narrower street, achieving a 40% reduction in pavement dedicated to street and sidewalk. A 16 ft-wide alley is provided in the back to access a garage at the rear of each lot. Additional pavement for the alley is balanced by elimination of pavement for the front driveway. This model assumes an impervious asphalt or concrete alley. Gravel alleys are feasible, and improve permeability. In this form, narrower, deeper lots are employed to accommodate the depth required for the alley.

The rural street form dramatically reduces impervious land coverage. The street is 19 ft wide with gravel shoulders for trees and parking. Pedestrians walk on the gravel shoulder or share the street with slow-moving cars.

Looking at a typical street, the rural form provides the greatest reduction in impervious land coverage. Only 570 sq-ft of pavement of street is required per housing unit, a reduction of 62% compared to the conventional sub-division.

### 5. Treatment Control BMP Design

Treatment Control BMPs are engineered technologies designed to remove pollutants from storm water runoff prior to discharge to the storm drain system or receiving waters. This section addresses BMP numeric sizing criteria, guidance for infiltration testing BMPs, and individual BMP fact sheets to support compliance with the *Water Quality Rules*.

### **5.1.** Best Management Practices Selection

### 5.1.1. Determine Drainage Management Areas

Drainage management areas (DMAs) provide an important framework for feasibility screening, BMP prioritization, and storm water management system configuration. BMP selection, sizing, and feasibility determinations must be made at the DMA level; therefore, delineation of DMAs is highly recommended at the conceptual site planning phase and is mandatory for completing the project design and meeting submittal requirements. This section provides guidance on delineating DMAs that is intended to be used when choosing BMPs.

DMAs are defined based on the proposed drainage patterns of the site and the BMPs to which they drain. During the early phases of the project, DMAs shall be delineated based onsite drainage patterns and possible BMP locations identified in the site planning process. DMAs should not overlap and should be similar with respect to BMP opportunities and feasibility constraints. More than one DMA can drain to the same BMP. However, because the BMP sizes are determined by the runoff from the DMA, a single DMA may not drain to more than one (1) BMP (see **Figure 5.1**).




Figure 5.1: DMA Delineation

In some cases, it may be appropriate in early planning phases to generalize the proposed treatment plan by simply assigning a certain BMP type to an entire planning area and calculating the total sizing requirement without identifying the specific BMP locations at that time. This planning area would be later subdivided for design-level calculations.

BMPs must be sized to treat the WQV or Water Quality Flow (WQF) from the total area draining to the BMP, including any offsite or onsite areas that combine with project runoff and drains to the BMP. To minimize offsite flows treated by project BMPs, consider diverting upgradient flows subject to local drainage and flood control regulation.

### 5.1.2. Evaluate Pollutants of Concern

BMPs selected for each DMA should address anticipated pollutants of concern. Pollutants identified in the USEPA 303(d) list for specific water bodies in Hawaii include metals, nitrogen, nutrients (without specifying nitrogen or phosphorus), indicator bacteria (i.e., fecal coliform), pesticides, and trash. Less commonly cited pollutants include suspended solids, polychlorinated biophenyls (PCBs), and ammonium. With respect to metals, typically, only the general term is used. In some cases, lead is identified.

The BMP plan development process typically includes consideration of:

- Receiving water quality (including pollutants for which receiving waters are listed as impaired under CWA section 303(d)).
- Land use type of the development project and pollutants associated with that land use type.
- Pollutants expected to be present on site.
- Changes in storm water discharge flow rates, velocities, durations, and volumes resulting from the development project.
- Sensitivity of receiving waters to changes in storm water discharge flow rates, velocities, durations, and volumes.

It is important to realize that pollutants of concern for a water body can extend beyond those pollutants listed in the 303(d) list as causing impairment. For example, trash is a pollutant of concern in most communities, yet only a few water bodies are presently listed as impaired by trash. The key is to remember that a pollutant does not need to cause an immediate impairment for it to be considered when developing a BMP Plan.

**Table 5.1** summarizes pollutants typically associated with Priority Project land uses and can be used as general guidance when selecting BMPs.

### 5.1.3. Identify Candidate BMPs

Selecting BMPs based on pollutants of concern is a function of site constraints, constituents of concern, BMP performance, stringency of permit requirements, and watershed specific requirements such as TMDLs. Pollutants of concern are especially important in water limited stream segments and must be carefully reviewed in relationship to BMP performance.

To facilitate comparison of the BMP characteristics and selection, a summary of the BMP categories, expected pollutants, and BMP performance is presented in **Tables 5.2, 5.3 and 5.4**, respectively. Developers shall consider the expected pollutants that could be generated at the site when choosing BMPs.

**Table 5.1: Typical Pollutants Associated with Priority Projects** 

Priority Project Categories	Nutrients	Sediment	Trash	Pathogens	Pesticides	Oil & Grease	Metals	Organic Compounds
Priority A: Residential Development > one acre	X	X	X	X	X	X		
Priority A: Commercial Development >one acre	P <sup>(1)</sup>	<b>P</b> <sup>(1)</sup>	X	P <sup>(3)</sup>	P <sup>(5)</sup>	X	X	$P^{(2)}$
Priority B: Industrial		X	X			X	X	X
Priority B: Automotive Repair Shops			X			X	X	X <sup>(4)(5)</sup>
Priority B: Restaurants			X	X	P <sup>(1)</sup>	X		
Priority B: Parking Lots	P <sup>(1)</sup>	P <sup>(1)</sup>	X		P <sup>(1)</sup>	X	X	
Priority B: Retail Gasoline Outlets			X			X	X	X
Priority B: Buildings taller than 100 ft in height	X	X	X	X	X	X		
(All) Streets, Highways & Freeways	P <sup>(1)</sup>	X	X	X	P <sup>(1)</sup>	X	X	X <sup>(4)</sup>

X = anticipated P = potential

- (1) A potential pollutant if landscaping exists onsite.
- (2) A potential pollutant if the project includes uncovered parking areas.
- (3) A potential pollutant if land use involves food or animal waste products.
- (4) Including petroleum hydrocarbons.
- (5) Including Solvents

**Table 5.2: Treatment Control BMP Categories** 

ВМР	Retention	Biofiltration	Other
Infiltration Basin	✓		
Infiltration Trench	✓		
Subsurface Infiltration	✓		
Dry Well	✓		
Bioretention Basin	✓		
Permeable Pavement	✓		
Harvesting/Reuse	✓		
Green Roof		✓	
Vegetated Bio-filter <sup>1</sup>		✓	
Enhanced Swale		✓	
Downspout Disconnection		✓	
Vegetated Swale		✓	
Vegetated Buffer Strip		✓	
Detention Basin			✓
Manufactured Treatment Device			✓
Sand Filter			✓
<sup>1</sup> Includes both proprietary and non-proprietary systems.			

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

**Table 5.3: Treatment Control BMP Expected Pollutant Removals** 

Priority Project Categories	Nutrients	Sediment	Trash	Pathogens	Pesticides	Oil & Grease	Metals	Organic Compounds
Infiltration Basin	Н	Н	Н	Н	Н	Н	Н	Н
Infiltration Trench	Н	Н	Н	Н	Н	Н	Н	Н
Subsurface Infiltration	Н	Н	Н	Н	Н	Н	Н	Н
Dry Well	Н	Н	Н	Н	Н	Н	Н	Н
Bioretention Basin	Н	Н	Н	Н	Н	Н	Н	Н
Permeable Pavement	Н	Н	L	Н	Н	Н	Н	Н
Green Roof	M	Н	Н	M	M	Н	M	M
Vegetated Bio-Filter	M	Н	Н	M	U	Н	Н	Н
Enhanced Swale	M	Н	Н	U	U	M	M	U
Vegetated Swale	L	M	L	L	U	M	M	U
Vegetated Buffer Strip	L	M	M	L	U	M	M	M
Manufactured Tree Filter	M	Н	Н	M	U	Н	Н	Н
Harvesting/Reuse	Н	Н	L	Н	Н	Н	Н	Н
Detention Basin	L	M	Н	L	U	M	L/M	U
Manufactured Treatment Device	L	M/H	Н	L	L	M/H	L	L
Sand Filter	L/M	Н	Н	M	U	Н	M/H	M/H
H = High, M = Medium, L = Low, U = Unknown								

By using BMPs that are applicable and feasible, the project can achieve benefits of these practices, while not incurring unnecessary expenses (associated with using practices that do not apply or would not be effective) or creating undesirable conditions (for example, infiltration-related issues, vector concerns including mosquito breeding, etc.).

For example, on Oahu, many high-density, ultra-urban districts are in tidally influenced coastal areas and frequently encounter high ground water where infiltration may not be feasible. These projects would most typically fall into the redevelopment category rather than new development, which presents additional challenges with space constraints and soil quality. In these cases, Developers are encouraged to utilize multiple BMPs in combination or series to meet the LID retention and treatment criteria. While infiltration may not be possible, the Rules prioritize harvest and reuse systems to capture roof runoff and use the water onsite. For the remaining runoff, biofiltration BMPs can be integrated into the overall facility landscaping which may include green roofs, aboveground planter boxes, and tree box filters. Configuration of these BMPs as either aboveground systems or with shallow footprints can overcome the challenges associated with high ground water levels so that underdrain inverts are compatible with the surrounding drainage infrastructure.

**Table 5.4** presents several development types and BMPs that are generally appropriate to meet the requirements of the *Water Quality Rules* for the various priority project types.

Source Control Harvest/Reuse Manufactured **Bio-filtration** Green Roof Permeable Pavement<sup>1</sup> Infiltration Treatment **Priority Development Type** Н Η Η  $NR^1$ Η M Η Single Family Residential Α Commercial/Institutional/Mixed Use Η Η  $M^1$ Η Η Η Η Parks and Open Space Η Η N/A Η N/A M N/A High Density/Ultra-urban, Buildings Greater than  $M^2$ A or B Η Η Η Η Η Η 100 feet tall, Retail Malls A or B Parking Lots Η Η N/A Η N/A Η Η Industrial, Automotive Repair Shops, Restaurants,  $M^3$ В  $M^3$ M Η M Η Η

**Table 5.4: Recommended Selection of Permanent BMPs** 

H= Highly Appropriate; M= May be Appropriate; NR= Not Recommended; N/A= Not Applicable

Retail Gasoline Outlets

### 5.1.4. Consider Operation and Maintenance Requirements

Once BMPs have been selected based on performance and appropriateness for site conditions, both installation cost and operation and maintenance cost can become an important differentiator in BMP selection. Treatment Control BMP costs vary depending on the type of BMP installed. **Table 5.5** shows maintenance costs compiled by the County of San Diego which looked at the maintenance time and costs for large, medium, and small BMPs. In general, the more time consuming maintenance resulted in higher costs. While permanent BMP maintenance is the responsibility of the owner, the City recommends that BMPs be chosen with consideration to maintenance requirements when possible. For instance, underground vault-type devices may provide valuable space savings, but there are concerns that regular maintenance will not be provided, as well as the worker safety and public safety risks presented during maintenance activities.

Table 5.5: Summary of Operation and Maintenance Effort for BMPs

ВМР	Small BMP		Mediu	n BMP	Large BMP		
	Annual Hours	Annual Cost	Annual Hours	Annual Cost	Annual Hours	Annual Cost	
Bioretention Area	32.0	\$ 3,174	44.0	\$ 4,078	68.0	\$ 5,877	
Flow-Through Planter	24.0	\$ 2,367	30.0	\$ 2,882	42.0	\$ 3,781	
Cistern With Bioretention	33.2	\$ 3,186	38.2	\$ 3,505	48.2	\$ 4,255	
Dry Detention Basin with Grass/ Vegetated Lining	25.8	\$ 2,433	32.6	\$ 3,204	53.0	\$ 4,734	

Source: San Diego Stormwater Urban Mitigation Plan website: http://www.sandiegocounty.gov/content/dam/sdc/dpw/WATERSHED PROTECTION PROGRAM/susmppdf/bmp om cost 2012.xlsx. Costs in Hawaii may be higher.

<sup>1.</sup> Green roofs are not recommended for single family homes.

<sup>2.</sup> High density/ultra-urban redevelopment projects may frequently encounter space constraints and high ground water levels which may limit the appropriateness or feasibility of infiltration BMPs.

<sup>3.</sup> Infiltration BMPs are not recommended for areas with high potential for concentrated pollutants or chemical spills. Source Control BMPs should be implemented in those areas.

Table 5.5: Summary of Operation and Maintenance Effort for BMPs (Continued)

ВМР	Small	BMP	IP Medium BMP		Large	BMP
	Annual Hours	Annual Cost	Annual Hours	Annual Cost	Annual Hours	Annual Cost
Dry Detention Basin with Impervious Lining	15.8	\$ 1,412	20.6	\$ 2,067	35.0	\$ 3,147
Underground Vault	19.8	\$ 1,819	24.6	\$ 2,418	39.0	\$ 3,498
Cistern	15.2	\$ 1,423	17.2	\$ 1,830	23.2	\$ 2,280
Infiltration Basin	28.6	\$ 2,679	33.0	\$ 3,297	46.2	\$ 4,287
Infiltration Trench	17.8	\$ 1,564	25.0	\$ 2,418	46.6	\$ 4,037
Wet Pond/Basin (Permanent Pool)	113.8	\$ 10,037	214.6	\$ 17,081	517.0	\$ 39,752
Constructed Wetland	109.8	\$ 9,708	210.6	\$ 16,763	513.0	\$ 39,433
Vegetated Swale	15.3	\$ 1,476	20.9	\$ 2,203	26.5	\$ 2,623
Austin Sand Filter	19.6	\$ 1,712	24.4	\$ 2,374	38.8	\$ 3,454
Delaware Sand Filter	19.6	\$ 1,712	24.4	\$ 2,374	38.8	\$ 3,454
Multi-Chambered Treatment Train	27.9	\$ 2,587	32.7	\$ 3,114	47.1	\$ 4,194
Tree-Pit-Style Unit	15.6	\$ 1,491	15.6	\$ 1,491	15.6	\$ 1,491
Vault Based Filtration with Replaceable Cartridges	23.8	\$ 2,050	28.6	\$ 2,690	43.0	\$ 3,769
Swirl Concentrator	15.0	\$ 2,062	15.0	\$ 2,062	15.0	\$ 2,062
Catch Basin Insert	15.0	\$ 1,493	15.0	\$ 1,493	15.0	\$ 1,493
Catch Basin Insert with Hydrocarbon Boom	17.0	\$ 1,707	17.0	\$ 1,707	17.0	\$ 1,707
Permeable Pavements	7.8	\$ 808	13.6	\$ 1,206	23.2	\$ 1,926
Self-Retaining	6.8	\$ 598	6.8	\$ 598	6.8	\$ 598
Vegetated Roof	17.0	\$ 1,975	21.0	\$ 2,252	33.0	\$ 3,152

Source: San Diego Stormwater Urban Mitigation Plan website: http://www.sandiegocounty.gov/content/dam/sdc/dpw/WATERSHED\_PROTECTION\_PROGRAM/susmppdf/bmp\_om\_cost\_2012.xlsx. Costs in Hawaii may be higher.

For the purpose of this document, the average annual maintenance time for a BMP device used to determine the Maintenance Ranks are defined in **Table 5.6**. These maintenance ranks are specified on each treatment control fact sheet (**Appendix B**).

**Table 5.6: Maintenance Rank Definition** 

Maintenance Rank	Definition
Low	BMPs with an average maintenance requirement of less than 25 hours per year.
Medium	BMPs with an average maintenance requirement of between 25 and 50 hours per year.
High	BMPS with an average maintenance requirement of over 50 hours per year.

Long-term O&M guidelines are presented in Section 7.

### 5.1.5. Other Considerations

### **Vector Breeding Considerations**

The potential of a BMP to create vector breeding habitat and/or harborage should also be considered when selecting BMPs. Mosquito and other vector production is a nuisance and public health threat.

Mosquitoes can breed in standing water almost immediately following a BMP installation and may persist at unnaturally high levels and for longer seasonal periods in created habitats. BMP siting, design, construction, and maintenance must be considered in order to select a BMP that is least conducive to providing habitat for vectors. Tips for minimizing vector-breeding problems in the design and maintenance of BMPs are presented in the BMP fact sheets. Certain BMPs, including ponds and wetlands and those designed with permanent water sumps, vaults, and/or catch basins (including below ground installations), may require routine inspections and treatments.

### Threatened and Endangered Species Considerations

The presence or potential presence of threatened and endangered species should also be considered when selecting BMPs. Although preservation of threatened endangered species is crucial, treatment BMPs are not intended to supplement or replace species habitat except under special circumstances. The presence of threatened or endangered species can hinder timely and routine maintenance, which in turn can result in reduced BMP performance and an increase in vector production. In extreme cases, rights to the treatment BMP and surrounding land may be lost if threatened or endangered species utilize or become established in the BMP.

When considering BMPs where there is a presence or potential presence of threatened or endangered species, early coordination with DLNR and USFWS is essential. During this coordination, the purpose and the long-term operation and maintenance requirements of the BMPs need to be clearly established through written agreements or memorandums of understanding. Absent firm agreements or understandings, proceeding with BMPs under these circumstances is not recommended.

#### 5.2. **Numeric Sizing Criteria**

Based on the selected BMPs, the capacity and primary design sizing criteria must be established using a combination of local hydrology, project drainage characteristics (i.e., percent imperviousness or runoff coefficient), and numerical sizing requirements. BMPs will be volume-based, flow-based, or demandbased, and must be able to effectively treat the design quantity. Peak storm event flows must also be taken into account if the BMP is a flow-based BMP, or a volume-based BMP that must also safely pass the design storm (i.e., an in-line detention basin).

This section presents the methodology for calculating the WQV and WQF Rate, which are used to size the majority of the Treatment Control BMPs. Calculations for the WQV and WQF should not include DMAs that are considered Self-Mitigating (refer to Site Design Strategies).

### 5.2.1. Volume-Based Best Management Practice Design

Volume-based BMP design standards apply to BMPs whose primary mode of pollutant removal depends on the volumetric capacity of the BMP. Examples of BMPs in this category include detention basins, retention basins, and infiltration. Typically, a volume-based BMP design criteria calls for the capture and infiltration or treatment of a certain percentage of the runoff from the project site.

Revised: July 2017

The WQV is calculated using the following equation:

```
WQV = PCA \times 3630
Where WQV = Water Quality Design Volume [cubic feet (cu-ft)]
P = Design Storm Runoff Depth (in)
C = Volumetric Runoff Coefficient
```

A = Tributary Drainage Area (acres)

As specified in the *Water Quality Rules*, a design storm runoff depth of 1 inch shall be used for LID retention BMPs and 1.5 inches shall be used for all treat and release BMPs including LID biofiltration and alternative compliance BMPs. In previous analysis, the City determined that the 1-inch design storm was equal to or exceeded the 24-hr 85th percentile storm for most of Oahu.

The volumetric runoff coefficient shall be calculated using the following equation as developed by USEPA for smaller storms in urban areas:

$$C = 0.05 + 0.009I$$

Where C = Volumetric Runoff Coefficient I = Percent of Impervious Cover (percent)

A graph presenting the relationship between the percent of impervious cover and the unit water quality design volume for a 1-inch and 1.5-inch runoff depth is shown in **Figure 5.2**.




Figure 5.2: Unit Water Quality Volume for 1 and 1.5 inch Runoff Depth

### 5.2.2. Flow-Based BMP Design

Flow-based BMP design standards apply to BMPs whose primary mode of pollutant removal depends on the rate of flow of runoff through the BMP. Examples of BMPs in this category include swales, screening devices, and many proprietary products. Typically, flow-based BMP design criteria calls for the capture and infiltration or treatment of the flow runoff produced by rain events of a specified magnitude.

The design WQF rate is calculated using the Rational Formula:

$$WQF = 1.5 \times CiA$$

Where WQF = Water Quality Design Flow Rate (cu-ft/sec)

C = Runoff Coefficient

i = Peak Rainfall Intensity (in/hr) A = Tributary Drainage Area (acres)

As specified in the *Water Quality Rules*, a peak rainfall intensity of 0.4 inches per hour shall be used. The runoff coefficient shall be determined from **Table 5.7**. For drainage areas containing multiple land uses, the following formula may be used to compute a composite weighted runoff coefficient:

$$C_{c} = (\sum_{i=1}^{n} C_{i} A_{i}) / A_{t}$$

Where  $C_C$  = Composite Weighted Runoff Coefficient

C<sub>1,2,..n</sub> = Runoff Coefficient for each Land Use Cover Type

 $A_{1,2,..n}$  = Drainage Area to each Land Use Cover Type (acres)

A<sub>t</sub> = Total Drainage Area (acres)

**Table 5.7: Runoff Coefficients for Water Quality Flow Calculations** 

Type of Drainage Area	<b>Runoff Coefficient</b>	Type of Drainage Area	Runoff Coefficient
Roofs	0.90	Permeable interlocking concrete pavement	0.10
Concrete	0.80	Grid pavements with grass or aggregate surface	0.10
Stone, brick, or concrete pavers with mortared joints and bedding	0.80	Crushed aggregate	0.10
Asphalt	0.70	Grass	0.10
Stone, brick, or concrete pavers with sand joints and bedding	0.70	Grass over Porous Plastic	0.05
Pervious Concrete	0.10	Gravel over Porous Plastic	0.05
Porous asphalt	0.10		

Note that these C-factors are only appropriate for small storm treatment design and are not appropriate for flood control facilities.

A graph presenting the relationship between the weighted runoff coefficient and the unit water quality design flow rate is shown in **Figure 5.3**.



Figure 5.3: Unit Water Quality Flow

### 5.2.3. Combined Volume-Based and Flow-Based BMP Design

Volume-based BMPs and flow-based BMPs do not necessarily treat precisely the same storm water runoff. For example, an on-line volume-based BMP such as a detention basin will treat the design runoff volume and is essentially unaffected by runoff entering the basin at an extremely high rate, say from a very short, but intense storm that produces the design volume of runoff. However, a flow-based BMP might be overwhelmed by the same short, but intense storm if the storm intensity results in runoff rates that exceed the flow-based BMP design flow rate. By contrast, a flow-based BMP such as a swale will treat the design flow rate of runoff and is essentially unaffected by the duration of the design flow, say from a long, low intensity storm. However, a volume-based detention basin subjected to this same rainfall land runoff event will begin to provide less treatment or will go into bypass or overflow mode after the design runoff volume is delivered.

Therefore, there may be some situations where designers need to consider both volume-based and flow based BMP design criteria. An example of where both types of criteria might apply is an off-line detention basin. For an off-line detention basin, the capacity of the diversion structure could be designed to comply with the flow-based BMP design criteria while the detention basin itself could be designed to comply with the volume-based criteria.

When both volume-based and flow based criteria apply, the designer should determine which of the criteria apply to each element of the BMP system, and then size the elements accordingly.

### 5.3. Infiltration Requirements

LID Retention BMPs rely on the soil's ability to infiltrate storm water runoff. This section outlines the design requirements applicable to all infiltration facilities.

### 5.3.1. Soil Types and Textures

The soil types within the subsoil profile, extending a minimum of 3 ft below the bottom of the proposed facility, should be identified to verify the infiltration rate or permeability of the soil. The infiltration

rate, or permeability, measured in inches per hour, is the rate at which water passes through the soil profile during saturated conditions. Although the units of infiltration rate and hydraulic conductivity of soils are similar, there is a distinct difference between these two (2) quantities. They cannot be directly related unless the hydraulic boundary conditions are known, such as hydraulic gradient and the extent of lateral flow of water, or can be reliably estimated. Minimum and maximum infiltration rates establish the suitability of various soil textural classes for infiltration. Each soil texture and corresponding hydrologic properties within the soil profile are identified through analysis of a gradation test of the soil boring material. **Table 5.8** presents a list of the infiltration rates for the soil textures of the U.S. Department of Agriculture (USDA) Textural Triangle, presented in **Figure 5.4**.

Table 5.8: Typical Soil Infiltration Rates<sup>a</sup>

Texture Class	Hydrologic Soil Group	Infiltration Rate (inches/hour)			
Sand	A	8.00			
Loamy Sand	A	2.00			
Sandy Loam	В	1.00			
Loam	В	0.50			
Silt Loam	С	0.25			
Sandy Clay Loam	С	0.15			
Clay Loam	D	0.09			
Silt Clay Loam	D	< 0.09			
Clay	D	< 0.05			
a - Source: ASCE, 1998					



Figure 5.4: USDA Soils Textural Triangle

Soil textures acceptable for use with infiltration systems include those with infiltration rates equal to or above 0.50 inches per hour (a soil texture indicative of loam). Soil textures with rates less than 0.50 inches per hour are not suitable as it increases the risk of the BMP not draining properly and creating localized areas of standing water. It is important to note however, that Hydrologic Soil Group (HSG) "D" soils (e.g., clay loam, silty clay loam, and silty clay) in Oahu have been shown to perform better than their counterparts in the Continental United States. As a result, locations with HSG "D" soils should not be automatically rejected as candidate sites for infiltration BMPs without the opinion of a licensed professional engineer with geotechnical expertise.

### 5.3.2. Field Investigations

According to the *Water Quality Rules*, infiltration can be considered infeasible if the soil at the site is HSG "C" or "D," or if the infiltration rate is less than 0.5 in/hr. For HSG "A" and "B" soils, and those sites who wish to use infiltration even with HSG C or D soils, soil investigations and infiltration tests are required for infiltration facilities to accurately determine the local soil characteristics and capacity for infiltration.

### Soil Lithology and Depth to Groundwater

An initial soil investigation is recommended to adequately evaluate soil lithology and determine if there are potential problems in the soil structure that would inhibit the rate or quantity of infiltration desired; or if there are potential adverse impacts to structures, slopes or groundwater that could result from locating the device nearby.

Geotechnical test pits or borings should be dug to a minimum of 5 ft deep below the proposed device invert, or as determined by the licensed professional engineer with geotechnical expertise. A test pit allows visual observation of the soil horizons and overall soil conditions both horizontally and vertically in that portion of the site. Although the use of soil borings is permitted at the recommendation of a geotechnical professional, it is discouraged as a substitute for test pits as visual observation is narrowly limited in a soil boring and the soil horizons cannot be observed in-situ, but must be observed from the extracted borings.

The soil profiles should be carefully logged to determine variations in the subsurface profile. Samples should be collected from the soil profiles at different horizons and transported to a laboratory for soil indices testing, plasticity, and chemical testing. In addition, the test pits or samples from borings should be examined for other characteristics that may adversely affect infiltration. These include evidence of significant mottling (indicative of high groundwater), restrictive layer(s), and significant variation in soil types, either horizontally or vertically.

An initial indication of the seasonal high groundwater water table elevation should be determined by using a piezometer or other accepted geotechnical means. The piezometer should be installed to a depth of at least 20 ft below the proposed device invert using the direct push or other suitable method. Initial groundwater levels shall be recorded at least 24 hrs after installation. The geotechnical professional will make a determination whether the groundwater elevation determined after 24 hrs can be considered to be a reasonable indication of the seasonal high water table for the site.

### **Permeability Testing**

Infiltration rate tests are used to help estimate the maximum sub-surface vertical infiltration rate of the soil below a proposed infiltration facility (e.g., infiltration trench or infiltration basin). The tests are intended

to simulate the physical process that will occur when the facility is in operation; therefore a saturation period is required to approximate the soil moisture conditions that may exist prior to the onset of a runoff event. Laboratory tests are strongly discouraged, as a homogeneous laboratory sample does not represent field conditions. Infiltration tests should be conducted in the field. Tests should not be conducted in the rain or within 24 hrs of significant rainfall events (greater than 0.5 inches).

There are a variety of infiltration field test methodologies to determine the infiltration rate of a soil, the two most coming being the Falling Head Percolation Test and the Double-Ring Infiltrometer Test. The actual testing protocols and methods used for a specific project should be determined by a licensed professional engineer with geotechnical expertise.

	Facility	Recommended # of Permeability Tests
•	Infiltration Basin	1 test per 2,500 sq-ft
•	Subsurface Infiltration	
•	Dry Well	
•	Bioretention Basin	
•	Permeable Pavement	
•	Infiltration Trench	1 test per 100 linear ft

Table 5.9: Test Pit/Boring Requirements for Infiltration

### 5.3.3. Design Infiltration Rates

To account for uncertainties and inaccuracies in testing, a correction (i.e., safety) factor shall be applied to the assumed or measured infiltration rate to produce a design infiltration rate for BMP sizing calculations. The minimum safety factor for infiltration facilities is 2.

### **5.4.** Technology Certification

This manual does not endorse specific proprietary products, although many are described. It is left to each developer to determine which proprietary products may be used, and under what circumstances. When considering a proprietary product, the *Water Quality Rules* require that the developer consider performance data, determined by established protocols. The City accepts certifications of product performance by the Washington State Department of Ecology [Technology Assessment Protocol- Ecology (TAPE)], for the New Jersey's Department of Environmental Protection [New Jersey Corporation for Advanced Technology (NJCAT)].

For proprietary biofiltration systems, the BMP must be certified for general use by TAPE for Enhanced Treatment (for the treatment of dissolved metals), Phosphorous Treatment, or Oil Treatment, according to the predominant pollutant(s) of concern at that site.

For alternative compliance, the device must provide, at minimum, a TSS removal rate of 80%, certified for general use by TAPE or verified by NJCAT consistent with the New Jersey Department of Environmental Protection (NJDEP) protocols.

It can be expected that subsequent to the publishing of this manual, new public-domain technologies will be proposed (or design criteria for existing technologies will be altered) by development engineers. As with proprietary products, it is advised that new public-domain technologies be considered only if performance data are available and have been collected following a widely accepted protocol.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

### 5.5. Feasibility Criteria

Individual BMPs may not be feasible at the site due to site constraints or activities. The City specified feasibility criteria for each BMP in an effort to protect ground water quality, archaeological resources, facilities from inadequate drainage, and avoid compromising the geotechnical/structural integrity of surrounding properties. Infeasibility must be documented using the Feasibility Screening Worksheet (Appendix F of the *Water Quality Rules*).

### 5.5.1. Infiltration Feasibility

Infiltration BMPs are infeasible and must not be used if any of the following conditions are met:

- 1. Soils beneath the BMP invert have measured infiltration rates of less than 0.5 in/hr or are USDA HSG "C" or "D" as reported by the USDA Natural Resources Conservation Service.
- 2. The seasonally high groundwater table is within 3 ft from the BMP invert.
- 3. There is a documented concern that there is a potential onsite for soil pollutants, ground water pollutants, or pollutants associated with industrial activities to be mobilized.
- 4. There are geotechnical concerns at the site.
- 5. Excavation for the installation of the BMP would disturb iwi kupuna or other archeological resources.
- 6. The BMP cannot be built within the following setbacks:

Distance	From the nearest		
10 ft	private property line		
20 ft	building foundation at the project site		
35 ft	septic system		
50 ft	drinking water well		
100 ft	down-gradient building foundation		

### 5.5.2. Harvest/Reuse Feasibility

Harvest/Reuse is considered infeasible for the any of the flowing reasons:

- 1. The demand is inadequate to reuse the required volume of water.
- 2. The technical requirements cause the harvesting system to exceed 2% of the total project cost.
- 3. The site where a cistern must be located is at a slope greater than 10%.
- 4. There is no available space to locate a cistern of adequate size to harvest and use the required amount of water.
- 5. The cistern cannot be built within the following setbacks:

Distance	From the nearest
5 ft	private property line or building foundation
10 ft	septic system


6. The project includes a reclaimed water system and demand for a harvest/reuse system cannot be met.

### 5.5.3. Biofiltration Feasibility

Biofiltration BMPs must be evaluated individually for feasibility as each has different applications. Only if all biofiltration BMPs are infeasible can alternative compliance be used.

- 1. Vegetated Biofilters are infeasible for any of the following reasons:
  - a. Excavation would disturb iwi kupuna or other archaeological resources.
  - b. The invert of underdrain layer is below seasonally high groundwater table.
  - c. The site does not receive enough sunlight to support vegetation.
  - d. The site lacks sufficient hydraulic head to support BMP operation by gravity.
  - e. Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.
- 2. Green Roofs are infeasible for any of the following reasons:
  - a. The roof is for a single family residential dwelling.
  - b. Roof space is unavailable due to renewable energy, electrical, and/or mechanical systems.
  - c. Slope on roof exceeds 25% (14 degrees).
- 3. Dry Swales or Enhanced Swales are infeasible for any of the following reasons:
  - a. Excavation would disturb iwi kupuna or other archaeological resources.
  - b. The invert of underdrain layer is below seasonally high groundwater table.
  - c. The site lacks sufficient head to support BMP operation by gravity.
  - d. Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.
- 4. Vegetated Swales are infeasible for any of the following reasons:
  - a. The excavation would disturb iwi kupuna or other archaeological resources.
  - b. The site does not receive enough sunlight to support vegetation.
  - c. Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.
- 5. Vegetated filter strips are infeasible for any of the following reasons:
  - a. Excavation would disturb iwi kupuna or other archaeological resources.
  - b. The site does not receive enough sunlight to support vegetation.
  - c. Unable to operate off-line with bypass and unable to operate in-line with safe overflow mechanism.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017



## 6. Considerations for Construction **Treatment Control BMPs**

As described in Section 1 of this document, the Water Quality Rules requires that a licensed engineer inspect BMPs during construction and must certify that they were built according to plan. Precautions must be taken during construction to ensure that permanent BMPs are installed as designed and function as intended.


The first and most important step in protecting permanent BMPs during construction is to utilize phasing to minimize the exposure of these structures to sediment. The following is a typical construction sequence. Depending on the BMP and design variation, alterations may be necessary. Note that Erosion and Sediment Control methods must adhere to the Water Quality Rules requirements throughout the duration of construction.

- 1. Protect future infiltration areas from compaction prior to installation. Clearly mark the existing vegetated areas to be preserved and future infiltration facilities with flags or temporary fencing.
- 2. Stabilize the entire area draining to the infiltration facility before construction of the infiltration facility begins. Or, construct a diversion berm around the perimeter of the infiltration site to prevent sediment transport during construction.
- 3. Excavate Structural Infiltration facilities to a uniform, level, uncompacted subgrade, free from rocks and debris. Excavation should be performed with the lightest practical equipment and should be placed outside the limits of the infiltration facility. If the use of heavy equipment on the base of the facility cannot be avoided, the infiltrative capacity must be restored by soil amendments or aerating prior to placing the infiltrative bed.
- 4. Complete final grading to achieve proposed design elevations, leaving space for upper layer of compost, mulch or topsoil as specified on plans.
- 5. Plant vegetation according to planting plan. Erosion and sediment control measures, such as temporary seeding and erosion control mats, should be used on vegetated slopes if appropriate.
- 6. Where pervious pavement is to be installed, installation of the pavement shall be scheduled as the last installation at a development site. Vehicular traffic should be prohibited for at least two (2) days following installation. Site materials should not be stored on pervious pavement.
- 7. Continue to use erosion and sediment control BMPs such as inlet protection and perimeter control to protect permanent BMPs until they are ready to be brought online. Once the drainage area is completely and permanently stabilized, the system can be brought online.
- 8. Consider re-verifying permeability prior to acceptance of the BMP.

For proprietary systems, the City recommends to follow manufacturers' installation guidelines while applying the basic principles outlined above.

Guidance on maintenance of BMPs after construction is presented in Section 7.

Revised: July 2017



### 7. Operations and Maintenance of BMPs

Once built, BMPs require ongoing, long-term inspection and maintenance to ensure that BMPs are meeting the specified design criteria for storm water flow rate, volume and water quality. If the BMPs are not properly maintained the effectiveness of the BMP decreases and may impact water quality. Routine maintenance will also help avoid more costly rehabilitative maintenance to repair damages that may occur when BMPs have not been adequately maintained on a regular basis. For these reasons, the City requires project applicants to develop and record an O&M Plan as part of the permitting process.

### 7.1. Consideration when Selecting Treatment BMPs

The long-term performance of BMPs hinges on ongoing and proper maintenance. Consideration of the time and funding necessary to support long term maintenance should be included as part of the process when selecting treatment BMP(s). Maintenance costs will also include disposal of accumulated residuals. Residuals include trash, oil and grease, filter media and fine sediments.

### 7.1.1. Sediment and Oil Removal and Disposal

Over time, BMPs will accumulate sediment, which will need to be removed to prevent clogging and reduction in effectiveness. Routine maintenance activities need to include measuring the depth of sediment as part of routine maintenance events and included in the maintenance log. Sediment should be removed when sediment accumulation reaches thirty (30) percent of total capacity. Thirty (30) percent of a facility's capacity is calculated by multiplying the total capacity by 0.30.

Some facilities may require professional assistance, such as underground facilities and manufactured facilities that have confined spaces. These types of facilities require proper certifications to enter or must be cleaned by a vactor truck. Vacuuming with a vactor truck or street sweeping equipment may be required for certain components, such as collection basins, piping or pervious pavement systems.

The owner is responsible for properly disposing accumulated residuals. Current research generally indicates that residuals are not hazardous wastes and can be disposed of residuals the same way any uncontaminated soil would be dispose of, following dewatering. If the BMP treats runoff from areas where chemical or hazardous wastes could come into contact with storm water and an oily sheen, odor, discoloration or other signs of pollution is observed, hire a professional laboratory or sampling firm to assess whether the material needs specialized hauling, treatment, or disposal. If you need assistance deciding whether the solids must be managed as hazardous waste, contact the City Department of Environmental Services - Solid Waste Division.

#### 7.1.2. Maintenance Costs

Storm Water BMP Guide for New and Redevelopment

The City requires the applicant to include a description of the funding mechanism for long-term operation and maintenance in the SWQR. For homeowner associations, this could be a portion of homeowner fees or a specific assessment.

Revised: July 2017

Maintenance costs need to include both routine (i.e., inspection, debris removal, or vegetation management) and non-routine (i.e., sediment removal, facility component repair/replace or major replanting) maintenance activities. The annual routine maintenance costs are typically between five (5) to ten (10) percent of the facility's total capital cost. For non-routine maintenance costs (i.e.: sediment removal or vegetative replacement), the owner should set aside a percentage of the non-routine maintenance costs per year based on the needed frequency. For example, if the facility needs sediment removal every five (5) years, twenty (20) percent of the total cost for sediment removal must be put aside each year. An additional three (3) to five (5) percent of the capital costs should also be incorporated into the overall maintenance costs for eventual facility replacement. The life expectancy for most treatment BMPs is between twenty-five (25) to fifty (50) years. The owner is responsible for replacing BMPs at the end of their lifecycle.

### 7.2. Developing the O&M Plan

Detailed O&M plans are required under the *Water Quality Rules* Section (§) 20-3-53. The O&M Plan is required to identify the specific maintenance activities and frequencies for each type of BMP. In addition, these should include indicators for assessing when "as needed" maintenance activities are required.

An O&M plan should be prepared by the project proponents and submitted to the DFM Storm Water Quality Branch (SWQ) prior to closure of any building, grading, grubbing, trenching, or stockpiling permits for Priority A and B projects.

The Water Quality Rules require the following as part of the O&M Plan

- Name, phone number and mailing address for the owner of the property.
- Name and phone number for the individual(s), association, or management company responsible ensuring maintenance is being performed.
- Maintenance activities for each BMP.
- Inspection frequencies for each BMP.
- A post-construction BMP plan showing the location of each BMP with a summary of the maintenance activities and inspection schedule for each BMP.

An O&M Template is available from the CCH and is available on their website. General maintenance activities and frequencies that should be included in the O&M plan are provided in **Appendix C**.

### 7.3. Maintenance Agreements, Certification, and Modifications

An O&M plan is particularly valuable during ownership transitions; for example, when a developer transitions maintenance to a homeowners association, or when a developer turns over maintenance to a new owner. The BMP maintenance plan is also important when evaluating properties for acquisition, allowing long-term costs associated with BMPs to be factored into the property purchase agreement.

Because of the long-term nature of these BMPs, the City requires that the BMP plan and O&M plan be recorded in the State of Hawaii Land Court or Bureau of Conveyances for privately-owned Real Property. A copy of the recorded O&M plan shall be submitted to the Department and Director of the DFM prior to closing the building and/or grading, grubbing, stockpiling or trenching permit(s).

Another valuable factor for ensuring BMP effectiveness is ensuring the BMP is installed according to plan. The City requires the owner to retain/hire a Licensed Engineer in the State of Hawaii and certified

by the DPP to observe the installation of BMPs during construction and submit a signed Certificate of Completion Form to the City prior to closing the building and/or grading, grubbing, stockpiling or trenching permit(s).

Any modifications to the O&M plan after permit closure must be approved by DFM. Modifications to the O&M plan will not be accepted if it reduces the level of protection from pollutant discharge.

### 7.4. Inspection Requirements

The owner is responsible for operation and maintenance inspections under the *Water Quality Rules*. The owner is required, at a minimum, to conduct an annual inspection of the installed BMP(s) and retain maintenance and inspection records for at least five (5) years. Furthermore, the owner is required to allow the City access to the BMPs for annual inspections to confirm compliance with the approved O&M plan.

The actual maintenance needs may be more frequently than annually. The need for maintenance depends on the type of BMP, amount and quality of runoff delivered to the structural BMP and any pretreatment facilities for that BMP. Maintenance should be performed on a routine basis and whenever needed, based on maintenance indicators. The optimum maintenance frequency is each time the maintenance threshold for removal of materials (sediment, trash, debris or overgrown vegetation) is met. If this maintenance threshold has been exceeded by the time the structural BMP is inspected, the BMP has been operating at reduced capacity. This would mean it is necessary to inspect and maintain the structural BMP more frequently.

During the first year of normal operation of a structural BMP (i.e., when the project is fully built out and occupied), inspection by the property owner's representative is recommended at least monthly. Inspection during a storm event is also recommended. It is during and after a rain event when one can determine if the components of the BMP are functioning properly. The inspection and maintenance frequency can be adjusted, based on the results of the inspections performed during the first year.

### 7.5. Minimum Maintenance Requirements

There are many different variations of structural BMPs, and structural BMPs may include multiple components. For the purpose of maintenance, the structural BMPs have been grouped into categories based on common maintenance requirements. The following fact sheets are available in **Appendix** C:

- Bioretention Basin
- Detention Basin
- Green Roof
- Infiltration Trench/Basin
- Manufactured Treatment Device
- Pervious Pavement
- Rainwater Harvesting
- Sand Filter
- Vegetated Biofilter
- Vegetated Swale/Strip

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

The project civil engineer is responsible for tailoring the maintenance activities and frequency based on the components of the structural BMP, and identifying the applicable maintenance indicators. The factsheets are intended to be general guidance and are meant to help prepare the maintenance plan, more explicit maintenance activities may be necessary to ensure proper operation and maintenance.

### 8. References


- Alameda Countywide Clean Water Program. www.cleanwaterprogram.org/businesses home.htm
- Arizona Department of Transportation. 2009. *ADOT Post-Construction Best Management Practices Manual*. http://www.azdot.gov/inside\_adot/OES/Water\_Quality/Stormwater/Manuals.asp
- ASCE. 1998. Urban Runoff Quality Management, Manual and Report of Engineering Practice 87. Reston, Virginia.
- Atlanta Regional Commission. 2001. *Georgia Stormwater Management Manual, Volume 2: Technical Handbook.* http://www.georgiastormwater.com/
- California Stormwater Quality Association. 2003. *Stormwater Best Management Practice Handbook, Industrial and Commercial*. http://www.cabmphandbooks.com/
- California Stormwater Quality Association. 2003. *Stormwater Best Management Practice Handbook, New Development and Redevelopment*. http://www.cabmphandbooks.com/
- City and County of Honolulu. 2012. *Green Infrastructure for Homeowners*. https://www.honolulu.gov/rep/site/dfmswq/library/Green\_Infrastructure\_for\_Homeowners-FINAL.pdf
- City and County of Denver. 2013. *Storm Drainage Design and Technical Criteria*. https://www.denvergov.org/Portals/711/documents/StormMasterPlan/StormDrainageDesignTechnicalCriteria.pdf
- City of Boulder, Colorado. Partners for a Clean Environment. www.bouldercolorado.gov/www/pace/government/index.html
- City of Los Angeles, California. Stormwater Program, Best Management Practices for Businesses and Commercial Industries. www.lastormwater.org/Siteorg/businesses/bmpbusiness.htm
- County of Maui, Hawaii, Document Center, Department of Water. Water Resource Planning Division. www.co.maui.hi.us/DocumentCenterii.aspx
- County of Orange, California. OC Watersheds Industrial/Commercial Businesses Activities. www. ocwatersheds.com/IndustrialCommercialBusinessesActivities.aspx
- County of Santa Barbara, California. Storm Water Management Program. www.sbprojectcleanwater.org/swmp.html
- County of Suffolk, New York. Stormwater Management Program. www.co.suffolk.ny.us/stormwater/bmps businesses.html

- City of Long Beach Development Services. 2012. Low Impact Development (LID) Best Management Practices (BMP) Design Manual. http://www.lbds.info/civica/filebank/blobdload. asp?BlobID=3855
- City of Portland. 2014. Stormwater Management Manual. http://www.portlandoregon.gov/bes/47952
- City of San Diego. 2016. Storm Water Standards. https://www.sandiego.gov/stormwater/regulations
- Clean Water Services. 2009. *Low Impact Development Approaches Handbook*. http://www.cleanwaterservices.org/Content/Documents/Permit/LIDA%20Handbook.pdf
- Connecticut Department of Environmental Protection. 2004. *Connecticut Stormwater Quality Manual*. http://ct.gov/dep/cwp/view.asp?a=2721&q=325704&depNav GID=1654
- County of Los Angeles Department of Public Works. 2014. *Low Impact Development (Standards Manual)*. http://dpw.lacounty.gov/DES/design\_manuals/
- County of San Diego Department of Public Works. 2012. *Operation and Maintenance Cost Table for Treatment Control BMPs*. http://www.sandiegocounty.gov/dpw/watersheds/susmp/susmp.html
- County of San Diego. 2014. Low Impact Development Handbook, Stormwater Management Strategies. http://www.sandiegocounty.gov/content/dam/sdc/dplu/docs/LID\_Handbook\_2014.pdf
- County of Santa Clara. 2012. *C.3. Stormwater Handbook*. http://www.scvurppp-w2k.com/c3\_handbook\_2012.shtml
- Ekern, P.C., and Chang, J.H. 1985. *Pan Evaporation: State of Hawaii, 1894-1983*. State of Hawaii, Department of Land and Natural Resources, Division of Water and Land Development.
- Idaho Department of Environmental Quality. 2005. Catalog of Stormwater Best Management Practices for Idaho Cities and Counties. http://www.deq.idaho.gov/water/data\_reports/storm\_water/catalog/
- Iowa State University Institute for Transportation. 2009. *Iowa Stormwater Management Manual*. http://www.intrans.iastate.edu/pubs/stormwater/index.cfm
- King County Department of Natural Resources and Parks. 2009. *King County, Washington Surface Water Design Manual*. http://www.kingcounty.gov/environment/waterandland/stormwater.aspx
- Maine Coastal Program, State Planning Office. 2007. *LID Guidance Manual for Maine Communities*. http://www.maine.gov/dep/blwq/docwatershed/materials.htm
- Maine Department of Environmental Protection. 2006. *Stormwater Management for Maine, Volume III BMPs Technical Design Manual*. http://www.maine.gov/dep/blwq/docstand/stormwater/stormwaterbmps/index.htm
- Maryland Department of the Environment. 2000. *Maryland Stormwater Design Manual*. http://www.mde.state.md.us/programs/Water/StormwaterManagementProgram/MarylandStormwaterDesignManual/
- New Hampshire Department of Environmental Services. 2008. *New Hampshire Stormwater Manual, Volume 2, Post-Construction Best Management Practices Selection and Design*. http://des.nh.gov/organization/divisions/water/stormwater/

- New Jersey Department of Environmental Protection, Division of Watershed Management. 2009. *New Jersey Stormwater Best Management Practices Manual*. http://www.state.nj.us/dep/stormwater/
- North Carolina State University. 2009. *Low Impact Development, A Guidebook for North Carolina*. http://www.ces.ncsu.edu/depts/agecon/WECO/lidguidebook/
- National Oceanic Atmospheric Association Coral Reef Conservation Program. 2014. Storm Water management in Pacific and Caribbean Islands: A practitioner's guide to Implementing LID. http://data.nodc.noaa.gov/coris/library/NOAA/CRCP/project/1906/Feb2014\_IslandBMPGuide\_wAppendix.pdf
- Pennsylvania Department of Environmental Protection. 2006. *Pennsylvania Stormwater Best Management Practices Manual*. http://www.elibrary.dep.state.pa.us/dsweb/View/Collection-8305
- Prince George's County, Maryland, Department of Environmental Resource. 1999. *Low Impact Development Design Strategies, An Integrated Design Approach*. http://www.lowimpactdevelopment.org/publications.htm
- Prince George's County, Maryland, Department of Environmental Resources. 2007. *Bioretention Manual*. http://www.princegeorgescountymd.gov/der/esg/bioretention/bioretention.asp
- Rawls, W. J., D. L. Brakensiek and K. E. Saxton. 1982. *Estimation of Soil Water Properties*. Transactions ASAE, 25(5)1316-1320, 1328.
- Riverside County Flood Control and Water Conservation District. 2006. *Riverside County Stormwater Quality Best Management Practice Design Handbook*. http://www.floodcontrol.co.riverside.ca.us/downloads/Planning/BMP%20Handbook%20(draft%208).pdf
- San Francisco Public Utilities Commission. *Rainwater Harvesting System Sizing Calculator*. http://sfwater.org/msc\_main.cfm/MC\_ID/17/MSC\_ID/404
- Southeast Michigan Council of Governments. 2008. Low Impact Development Manual for Michigan: A Design Guide for Implementers and Reviewers. http://www.semcog.org/lowimpactdevelopment.aspx
- State of California Department of Transportation. 2010. *Stormwater Quality Handbooks, Project Planning and Design Guide*. http://www.dot.ca.gov/hq/oppd/stormwtr/
- State of Hawaii, Department of Health, Wastewater Branch. 2009. *Guidelines for the Reuse of Gray Water*. http://hawaii.gov/wastewater/pdf/graywater\_guidelines.pdf
- State of Hawaii Department of Transportation. 2007. *Storm Water Permanent Best Management Practices Manual*. http://stormwaterhawaii.com/pdfs/PermanentManual.pdf
- State of Hawaii Office of Planning, Coastal Zone Management Program. 2006. *Hawaii Low Impact Development, A Practitioner's Guide*. http://hawaii.gov/dbedt/czm/initiative/lid.php
- State of New York Department of Environmental Conservation. 2010. New York State Stormwater Management Design Manual. http://www.dec.ny.gov/chemical/29072.html

- University of California Cooperative Extension, California Department of Water Resources. 2000. *A Guide to Estimating Irrigation Water Needs of Landscape Plantings in California*. http://www.water.ca.gov/wateruseefficiency/docs/wucols00.pdf
- University of Hawaii at Manoa, College of Tropical Agriculture and Human Resources. 2010. Guidelines on Rainwater Catchment Systems for Hawaii. http://www.ctahr.hawaii.edu/Site/PubList.aspx?key=Forest%20and%20Natural%20Resource%20Management
- Urban Drainage and Flood Control District. 2010. Urban Storm Drainage Criteria Manual, Volume 3 Best Management Practices. http://www.udfcd.org/downloads/down critmanual.htm
- U.S. Department of Agriculture, Natural Resources Conservation Service. 2006. *Soil Data Mart.* http://soildatamart.nrcs.usda.gov/
- U.S. Department of Commerce National Oceanic and Atmospheric Administration, National Climatic Data Center. 2002. *Climatography of the United States No. 81, Monthly Normals of Temperature, Precipitation, and Heating and Cooling Degree Days, 1971-2000, Hawaii.* http://cdo.ncdc.noaa.gov/cgi-bin/climatenormals/climatenormals.pl
- U.S. Environmental Protection Agency. 2004. Stormwater Best Management Practice Design Guide, Volume 2, Vegetative Biofilters. http://www.epa.gov/ORD/NRMRL/pubs0402.html
- U.S. Environmental Protection Agency. 2004. Stormwater Best Management Practice Design Guide, Volume 3, Basin Best Management Practices. http://www.epa.gov/ORD/NRMRL/pubs0402.html
- U.S. Soil Conservation Service. 1986. *Urban Hydrology for Small Watersheds, Technical Release 55*. http://www.wsi.nrcs.usda.gov/products/w2q/H&H/Tools Models/other/TR55.html
- Ventura Countywide Stormwater Quality Management Program. 2010. *Ventura County Technical Guidance Manual for Stormwater Quality Control Measures*. http://www.vcstormwater.org/technicalguidancemanual.html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 3, Grass Channels*. http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs.html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 5, Vegetated Roof.* http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs.html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 7, Permeable Pavement*. http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs. html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 8, Infiltration Practices*. http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs. html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 9, Bioretention*. http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs.html
- Virginia Department of Conservation and Recreation. 2011. *Virginia DCR Stormwater Design Specification No. 10, Dry Swales*. http://www.vwrrc.vt.edu/swc/NonProprietaryBMPs.html

- Washington State University Extension. 2012. Low Impact Development Technical Guidance Manual for Puget Sound. http://www.psp.wa.gov/downloads/LID/20121221 LIDmanual FINAL secure.pdf
- Western Regional Climate Center, National Oceanic and Atmospheric Administration. *Average Pan Evaporation Data by State*. http://www.wrcc.dri.edu/htmlfiles/westevap.final.html
- Western Regional Climate Center, National Oceanic and Atmospheric Administration. *Comparative Data for the Western States*. http://www.wrcc.dri.edu/htmlfiles/



# **Appendix A: Source Control BMP Fact Sheets**

This section describes specific Source Control (SC) BMPs to be considered for incorporation into newly developed public and private infrastructure, as well as retrofit into existing facilities to meet storm water management objectives.

Source Control BMPs are required for all Priority A and B projects for the following activities and areas:

- Landscaped Areas
- Automatic Irrigation Systems
- Storm Drain Inlets
- Vehicle/Equipment Fueling
- Vehicle/Equipment Repair
- Vehicle/Equipment Washing/Cleaning

- Loading Docks
- Outdoor Trash Storage
- Outdoor Material Storage
- Outdoor Work Areas
- Outdoor Process Equipment Operations
- Parking Areas


The following fact sheets are included in this guidance manual and recommended by CCH but are not required by the *Water Quality Rules*.

- Alternative Building Materials
- Roof Runoff Controls

The following information is provided for each of the above-listed BMPs:

- Brief Description/Approach
- Suitable Applications
- Design Considerations
- Design Guidelines
- Examples
- Operations & Maintenance Recommendations

A-1



## **SC-01: Landscaped Areas**



Design Objectives	
✓	Maximum Infiltration
✓	Provide On-Site Retention
✓	Slow Runoff
✓	Minimize Impervious Land Coverage
✓	Implement LID
	Prohibit Dumping of Improper Materials
	Contain Pollutants
	Collect and Convey

### **Description**

Each project site possesses unique topographic, hydrologic, and vegetative features, some of which are more suitable for development than others. Integrating and incorporating appropriate landscape planning methodologies into the project design is the most effective action that can be done to minimize surface and groundwater contamination from storm water.

### **Approach**

Landscape planning should couple consideration of land suitability for urban uses with consideration of community goals and projected growth. Project plan designs should conserve natural areas to the maximum extent possible, maximize natural water storage and infiltration opportunities, and protect slopes and channels.

### **Suitable Applications**

Appropriate applications include residential, commercial and industrial areas planned for development or redevelopment.

### **Design Considerations**

Design requirements for site design and landscapes planning should conform to applicable standards and specifications of agencies with jurisdiction and be consistent with applicable General Plan and Local Area Plan policies.

### Design Guidelines

- Conserve natural areas to the extent possible.
- Maximize natural water storage and infiltration opportunities to the extent possible.
- Limit runoff from landscaped areas to impervious areas.
- Protect slopes and channels.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

### **Designing New Installations**

Begin the development of a plan for the landscape unit with attention to the following general principles:

- Formulate the plan on the basis of clearly articulated community goals. Carefully identify conflicts and choices between retaining and protecting desired resources and community growth.
- Map and assess land suitability for urban uses. Include the following landscape features in the assessment: wooded land, open un-wooded land, steep slopes, erosion-prone soils, foundation suitability, soil suitability for waste disposal, aquifers, aquifer recharge areas, wetlands, floodplains, surface waters, agricultural lands, and various categories of urban land use. When appropriate, the assessment can highlight outstanding local or regional resources that the community determines should be protected (i.e., a scenic area, recreational area, threatened species habitat, farmland, fish run). Mapping and assessment should recognize not only these resources but also additional areas needed for their sustenance.

Project plan designs should conserve natural areas to the extent possible, maximize natural water storage and infiltration opportunities, and protect slopes and channels.

### Conserve Natural Areas during Landscape Planning

If applicable, the following items are required and must be implemented in the site layout during the subdivision design and approval process, consistent with applicable General Plan and Local Area Plan policies:

- Cluster development on least-sensitive portions of a site while leaving the remaining land in a natural undisturbed condition.
- Limit clearing and grading of native vegetation at a site to the minimum amount needed to build lots, allow access, and provide fire protection.
- Maximize trees and other vegetation at each site by planting additional vegetation, clustering tree areas, and promoting the use of native and/or drought tolerant plants.
- Promote natural vegetation by using parking lot islands and other landscaped areas.
- Preserve riparian areas and wetlands.

#### Maximize Natural Water Storage and Infiltration Opportunities within the Landscape Unit

- Promote the conservation of forest cover. Building on land that is already deforested affects
  basin hydrology to a lesser extent than converting forested land. Loss of forest cover
  reduces interception storage, detention in the organic forest floor layer, and water losses by
  evapotranspiration, resulting in large peak runoff increases and either their negative effects or the
  expense of countering them with structural solutions.
- Maintain natural storage reservoirs and drainage corridors, including depressions, areas
  of permeable soils, swales, and intermittent streams. Develop and implement policies and
  regulations to discourage the clearing, filling, and channelization of these features. Utilize them in
  drainage networks in preference to pipes, culverts, and engineered ditches.
- Evaluating infiltration opportunities by referring to the storm water management manual for the jurisdiction and pay particular attention to the selection criteria for avoiding groundwater contamination, poor soils, and hydro-geological conditions that cause these facilities to fail. If necessary, locate developments with large amounts of impervious surfaces or a potential to produce relatively contaminated runoff away from groundwater recharge areas.

A-4

### Protection of Slopes and Channels during Landscape Design

- Convey runoff safely from the tops of slopes.
- Avoid disturbing steep or unstable slopes.
- Avoid disturbing natural channels.
- Stabilize disturbed slopes as quickly as possible.
- Vegetated slopes with native or drought tolerant vegetation.
- Control and treat flows in landscaping and/or other controls prior to reaching existing natural drainage systems.
- Stabilize temporary and permanent channel crossings as quickly as possible, and ensure that increases in run-off velocity and frequency caused by the project do not erode the channel.
- Install energy dissipaters, such as riprap, at the outlets of new storm drains, culverts, conduits, or channels that enter unlined channels in accordance with applicable specifications to minimize erosion. Energy dissipaters shall be installed in such a way as to minimize impacts to receiving
- Line on-site conveyance channels where appropriate, to reduce erosion caused by increased flow velocity due to increases in tributary impervious area. The first choice for linings should be grass or some other vegetative surface, since these materials not only reduce runoff velocities, but also provide water quality benefits from filtration and infiltration. If velocities in the channel are high enough to erode grass or other vegetative linings, riprap, concrete, soil cement, or geo-grid stabilization are other alternatives.
- Consider other design principles that are comparable and equally effective.

### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. Redevelopment includes, but is not limited to:

- Expansion of a building footprint.
- Addition to or replacement of a structure.
- Replacement of an impervious surface that is not part of a routine maintenance activity.
- Land disturbing activities related to structural or impervious surfaces.

Redevelopment may present significant opportunity to add features which had not previously been implemented. Examples include incorporation of depressions, areas of permeable soils, and swales in newly redeveloped areas. While some site constraints may exist due to the status of already existing infrastructure, opportunities should not be missed to maximize infiltration, slow runoff, reduce impervious areas, and disconnect directly connected impervious areas.

### **O&M Recommendations**

- Do not use pesticides and fertilizers during wet weather or when rain is forecast, and minimize their use during dry weather.
- Do not blow or rake leaves, grass, or garden clippings into the street, gutter, or storm drain.
- Do not apply any chemicals (insecticide, herbicide, or fertilizer) directly to surface waters, unless the application is approved and permitted by the state.

Revised: July 2017

- Dispose of grass clippings, leaves, sticks, or other collected vegetation as garbage, or by composting. Do not dispose of collected vegetation into waterways or storm drainage systems.
- Use mulch or other erosion control measures on exposed soils.
- Check irrigation schedules so pesticides will not be washed away and to minimize non-storm water discharge.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County, Department of Public Works, May 2002.
- Stormwater Management Manual for Western Washington, Washington State Department of Ecology, August 2001.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.
- Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.

# **SC-02: Roof Runoff Controls**



	Design Objectives	
✓	Maximum Infiltration	
✓	Provide On-Site Retention	
✓	Slow Runoff	
	Minimize Impervious Land Coverage	
✓	Implement LID	
	Prohibit Dumping of Improper Materials	
✓	Contain Pollutants	
	Collect and Convey	

#### **Description**

Various roof runoff controls are available to address storm water that drains off rooftops. The objective is to reduce the total volume and rate of runoff from individual lots, and retain the pollutants on site that may be picked up from roofing materials and atmospheric deposition. Roof runoff controls consist of directing the roof runoff away from paved areas and mitigating flow to the storm drain system through one of several general approaches: cisterns or rain barrels; dry wells or infiltration trenches; green roofs (LID, see TC-07), pop-up emitters, and foundation planting. The first three (3) approaches require the roof runoff to be contained in a gutter and downspout system. Foundation planting provides a vegetated strip under the drip line of the roof.

#### **Approach**

Design of individual lots for single-family homes as well as lots for higher density residential and commercial structures should consider site design provisions for containing and infiltrating roof runoff or directing roof runoff to vegetative swales or buffer areas. Retained water can be reused for watering gardens, lawns, and trees. Benefits to the environment include reduced demand for potable water used for irrigation, improved storm water quality, increased groundwater recharge, decreased runoff volume and peak flows, and decreased flooding potential.

#### **Suitable Applications**

Appropriate applications include residential, commercial and industrial areas planned for development or redevelopment.

#### **Design Considerations**

#### **Designing New Installations**

Cisterns or Rain Barrels

One (1) method of addressing roof runoff is to direct roof downspouts to cisterns or rain barrels. A cistern is an above ground storage vessel with either a manually operated valve or a permanently open outlet. Roof runoff is temporarily stored and then released for irrigation or infiltration between storms. The number of rain barrels needed is a function of the rooftop area. Some low impact developers recommend that every house have at least two (2) rain barrels, with a minimum storage capacity of 1,000 liters. Roof barrels serve several purposes including mitigating the first flush from the roof which has a high volume, amount of contaminants, and thermal load. Several types of rain barrels are commercially available. Consideration must be given to selecting rain barrels that are vector proof and childproof. In addition, some barrels are designed with a bypass valve that filters out grit and other contaminants and routes overflow to a soak-away pit or rain garden.

If the cistern has an operable valve, the valve can be closed to store storm water for irrigation or infiltration between storms. This system requires continual monitoring by the resident or grounds crews, but provides greater flexibility in water storage and metering. If a cistern is provided with an operable valve and water is stored inside for long periods, the cistern must be covered to prevent mosquitoes from breeding.

A cistern system with a permanently open outlet can also provide for metering storm water runoff. If the cistern outlet is significantly smaller than the size of the downspout inlet (say ½ to ½ inch diameter), runoff will build up inside the cistern during storms, and will empty out slowly after peak intensities subside. This is a feasible way to mitigate the peak flow increases caused by rooftop impervious land coverage, especially for the frequent, small storms.

#### Dry Wells and Infiltration Trenches

Roof downspouts can be directed to dry wells or infiltration trenches. A dry well is constructed by excavating a hole in the ground and filling it with an open graded aggregate, and allowing the water to fill the dry well and infiltrate after the storm event. An underground connection from the downspout conveys water into the dry well, allowing it to be stored in the voids. To minimize sedimentation from lateral soil movement, the sides and top of the stone storage matrix can be wrapped in a permeable filter fabric, though the bottom may remain open. A perforated observation pipe can be inserted vertically into the dry well to allow for inspection and maintenance.

In practice, dry wells receiving runoff from single roof downspouts have been successful over long periods because they contain very little sediment. They should be sized according to the amount of rooftop runoff received, but are typically 4 to 5 sq-ft, and 2 to 3 ft deep, with a minimum of 1-ft soil cover over the top (maximum depth of 10 ft).

To protect the foundation, dry wells must be set away from the building at least 10 ft. The location of drywells should be determined by a licensed engineer. They must be installed in solids that accommodate infiltration. In poorly drained soils, dry wells have very limited feasibility. Overflow shall be directed away from the structure and surrounding buildings.

Infiltration trenches function in a similar manner and would be particularly effective for larger roof areas. An infiltration trench is a long, narrow, rock-filled trench with no outlet that receives storm water runoff. These are described under Treatment Controls.

#### Pop-up Drainage Emitter

Roof downspouts can be directed to an underground pipe that daylights some distance from the building foundation, releasing the roof runoff through a pop-up emitter. Similar to a pop-up irrigation head, the emitter only opens when there is flow from the roof. The emitter remains flush to the ground during dry periods, for ease of lawn or landscape maintenance.

### Foundation Planting

Landscape planting can be provided around the base to allow increased opportunities for storm water infiltration and protect the soil from erosion caused by concentrated sheet flow coming off the roof. Foundation plantings can reduce the physical impact of water on the soil and provide a subsurface matrix of roots that encourage infiltration. These plantings must be sturdy enough to tolerate the heavy runoff sheet flows, and periodic soil saturation.

## Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **Supplemental Information**

### **Examples**

- City of Ottawa's Water Links Surface –Water Quality Protection Program
- City of Toronto Downspout Disconnection Program
- City of Boston, MA, Rain Barrel Demonstration Program


#### References

California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.

Hager, Marty Catherine, Stormwater, "Low-Impact Development," January/February 2003. http://www.stormh2o.com/SW/Articles/226.aspx

Low Impact Urban Design Tools, Low Impact Development Design Center, Beltsville, MD. www.lid-stormwater net

Start at the Source, Bay Area Stormwater Management Agencies Association, 1999 Edition.



# SC-03: Automatic Irrigation System



	Design Objectives	
✓	Maximum Infiltration	
✓	Provide On-Site Retention	
✓	Slow Runoff	
	Minimize Impervious Land Coverage	
✓	Implement LID	
	Prohibit Dumping of Improper Materials	
✓	Contain Pollutants	
	Collect and Convey	

### **Description**

Irrigation water provided to landscaped areas may result in excess irrigation water being conveyed into storm water drainage systems.

# **Approach**

Project plan designs for development and redevelopment should include application methods of irrigation water that minimize runoff of excess irrigation water into the storm water conveyance system.

#### **Suitable Applications**

Appropriate applications include residential, commercial and industrial areas planned for development or redevelopment. Detached residential single-family homes are typically excluded from this requirement.

#### **Design Considerations**

#### Design Guidelines

- Design irrigation systems to each landscape area's specific water requirements.
- Implement landscape plans consistent with City water conservation resolutions, which may include provision of drip irrigation, water sensors, programmable irrigation times (for short cycles), etc.
- Design timing and application methods of irrigation water to minimize the runoff of excess irrigation water into the storm water drainage system.
- Group plants with similar water requirements in order to reduce excess irrigation runoff and promote surface filtration.

#### **Designing New Installations**

The following methods to reduce excessive irrigation runoff should be considered, and incorporated and implemented where determined applicable and feasible:

- Employ rain-triggered shutoff devices to prevent irrigation after precipitation.
- Design irrigation systems to each landscape area's specific water requirements.
- Include design featuring flow reducers or shutoff valves triggered by a pressure drop to control water loss in the event of broken sprinkler heads or lines.
- Implement landscape plans consistent with City water conservation resolutions, which may include provision of water sensors, programmable irrigation times (for short cycles), etc.
- Design timing and application methods of irrigation water to minimize the runoff of excess irrigation water into the storm water drainage system.
- Group plants with similar water requirements in order to reduce excess irrigation runoff and promote surface filtration. Choose plants with low irrigation requirements (for example, native or drought tolerant species). Consider design features such as:
  - Using mulches (such as wood chips or bar) in planter areas without ground cover to minimize sediment in runoff.
  - Installing appropriate plant materials for the location, in accordance with amount of sunlight
    and climate, and use native plant materials where possible and/or as recommended by the
    landscape architect.
  - Leaving a vegetative barrier along the property boundary and interior watercourses, to act as a pollutant filter, where appropriate and feasible.
  - Choosing plants that minimize or eliminate the use of fertilizer or pesticides to sustain growth.
- Employ other comparable, equally effective methods to reduce irrigation water runoff.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **O&M Recommendations**

- Inspect irrigation system periodically to ensure that the right amount of water is being applied and that excessive runoff is not occurring.
- Minimize excess watering, and repair leaks in the irrigation system as soon as they are observed.

### References


California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.

A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.

Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.

Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# SC-04: Storm Drain Inlet



	Design Objectives	
	Maximum Infiltration	
	Provide On-Site Retention	
	Slow Runoff	
	Minimize Impervious Land Coverage	
	Implement LID	
✓	Prohibit Dumping of Improper Materials	
	Contain Pollutants	
	Collect and Convey	

### **Description**

Waste materials dumped into storm drain inlets can have severe impacts on receiving and ground waters. Posting notices regarding discharge prohibitions at storm drain inlets can prevent waste dumping. Storm drain signs and stencils are highly visible source controls that are placed directly adjacent to storm drain inlets.

#### **Approach**

The stencil or affixed sign contains a brief statement that prohibits dumping of improper materials into the urban runoff conveyance system. Stencils and signs alert the public to the destination of pollutants discharged to the storm drain.

#### **Suitable Applications**

Stencils and signs alert the public to the destination of pollutants discharged to the storm drain. Signs are appropriate in residential, commercial, and industrial areas, as well as any other area where contributions or dumping to storm drains is likely.

#### **Design Considerations**

Storm drain message markers or placards are recommended at all storm drain inlets within the boundary of a development project. The marker should be placed in clear sight facing toward anyone approaching the inlet from either side. All storm drain inlet locations should be identified on the development site map.

#### Design Guidelines

- Provide stenciling or labeling of all storm drain inlets and catch basins, constructed or modified, within the project area with prohibitive language.
- Place the marker in clear sight facing toward anyone approaching the inlet from either side.

- Be aware that signage on face of curbs tends to be worn by contact with vehicle tires and sweeper brooms.
- Post signs with prohibitive language and/or graphical icons, which prohibit illegal dumping at public access points along channels and creeks within the project area.

#### **Designing New Installations**

The following methods should be considered for inclusion in the project design and shown on project plans:

- Provide stenciling or labeling of all storm drain inlets and catch basins, constructed or modified, within the project area with prohibitive language. Examples include "Dump No Waste" and/or other graphical icons to discourage illegal dumping.
- Post signs with prohibitive language and/or graphical icons, which prohibit illegal dumping at public access points along channels and creeks within the project area.

Note: DFM-SWQ has approved specific signage and/or storm drain message placards for use. Consult local agency storm water staff to determine specific requirements for placard types and methods of application.

# Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. If the project meets the definition of "redevelopment," then the requirements stated under "designing new installations" above should be included in all project design plans.

#### **Supplemental Information**

#### Maintenance Considerations

Legibility of markers and signs should be maintained. If required by the agency with jurisdiction over the project, the owner/operator or homeowner's association should enter into a maintenance agreement with the agency or record a deed restriction upon the property title to maintain the legibility of placards or signs.

#### Placement

- Signage on top of curbs tends to weather and fade.
- Signage on face of curbs tends to be worn by contact with vehicle tires and sweeper brooms.


#### **O&M Recommendations**

- Inspect signage regularly and maintain as appropriate to ensure legibility.
- Inspect regularly, at least annually, for structural deterioration or significant build-up of debris or sediment.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# **SC-05: Alternative Building Materials**



	Design Objectives	
✓	Maximum Infiltration	
✓	Provide On-Site Retention	
✓	Slow Runoff	
	Minimize Impervious Land Coverage	
<b>✓</b>	Implement LID	
	Prohibit Dumping of Improper Materials	
	Contain Pollutants	
	Collect and Convey	

# Description

Alternative building materials are selected instead of conventional materials for new construction and renovation. These materials reduce potential sources of pollutants in storm water runoff by eliminating compounds that can leach into runoff, reducing the need for pesticide application, reducing the need for painting and other maintenance, or by reducing the volume of runoff.

#### **Approach**

Alternative building materials are available for use as lumber for decking, roofing materials, home siding, and paving for driveways, decks, and sidewalks.

#### **Suitable Applications**

Appropriate applications include residential, commercial and industrial areas planned for development or redevelopment.

#### **Design Considerations**

#### Design New Installations

#### Decking

One of the most common materials for construction of decks and other outdoor construction has traditionally been pressure treated wood, which is now being phased out. The standard treatment is called CCA, for chromated copper arsenate. The key ingredients are arsenic (which kills termites, carpenter ants and other insects), copper (which kills the fungi that cause wood to rot) and chromium (which reacts with the other ingredients to bind them to the wood). The amount of arsenic is far from trivial. A deck just 8 ft by 10 ft contains more than 1 1/3 pounds of this highly potent poison. Replacement materials include a new type of pressure treated wood, plastic and composite lumber.

There are currently over 20 products in the market consisting of plastic or plastic-wood composites. Plastic lumber is made from 100% recycled plastic, # 2 high-density polyethylene (HDPE), and polyethylene plastic milk jugs and soap bottles. Plastic-wood composites are a combination of plastic and wood fibers or sawdust. These materials are a long lasting exterior weather, insect, and chemical resistant wood lumber replacement for non-structural applications. Use it for decks, docks, raised garden beds and planter boxes, pallets, hand railings, outdoor furniture, animal pens, boat decks, etc.

New pressure treated wood uses a much safer recipe, ACQ, which stands for ammoniacal copper quartenary. It contains no arsenic and no chromium. Yet the American Wood Preservers Association has found it to be just as effective as the standard formula. ACQ is common in Japan and Europe.

### Roofing

Several studies have indicated that metal used as roofing material, flashing, or gutters can leach metals into the environment. The leaching occurs because rainfall is slightly acidic and slowly dissolved the exposed metals. Common traditional applications include copper sheathing and galvanized (zinc) gutters.

Coated metal products are available for both roofing and gutter applications. These products eliminate contact of bare metal with rainfall, eliminating one source of metals in runoff. There are also roofing materials made of recycled rubber and plastic that resemble traditional materials.

A less traditional approach is the use of green roofs (See TC-07). These roofs are not just green, they're alive. Planted with grasses and succulents, low-profile green roofs reduce the urban heat island effect, storm water runoff, and cooling costs, while providing wildlife habitat and a connection to nature for building occupants. These roofs are widely used on industrial facilities in Europe and have been established as experimental installations in several locations in the US, including Portland, Oregon.

#### Paved Areas

Traditionally, concrete is used for construction of patios, sidewalks, and driveways. Although it is non-toxic, these paved areas reduce storm water infiltration and increase the volume and rate of runoff. This increase in the amount of runoff is the leading cause of stream channel degradation in urban areas.

There are a number of alternative materials that can be used in these applications, including porous concrete and asphalt, modular blocks, and crushed granite. These materials, especially modular paving blocks, are widely available and well established methods to reduce storm water runoff.

### Building Siding

Wood siding is commonly used on the exterior of residential construction. This material weathers fairly rapidly and requires repeated painting to prevent rotting. Alternative "new" products for this application include cement-fiber and vinyl. Cement-fiber siding is a masonry product made from Portland cement, sand, and cellulose and will not burn, cup, swell, or shrink.

#### Pesticide Reduction

A common use of powerful pesticides is for the control of termites. Chlordane was used for many years for this purpose and is now found in urban streams and lakes nationwide. There are a number of physical barriers that can be installed during construction to help reduce the use of pesticides.

Sand barriers for subterranean termites are a physical deterrent because the termites cannot tunnel through it. Sand barriers can be applied in crawl spaces under pier and beam foundations, under slab foundations, and between the foundation and concrete porches, terraces, patios and steps. Other possible locations include under fence posts, underground electrical cables, water and gas lines, telephone and electrical poles, inside hollow tile cells and against retaining walls.

Metal termite shields are physical barriers to termites which prevent them from building invisible tunnels. In reality, metal shields function as a helpful termite detection device, forcing them to build tunnels on the outside of the shields which are easily seen. Metal termite shields also help prevent dampness from wicking to adjoining wood members which can result in rot, thus making the material more attractive to termites and other pests. Metal flashing and metal plates can also be used as a barrier between piers and beams of structures such as decks, which are particularly vulnerable to termite attack.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.


#### Other Resources

There are no good, independent, comprehensive sources of information on alternative building materials for use in minimizing the impacts of storm water runoff. Most websites or other references to "green" or "alternative" building materials focus on indoor applications, such as formaldehyde free plywood and low VOC paints, carpets, and pads. Some supplemental information on alternative materials is available from the manufacturers.

#### References

California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.

Storm Water BMP Guide for New and Redevelopment



# SC-06: Vehicle/Equipment Fueling



Design Objectives	
	Maximum Infiltration
	Provide On-Site Retention
	Slow Runoff
	Minimize Impervious Land Coverage
	Implement LID
	Prohibit Dumping of Improper Materials
✓	Contain Pollutants
<b>✓</b>	Collect and Convey

### **Description**

Fueling areas have the potential to discharge oil and grease, solvents, car battery acid, coolant and gasoline to the storm drain. Spills can be a significant source of pollution because fuels contain toxic materials and heavy metals that are not easily removed by storm water treatment devices.

#### **Approach**

Project plans must be developed for cleaning near fuel dispensers, emergency spill cleanup, containment, and leak prevention.

#### **Suitable Applications**

Appropriate applications include commercial, industrial, and any other areas planned to have fuel dispensing equipment, including retail gasoline outlets, automotive repair shops, and major non-retail dispensing areas.

#### **Design Considerations**

Design requirements for fueling areas are governed by Building and Fire Codes and by current local agency ordinances and zoning requirements. Design requirements described in this fact sheet are meant to enhance and be consistent with these code and ordinance requirements.

#### Design Guidelines

• Covering. Include an overhanging roof structure or canopy over fuel dispensing areas. The cover's minimum dimensions must be equal to or greater than the area within the grade break. The cover must not drain onto the fuel dispensing area and the downspouts must be routed to prevent drainage across the fueling area. If fueling large equipment or vehicles that prohibit the use of covers or roofs, the fueling island should be designed to accommodate the larger vehicles and equipment and to prevent storm water run-on and runoff.

- **Surfacing.** Pave fuel dispensing areas with Portland cement concrete (or equivalent smooth impervious surface). Extend the paved area a minimum of 6.5 ft from the corner of each fuel dispenser, or the length at which the hose and nozzle assembly may be operated plus 1 ft, whichever is less. The use of asphalt concrete is prohibited. Use asphalt sealant to protect asphalt paved areas surrounding the fueling area.
- **Grading/Contouring.** Slope the dispensing areas to prevent ponding, and separate it from the rest of the site by a grade break that prevents run-on. Grade the fueling areas to drain toward a dead-end sump or vegetated/landscaped area. Direct runoff from downspouts/roofs away from fueling areas towards vegetated/landscaped areas if possible.
- **Drains.** Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/water separator.

## **Designing New Installations**

#### Covering

Fuel dispensing areas should provide an overhanging roof structure or canopy. The cover's minimum dimensions must be equal to or greater than the area within the grade break. The cover must not drain onto the fuel dispensing area and the downspouts must be routed to prevent drainage across the fueling area. The fueling area should drain to the project's treatment control BMP(s) prior to discharging to the storm water conveyance system. Note: If fueling large equipment or vehicles that would prohibit the use of covers or roofs, the fueling island should be designed to sufficiently accommodate the larger vehicles and equipment and to prevent storm water run-on and runoff. Grade to direct storm water to a dead-end sump.

### Surfacing

Fuel dispensing areas should be paved with Portland cement concrete (or equivalent smooth impervious surface). The use of asphalt concrete should be minimized. Use asphalt sealant to protect asphalt paved areas surrounding the fueling area. This provision may be made to sites that have pre-existing asphalt surfaces.

The concrete fuel dispensing area should be extended a minimum of 6.5 ft from the corner of each fuel dispenser, or the length at which the hose and nozzle assembly may be operated plus 1 ft, whichever is less.

#### Grading/Contouring

Dispensing areas should have an appropriate slope to prevent ponding, and be separated from the rest of the site by a grade break that prevents run-on of urban runoff (slope is required to be 2 to 4% in some jurisdictions' storm water management and mitigation plans).

Fueling areas should be graded to drain toward a dead-end sump. Runoff from downspouts/roofs should be directed away from fueling areas. Do not locate storm drains in the immediate vicinity of the fueling area.

### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine

whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **Supplemental Information**

In the case of an emergency, provide storm drain seals, such as isolation valves, drain plugs, or drain covers, to prevent spills or contaminated storm water from entering the storm water conveyance system.


#### **O&M Recommendations**

- Maintain clean fuel-dispensing areas using dry cleanup methods such as sweeping, or use of rags and absorbents for leaks and spills.
- If you clean by washing, place a temporary plug in the downstream drain and pump out the accumulated water. Properly dispose the water.
- Install vapor recovery nozzles to help control drips as well as air pollution.
- Use secondary containment when transferring fuel from the tank truck to the fuel tank. Cover storm drains in the vicinity during transfer.
- Post signs at the fuel dispenser or fuel island warning vehicle owners/operators against "topping off" of vehicle fuel tanks.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# SC-07: Vehicle/Equipment Repair



Design Objectives	
	Maximum Infiltration
	Provide On-Site Retention
	Slow Runoff
	Minimize Impervious Land Coverage
	Implement LID
	Prohibit Dumping of Improper Materials
✓	Contain Pollutants
✓	Collect and Convey

### Description/Approach

Several measures can be taken to prevent operations at maintenance bays from contributing a variety of toxic compounds, oil and grease, heavy metals, nutrients, suspended solids, and other pollutants to the storm water conveyance system. In designs for maintenance bays containment is encouraged. Preventive measures include overflow containment structures and dead-end sumps.

#### **Design Guidelines**

Design requirements for vehicle maintenance and repair are governed by Building and Fire Codes, and by current local agency ordinances, and zoning requirements. The design requirements described hereon are meant to enhance and be consistent with these code requirements.

- Locate repair/maintenance bays indoors; or design them to preclude run-on and runoff.
- Pave repair/maintenance floor areas with Portland cement concrete (or equivalent smooth impervious surface).
- Provide impermeable berms, drop inlets, trench catch basins, or overflow containment structures around repair bays to prevent spilled materials and wash-down waters from entering the storm drain system. Connect drains to a sump for collection and disposal. Direct connection of the repair/maintenance bays to the storm drain system is prohibited.
- Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/water separator.

#### **O&M Recommendations**

- Avoid hosing down work areas. If work areas are washed, collect and direct wash water to sanitary sewer.
- Do not pour liquid waste down floor drains, sinks, outdoor storm drain inlets, or other storm drains or sewer connections.

- Do not dispose of used or leftover cleaning solutions, solvents, and automotive fluids and oil in the sanitary sewer.
- Keep drip pans or containers under vehicles or equipment that may drip during repairs.
- When steam cleaning or pressure washing parts, the wastewater must be discharged to an on-site oil water separator that is connected to a sanitary sewer or blind sump.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

# SC-08: Vehicle/Equipment Cleaning



Design Objectives	
	Maximum Infiltration
	Provide On-Site Retention
	Slow Runoff
	Minimize Impervious Land Coverage
	Implement LID
	Prohibit Dumping of Improper Materials
✓	Contain Pollutants
✓	Collect and Convey

# **Description**

Vehicle washing, equipment washing, and steam cleaning may contribute high concentrations of pollutants to wash waters that drain to storm water conveyance systems. Wash water may not be conveyed to a sewer without a sewer connection permit.

#### **Approach**

Project plans should include appropriately designed area(s) for washing-steam cleaning of vehicles and equipment. Depending on the size and other parameters of the wastewater facility, wash water may be conveyed to a sewer, an infiltration system, recycling system or other alternative. Pretreatment may be required for conveyance to a sanitary sewer.

#### **Suitable Applications**

Appropriate applications include commercial developments, restaurants, retail gasoline outlets, automotive repair shops, condominiums, apartment buildings, and others.

### **Design Considerations**

Design requirements for vehicle maintenance are governed by Building and Fire Codes, and by current local agency ordinances, and zoning requirements. Design criteria described in this fact sheet are meant to enhance and be consistent with these code requirements.

#### Design Guidelines

Commericial Applications

Incorporate at least one of the following features for equipment washing/steam cleaning:

- Be self-contained and/or covered with a roof or overhang.
- Be equipped with a clarifier or other pretreatment facility.

Revised: July 2017

- Have a proper connection to a sanitary sewer.
- Install sumps or drain lines to collect wash water. Divert wash water to the sanitary sewer, an engineered infiltration system, or an equally effective alternative.
- Direct and divert surface water runoff away from the exposed area around the wash pad, and wash pad itself to alternatives other than the sanitary sewer.
- Cover areas used for regular washing of vehicles, trucks, or equipment, surround them with a perimeter berm, and clearly mark them as a designated washing area.
- Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/water separator.

# Residential Applications

- Designate a car wash area and post signs for area.
- Divert wash water to a vegetated area where it may percolate into the ground, the sanitary sewer, an engineered Infiltration system, or an equally effective alternative.
- Direct and divert surface water runoff away from the wash area to alternatives other than the sanitary sewer.
- Approval for a sanitary connection must be obtained from the City Department of Environmental Services.

#### **Designing New Installations**

Areas for washing/steam cleaning should incorporate one of the following features:

- Be self-contained and/or covered with a roof or overhang.
- Be equipped with a clarifier or other pretreatment facility.
- Have a proper connection to a sanitary sewer.
- Include other features which are comparable and equally effective.

#### Car Wash Areas

Wash water from the areas may be directed to the sanitary sewer, to an engineered infiltration system, or to an equally effective alternative. Pre-treatment may also be required. For residential applications, it can be appropriate to direct wash water to a planted area and allow it to percolate into the ground.

Developers are to direct and divert surface water runoff away from the exposed area around the wash pad (parking lot, storage areas), and wash pad itself to alternatives other than the sanitary sewer. Roofing may be required for exposed wash pads.

It is generally advisable to cover areas used for regular washing of vehicles, trucks, or equipment, surround them with a perimeter berm, and clearly mark them as a designated washing area. Sumps or drain lines can be installed to collect wash water, which may be treated for reuse or recycling, or for discharge to the sanitary sewer. Some areas may require some form of pretreatment, such as a trap, for these areas.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine

whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **Supplemental Information**

#### Maintenance Considerations

Storm water and non-storm water will accumulate in containment areas and sumps with impervious surfaces. Contaminated accumulated water must be disposed of in accordance with applicable laws and cannot be discharged directly to the storm drain or sanitary sewer system without the appropriate permit.

#### **O&M Recommendations**


- Mark the area clearly as a wash area.
- Post signs to state that washing is only allowed in wash area.
- Provide trash container with lids in wash area.
- Recycle, collect or treat wash water effluent prior to discharge to the sanitary sewer system.
- Do not conduct oil changes and other engine maintenance in the designated washing area. Perform these activities in a place designated for oil change and maintenance activities.
- Cover the wash area when not in use to prevent contact with rain water.
- Do not permit steam cleaning wash water to enter the storm drain.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Storm Water Quality Control Measures, July 2002.

Revised: July 2017



# SC-09: Loading Dock



Design Objectives	
	Maximum Infiltration
	Provide On-Site Retention
	Slow Runoff
	Minimize Impervious Land Coverage
	Implement LID
✓	Prohibit Dumping of Improper Materials
✓	Contain Pollutants
	Collect and Convey

### **Description**

Several measures can be taken to prevent operations at loading docks from contributing a variety of toxic compounds, oil and grease, heavy metals, nutrients, suspended solids, and other pollutants to the storm water conveyance system.

#### **Approach**

In designs for loading docks, containment is encouraged. Preventive measures include overflow containment structures and dead-end sumps. However, in the case of loading docks from grocery stores and warehouse/distribution centers, engineered infiltration systems may be considered.

#### **Suitable Applications**

Appropriate applications include commercial and industrial areas planned for development or redevelopment.

#### **Design Considerations**

Design requirements for vehicle maintenance and repair are governed by Building and Fire Codes, and by current local agency ordinances, and zoning requirements. The design criteria described in this fact sheet are meant to enhance and be consistent with these code requirements.

#### Design Guidelines

Design requirements for vehicle maintenance and repair are governed by Building and Fire Codes, and by current local agency ordinances, and zoning requirements. The design requirements described hereon are meant to enhance and be consistent with these code requirements.

- Cover all loading dock areas, or design them to preclude run-on and runoff.
- Do not allow runoff from depressed loading docks (truck wells) to discharge into storm drains.

- Drain below-grade loading docks from grocery stores and warehouse/distribution centers of fresh food items through water quality inlets, an engineered infiltration system, or an equally effective alternative.
- Grade and/or berm the loading/unloading area to a drain that is connected to a dead-end.
- Pave loading areas with concrete instead of asphalt.

#### **Designing New Installations**

Designs of maintenance bays should consider the following:

- Repair/maintenance bays and vehicle parts with fluids should be indoors; or designed to preclude urban run-on and runoff.
- Repair/maintenance floor areas should be paved with Portland cement concrete (or equivalent smooth impervious surface).
- Repair/maintenance bays should be designed to capture all wash water leaks and spills. Provide impermeable berms, drop inlets, trench catch basins, or overflow containment structures around repair bays to prevent spilled materials and wash-down waters from entering the storm drain system. Connect drains to a sump for collection and disposal. Direct connection of the repair/maintenance bays to the storm drain system is prohibited. If required by local jurisdiction, obtain an Industrial Waste Discharge Permit.
- Other features may be comparable and equally effective.

The following designs of loading/unloading dock areas should be considered:

- Loading dock areas should be covered, or drainage should be designed to preclude urban run-on and runoff.
- Direct connections into storm drains from depressed loading docks (truck wells) are prohibited.
- Below-grade loading docks from grocery stores and warehouse/distribution centers of fresh food items should drain through water quality inlets, or to an engineered infiltration system, or an equally effective alternative. Pre-treatment may also be required.
- Other features may be comparable and equally effective.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

### **Supplemental Information**

Storm water and non-storm water will accumulate in containment areas and sumps with impervious surfaces. Contaminated accumulated water must be disposed of in accordance with applicable laws and cannot be discharged directly to the storm drain or sanitary sewer system without the appropriate permit.

#### **O&M Recommendations**


- Develop an operations plan that describes procedures for loading and/or unloading.
- Conduct loading and unloading in dry weather if possible.

- Load and unload all materials and equipment in covered areas if feasible.
- Load/unload only at designated loading areas.
- Check loading and unloading equipment regularly for leaks.
- Look for dust or fumes during loading or unloading operations.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# **SC-10: Outdoor Trash Storage**



	Design Objectives	
	Maximum Infiltration	
	Provide On-Site Retention	
	Slow Runoff	
	Minimize Impervious Land Coverage	
	Implement LID	
	Prohibit Dumping of Improper Materials	
✓	Contain Pollutants	
	Collect and Convey	

### **Description**

Storm water runoff from areas where trash is stored or disposed of can be polluted. In addition, loose trash and debris can be easily transported by water or wind into nearby storm drain inlets, channels, and/or streams.

#### **Approach**

Preventive measures including enclosures, containment structures, and impervious pavements to mitigate spills, should be used to reduce the likelihood of contamination.

#### **Suitable Applications**

Appropriate applications include residential, commercial, and industrial areas planned for development or redevelopment. Detached residential single-family homes are typically excluded from this requirement.

#### **Design Considerations**

Design requirements for waste handling areas are governed by Building and Fire Codes, and by current local agency ordinances and zoning requirements. The design criteria described in this fact sheet are meant to enhance and be consistent with these code and ordinance requirements. Hazardous waste should be handled in accordance with legal requirements established in Hawaii Administrative Rules Title 11 Chapter 58.1 Solid Waste Management Control, and enforcement by the State of Hawaii Department of Health Solid and Hazardous Waste Branch.

Wastes from commercial and industrial sites are typically hauled by either public or commercial carriers that may have design or access requirements for waste storage areas. The design criteria in this fact sheet are recommendations and are not intended to be in conflict with requirements established by the waste hauler. The waste hauler should be contacted prior to the design of your site trash collection areas. Conflicts or issues should be discussed with the local agency.

#### Design Guidelines

- Hazardous waste must be handled in accordance with legal requirements established in Hawaii Administrative Rules Title 11 Chapter 58.1 Solid Waste Management Control, and enforcement by the State of Hawaii Department of Health solid and Hazardous Waste Branch.
- Berm trash storage areas to prevent run-on from adjoining roofs and pavement, or grade areas towards vegetated/landscaped areas.
- Reduce/prevent leaking of liquid waste by incorporating at least one of the following:
  - Lined bins or dumpsters.
  - Low containment berm around the dumpster area.
  - Drip pans underneath dumpsters.
- Prevent rainfall from entering containers with roofs, awnings, or attached lids.
- Pave trash storage areas with an impervious surface to mitigate spills.
- Do not locate storm drains in immediate vicinity of the trash storage area.
- Post signs on dumpsters indicating that hazardous material are not to be disposed of therein.

#### **Designing New Installations**

Trash storage areas should be designed to consider the following structural or treatment control BMPs:

- Design trash container areas so that drainage from adjoining roofs and pavement is diverted around the area(s) to avoid run-on. This might include berming or grading the waste handling area to prevent run-on of storm water.
- Make sure trash container areas are screened or walled to prevent off-site transport of trash.
- Use lined bins or dumpsters to reduce leaking of liquid waste.
- Provide roofs, awnings, or attached lids on all trash containers to minimize direct precipitation and prevent rainfall from entering containers.
- Pave trash storage areas with an impervious surface to mitigate spills.
- Do not locate storm drains in immediate vicinity of the trash storage area.
- Post signs on all dumpsters informing users that hazardous material are not to be disposed of therein.

### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **Supplemental Information**

#### Maintenance Considerations

The integrity of structural elements that are subject to damage (i.e., screens, covers, and signs) must be maintained by the owner/operator. Maintenance agreements between the local agency and the owner/operator may be required. Some agencies will require maintenance deed restrictions to be recorded of the property title. If required by the local agency, maintenance agreements or deed restrictions must be executed by the owner/operator before improvement plans are approved.


#### **O&M** Recommendations

- Spot clean leaks and drips routinely to prevent runoff of spillage.
- Post "no littering" signs.
- Use only watertight waste receptacle(s) and keep the lid(s) closed.
- Do not overfill or fill with any liquid. Keep lid closed at all times.
- Periodically inspect for leaks. If found contact the leasing company immediately.
- Never wash down or rinse with a hose. Contact leasing company for cleaning.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- Hawaii Administrative Rules Title 11 Chapter 58.1 Solid Waste Management Control, Honolulu Hawaii Department of Health, 2003: http://health.hawaii.gov/shwb/files/2013/06/11-5811.pdf
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# **SC-11: Outdoor Material Storage**



Design Objectives	
	Maximum Infiltration
	Provide On-Site Retention
	Slow Runoff
	Minimize Impervious Land Coverage
	Implement LID
	Prohibit Dumping of Improper Materials
✓	Contain Pollutants
✓	Collect and Convey

# Description

Proper design of outdoor storage areas for materials reduces opportunity for pollutants to enter the storm water conveyance system. Materials may be in the form of raw products, by-products, finished products, and waste products.

#### **Approach**

Outdoor storage areas require a drainage approach different from the typical infiltration/detention strategy. In outdoor storage areas, infiltration is discouraged and containment is encouraged. Preventative measures include enclosures, secondary containment structures and impervious surfaces.

#### **Suitable Applications**

Appropriate applications include residential, commercial and industrial areas planned for development or redevelopment.

#### **Design Considerations**

Some materials are more of a concern than others. Toxic and hazardous materials must be prevented from coming in contact with storm water. Non-toxic or non-hazardous materials do not have to be prevented from storm water contact. However, these materials may have toxic effects on receiving waters if allowed to be discharged with storm water in significant quantities. Accumulated material on an impervious surface could result in significant impact on the rivers or streams that receive the runoff.

Material may be stored in a variety of ways, including bulk piles, containers, shelving, stacking, and tanks. Storm water contamination may be prevented by eliminating the possibility of storm water contact with the material storage areas either through diversion, cover, or capture of the storm water. Control measures may also include minimizing the storage area. Design requirements for material storage areas are governed by Building and Fire Codes, and by current City ordinances and zoning requirements. Control measures are site specific, and must meet local agency requirements.

# Design Guidelines

Design requirements for material storage areas are governed by Building and Fire Codes, and by current City ordinances and zoning requirements. Control measures are site specific, and must meet local agency requirements.

- Materials with the potential to contaminate storm water must either be placed in an enclosure that prevents contact with runoff or spillage to the storm water conveyance system, or protected by secondary containment structures such as berms, dikes, or curbs.
- Pave the storage area with Portland cement concrete (or equivalent smooth impervious surface) to contain leaks and spills.
- Slope the storage area towards a dead-end sump to contain spills.
- Direct runoff from downspouts/roofs away from storage areas.
- Cover the storage area with an awning that extends beyond the storage area to minimize collection of storm water within the secondary containment area. A manufactured storage shed may be used for small containers.

# **Designing New Installations**

Where proposed project plans include outdoor areas for storage of materials that may contribute pollutants to the storm water conveyance system, the following structural or treatment BMPs should be considered:

- Materials with the potential to contaminate storm water should be:
  - Placed in an enclosure such as, but not limited to, a cabinet, shed, or similar structure that prevents contact with runoff or spillage to the storm water conveyance system, or
  - Protected by secondary containment structures such as berms, dikes, or curbs.
- The storage area should be paved and sufficiently impervious to contain leaks and spills.
- The storage area should slope towards a dead-end sump to contain spills and direct runoff from downspouts/roofs should be directed away from storage areas.
- The storage area should have a roof or awning that extends beyond the storage area to minimize collection of storm water within the secondary containment area. A manufactured storage shed may be used for small containers.

Note that the location(s) of installations of where these preventative measures will be employed must be included on the map or plans identifying BMPs.

## Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

## **Supplemental Information**

Storm water and non-storm water will accumulate in containment areas and sumps with impervious surfaces. Contaminated accumulated water must be disposed of in accordance with applicable laws and cannot be discharged directly to the storm drain or sanitary sewer system without the appropriate permits.


#### **O&M Recommendations**

- Protect materials from rainfall, run-on, runoff, and wind dispersal.
- Employ safeguards against accidental releases.
- Inspect storage areas regularly for leaks or spills.
- Keep storage areas clean and dry.
- Keep containers in good condition without corrosion or leaky seams.
- Cover and contain stockpiles of raw materials to prevent storm water run-on. If infeasible, implement erosion control practices around site perimeter and catch basins.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

- California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.
- A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.
- Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.
- Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# SC-12: Outdoor Work Areas



Design Objectives		
	Maximum Infiltration	
	Provide On-Site Retention	
	Slow Runoff	
	Minimize Impervious Land Coverage	
	Implement LID	
	Prohibit Dumping of Improper Materials	
<b>✓</b>	Contain Pollutants	
<b>✓</b>	Collect and Convey	

# **Description**

Proper design of outdoor work areas (grinding, painting, coating, sanding, parts cleaning, etc.) reduces opportunity for pollutants to enter the storm water conveyance system.

# **Approach**

In outdoor work areas, infiltration and discharge to the storm drain are discouraged; collection and conveyance to the sanitary sewer are encouraged.

# **Suitable Applications**

Appropriate applications include residential, commercial, and industrial areas planned for development or redevelopment.

## **Design Considerations**

Design requirements for outdoor work areas are governed by Building and Fire Codes, and by current City ordinances, and zoning requirements.

# Design Guidelines

Design requirements for outdoor work areas are governed by Building and Fire Codes, and by current City ordinances, and zoning requirements.

- Create an impermeable surface such as concrete or asphalt, or a prefabricated metal drip pan, depending on the use.
- Cover the area with a roof to prevent rain from falling on the work area and becoming polluted runoff.
- Berm or perform mounding around the perimeter of the area to prevent water from adjacent areas from flowing on to the surface of the work area.

- Directly connect runoff to the sanitary sewer or other specialized containment system(s). This allows the more highly concentrated pollutants from these areas to receive special treatment that removes particular constituents. Approval for this connection must be obtained from the City.
- Locate the work area away from storm drains or catch basins.

## **Designing New Installations**

Outdoor work areas can be designed in particular ways to reduce impacts on both storm water quality and sewage treatment plants.

- Create an impermeable surface such as concrete or sealed asphalt, or a prefabricated metal drip pan, depending on the use.
- Cover the area with a roof. This prevents rain from falling on the work area and becoming polluted runoff.
- Berm or perform mounding around the perimeter of the area to prevent water from adjacent areas from flowing on to the surface of the work area.
- Directly connect runoff. Unlike other areas, runoff from work areas is directly connected to the sanitary sewer or other specialized containment system(s). This allows the more highly concentrated pollutants from these areas to receive special treatment that removes particular constituents. Approval for this connection must be obtained from the appropriate sanitary sewer agency.
- Locate the work area away from storm drains or catch basins.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **O&M Recommendations**

- Dry clean the work area regularly.
- Inspect storage areas regularly for leaks or spills.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

#### References

California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.


A Manual for the Standard Urban Stormwater Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.

Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.

A-46

Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# SC-13: Outdoor Process Equipment Operations



	Design Objectives		
	Maximum Infiltration		
	Provide On-Site Retention		
	Slow Runoff		
	Minimize Impervious Land Coverage		
	Implement LID		
	Prohibit Dumping of Improper Materials		
✓	Contain Pollutants		
<b>✓</b>	Collect and Convey		

# **Description**

Outdoor process equipment operations such as rock grinding or crushing, painting or coating, grinding or sanding, degreasing or parts cleaning, may contribute a variety of pollutants to the storm conveyance system.

#### **Approach**

In outdoor process equipment areas, infiltration is discouraged and containment is encouraged, accompanied by collection and conveyance.

# **Suitable Applications**

Appropriate applications include commercial and industrial areas planned for development or redevelopment.

## **Design Considerations**

Design requirements for outdoor processing areas are governed by Building and Fire codes, and by current local agency ordinances, and zoning requirements.

#### Design Guidelines

Design requirements for outdoor processing areas are governed by Building and Fire codes, and by current local agency ordinances, and zoning requirements.

- Cover or enclose areas that would be the most significant source of pollutants; or slope the area toward a dead-end sump; or, discharge to the sanitary sewer system following appropriate treatment in accordance with conditions established by the applicable sewer agency.
- Grade or berm area to prevent run-on from surrounding areas.
- Do not install storm drains in areas of equipment repair.

• Provide secondary containment structures (not double wall containers) where wet material processing occurs (e.g., electroplating), to hold spills resulting from accidents, leaking tanks, or equipment, or any other unplanned releases. Note: if these are plumbed to the sanitary sewer, they must be with the prior approval of the City.

#### **Designing New Installations**

Operations determined to be a potential threat to water quality should consider to the following recommendations:

- Cover or enclose areas that would be the most significant source of pollutants; or slope the area toward a dead-end sump; or, discharge to the sanitary sewer system following appropriate treatment in accordance with conditions established by the applicable sewer agency.
- Grade or berm area to prevent run-on from surrounding areas.
- Do not install storm drains in areas of equipment repair.
- Consider other features that are comparable or equally effective.
- Provide secondary containment structures (not double wall containers) where wet material processing occurs (i.e., electroplating), to hold spills resulting from accidents, leaking tanks, or equipment, or any other unplanned releases. Note: if these are plumbed to the sanitary sewer, they must be with the prior approval of the City or other applicable sanitary sewer agency.

#### Redeveloping Existing Installations

The City's SWMPP defines "redevelopment" as development that would create or add impervious surface area on an already developed site. The definition of "redevelopment" must be consulted to determine whether or not the requirements for new development apply to areas intended for redevelopment. If the definition applies, the steps outlined under "designing new installations" above should be followed.

#### **Supplemental Information**

Storm water and non-storm water will accumulate in containment areas and sumps with impervious surfaces. Contaminated accumulated water must be disposed of in accordance with applicable laws and cannot be discharged directly to the storm drain or sanitary sewer system without the appropriate permit.

#### **O&M Recommendations**

- Dry clean the work area regularly.
- Inspect storage areas regularly for leaks or spills.
- Develop and implement a Spill Prevention Control and Countermeasure (SPCC) Plan.

# References

California Stormwater Quality Association (CASQA) Best Management Practices Handbook New Development and Redevelopment, 2003.


A Manual for the Standard Urban Storm Water Mitigation Plan (SUSMP), Los Angeles County Department of Public Works, May 2002.

Model Standard Urban Storm Water Mitigation Plan (SUSMP) for San Diego County, Port of San Diego, and Cities in San Diego County, February 14, 2002.

A-50

Model Water Quality Management Plan (WQMP) for County of Orange, Orange County Flood Control District, and the Incorporated Cities of Orange County, Draft February 2003.

Ventura Countywide Technical Guidance Manual for Stormwater Quality Control Measures, July 2002.



# **SC-14: Parking Areas**



Design Objectives				
✓	Maximum Infiltration			
✓	Provide On-Site Retention			
✓	Slow Runoff			
<b>✓</b>	Minimize Impervious Land Coverage			
✓	Implement LID			
	Prohibit Dumping of Improper Materials			
	Contain Pollutants			
	Collect and Convey			

# Description/Approach


Parking lots and storage areas can contribute a number of substances, such as trash, suspended solids, hydrocarbons, oil and grease, and heavy metals that can enter receiving waters through storm water runoff or non-storm water discharges. The protocols in this fact sheet are intended to prevent or reduce the discharge of pollutants from parking/storage areas.

## **Design Guidelines**

Direct pavement runoff towards vegetated/landscaped areas if possible.

#### **O&M Recommendations**

- Clean leaves, trash, sand, and other debris regularly.
- Routinely sweep, shovel, and dispose of litter in the trash. Sweep entire parking lot at least once before the onset of the wet season.
- Provide an adequate number of covered trash receptacles. Clean out frequently.
- Re-seal or pave only on dry days, and stop immediately before rainfall.
- Pre-heat, transfer or load hot bituminous material away from storm drain inlets.
- Do not allow any solids, liquids, or slurries to enter storm drains.
- Use dry clean-up methods (absorbents) on auto spills and/or drips.
- Do not hose down unless absolutely necessary. If you must pressure wash, discharge wash water to the sanitary sewer or a vegetated area. Do not allow wash water to enter storm drains.



# **Appendix B: Treatment Control BMP Fact Sheets**


On the following pages are fact sheets for each Treatment Control BMP specified in the *Water Quality Rules*. The following information is provided for each BMP:

- Brief description
- BMP category
- Expected pollutant removals
- Minimum design criteria
- Feasibility criteria
- Step-by-stem sizing procedure

- Pretreatment considerations
- Area requirements
- Sizing example
- Other design considerations
- Typical schematic
- General maintenance rank and requirements

The sizing procedures are based on simple dynamic and static principles and therefore may result in larger BMPs than are necessary. More rigorous sizing methods (such as detailed routing methods or continuous simulation models) may be used with City approval. Sizing worksheets are available on the DPP's website.

BMPs not included herein, such as Stormwater wetlands, wet ponds, and proprietary devices, may be used with written City approval.



# **TC-01: Infiltration Basin**



BMP Category		
Retention	•	
Biofiltration	0	
Other	0	

<b>O&amp;M Requirements</b>
Medium
1110010111

Expected Pollutant Removals				
Nutrients	High	Pesticides	High	
Sediment	High	Oil & Grease	High	
Trash	High	Metals	High	
Pathogens	High	Organic Compounds	High	

Halawa District Park

# **Description**

An infiltration basin is a shallow impoundment with no outlet, where storm water runoff is stored and infiltrates through the basin invert and into the soil matrix.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Invert Slope	percent	0
Maximum Interior Side Slope (length per unit height)		3:1
Drawdown (drain) Time	hours	48
Minimum Soil Infiltration Rate	inches/hour	0.5
Minimum Freeboard	feet	1.0
Minimum Depth from Basin Invert to Groundwater Table	feet	3

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Calculate the maximum allowable water storage depth (d<sub>max</sub>) using the underlying soil infiltration rate (k) and the required drawdown time (t):

$$d_{max} = kt/(F_s \times 12)$$

Where  $d_{max} = Maximum Storage Depth (ft)$ 
 $k = Soil Infiltration Rate (in/hr)$ 

F = Infiltration Rate Factor of Safety (see Section 5)

Step 3. Select a design ponding depth no greater than the maximum allowable depth calculated in Step 2.

= Drawdown (drain) Time (hrs)

$$d_p \le d_{max}$$

Where  $d_p$  = Design Ponding Depth (ft)

 $d_{max}$  = Maximum Storage Depth from Step 2 (ft)

 $k$  = Soil Infiltration Rate (in/hr)

Step 4. Calculate the basin bottom surface area  $(A_b)$ :

$$A_b = WQV/(d_p + kT/12F_s)$$
Where  $A_b = Bottom Surface Area (sq-ft)$ 

$$WQV = WQV from Step 1 (cu-ft)$$

$$d_p = Design Ponding Depth from Step 3 (ft)$$

$$k = Soil Infiltration Rate (in/hr)$$

$$T = Fill Time (time for the BMP to fill with water [hrs])$$

$$F_s = Infiltration Rate Factor of Safety (see Section 5)$$

Step 5. Select a basin bottom width  $(w_k)$ , and calculate the basin bottom length  $(l_k)$ :

$$l_b = A_b/w_b$$

Where  $l_b$  = Bottom Length (ft)

 $A_b$  = Bottom Surface Area from Step 4 (sq-ft)

 $w_b$  = Bottom Width (ft)

Step 6. Calculate the total area occupied by the BMP excluding pretreatment (A<sub>BMP</sub>) using the basin bottom dimensions, embankment side slopes, and freeboard:

$$A_{BMP} = [W_b + 2z(d_p + f)] \times [l_b + 2z(d_p + f)]$$

Where  $A_{BMP}$  = Area Occupied by BMP Excluding Pretreatment (sq-ft)

 $w_b$  = Bottom Width from Step 5 (ft)

z = Basin Interior Side Slope (length per unit height)

 $d_n$  = Design Ponding Depth from Step 3 (ft)

f = Freeboard (ft)

l = Bottom Length from Step 5 (ft)

If the calculated area does not fit in the available space, either reduce the drainage area, increase the ponding depth (if it's not already set to the maximum depth), and/or reduce the Infiltration Rate Factor of Safety (if minimum number of test pits and permeability tests have not been performed) and repeat the calculations.

#### **Pretreatment Considerations**

Infiltration facilities are highly susceptible to clogging and premature failure from sediment, trash, and other materials. Suitable pretreatment systems maintain the infiltrate rate of the device without frequent and intensive maintenance. For measured soil infiltration rates below 3 in/hr, pretreatment is strongly recommended, and the pretreatment device should be sized for at least 25% of the WQV. For measured soil infiltration rates greater than 3 in/hr, pretreatment is mandatory to minimize groundwater contamination risks, and the pretreatment device must be sized for at least 50% of the WQV if the measured soil infiltration rate is below 5 in/hr and 100% of the WQV if the measured soil infiltration rate is greater than 5 in/hr. Pretreatment may be achieved with vegetated swales, vegetated filter strips, sedimentation basins or forebays, sedimentation manholes, and manufactured treatment devices.

#### **Area Requirements**

An infiltration basin requires a footprint equivalent to 7% - 20% of its contributing impervious drainage area, excluding pretreatment. The lower value reflects the maximum allowable infiltration rate and minimum allowable factor of safety, while the upper value reflects the minimum allowable infiltration rate and maximum allowable factor of safety.

## Sizing Example

Calculate the size of an infiltration basin serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	%	70
Design Storm Depth, P	inches	1
Basin Fill Time, T	hours	2
Drawdown (drain) Time, t	hours	48
Basin Interior Side Slope (length per unit height), z		3

Design Parameter	Units	Value
Soil Infiltration Rate, k	inches/hour	1.0
Infiltration Rate Factor of Safety, F <sub>s</sub>		2
Freeboard, f	feet	1

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.009 \times 70$$

$$C = 0.68$$

$$WQV = PCA \times 3630$$

$$WQV = 1 \times 0.68 \times 1 \times 3630$$

$$WQV = 2,468 \text{ cu-ft}$$

2. Calculate the maximum allowable water storage depth of the infiltration trench  $(d_{max})$ :

$$d_{max} = kt/12F_s$$

$$d_{\text{max}} = 1.0 \times 48/(12 \times 2)$$

$$d_{max} = 2.0 \text{ ft}$$

3. Select a ponding depth (d<sub>p</sub>) is no greater than the maximum allowable depth:

$$d_p = 2.0 \text{ ft}$$

4. Calculate the basin bottom surface area (A<sub>b</sub>):

$$A_b = WQV/(d_p + kT/12F_s)$$

$$A_b = 2,468/[2.0 + 1.0 \times 2.0/(12 \times 2)]$$

$$A_{b} = 1,185 \text{ sq-ft}$$

5. Set the basin bottom width  $(w_h)$  to 25 ft, and calculate the basin bottom length  $(l_h)$ :

$$l_b = A_b/W_b$$

$$l_{b} = 1,185/25$$

$$l_{b} = 47.4 \text{ ft}$$

6. Calculate the total area excluding pretreatment  $(A_{BMP})$ :

$$A_{BMP} = [w_b + 2z(d_p + f)] \times [l_b + 2z(d_p + f)]$$

$$A_{BMP} = [25 + 2 \times 3(2+1)] \times [47.4 + 2 \times 3(2+1)]$$

$$A_{BMP} = 2,812 \text{ sq-ft}$$


#### **Other Design Considerations**


- If a temporarily-filled pond creates a potential public safety issue, perimeter fencing may be considered. A vegetative screen around the basin to restrict direct view from adjacent properties may improve the aesthetics of the site and public acceptance of the facility.
- If feasible, include vehicle access to the basin invert for maintenance.
- If the area around the basin has a recreational use, a safety shelf around the perimeter of the basin can be included for times when the basin is flooded.
- The infiltration basin should be designed with an outlet structure to pass peak flows during a range of storm events, as well as with an emergency spillway to pass peak flows around the embankment during extreme storm events that exceed the combined infiltration capacity and outlet structure capacity of the facility.
- To help ensure maintenance of the design permeability rate over time, a 6-inch layer of sand may be placed on the bottom of an infiltration basin. This sand layer can intercept silt, sediment, and debris that could otherwise clog the top layer of the soil below the basin. The sand layer will also facilitate silt, sediment, and debris removal from the basin and can be readily restored following removal operations.
- Observation wells are recommended. They will indicate how quickly the basin dewaters following a storm and it will provide a method of observing how quickly the basin fills up with sediments.

#### Construction/Inspection Considerations

- Before construction begins, stabilize the entire area draining to the facility. If impossible, place a diversion berm around the perimeter of the infiltration site to prevent sediment entrance during construction or remove the top two (2) inches of soil after the site is stabilized. Stabilize the entire contributing drainage area, including the side slopes, before allowing any runoff to enter once construction is complete.
- Place excavated material such that it cannot be washed back into the basin if a storm occurs during construction of the facility.
- Build the basin without driving heavy equipment over the infiltration surface. Any equipment driven on the surface should have extra-wide ("low pressure") tires. Prior to any construction, rope off the infiltration area to stop entrance by unwanted equipment.
- After final grading, till the infiltration surface deeply.
- Use appropriate erosion control seed mix for the specific project and location.

Revised: July 2017





# **Schematic of an Infiltration Basin**

# **TC-02: Infiltration Trench**



BMP Category		
Retention	•	
Biofiltration	0	
Other	0	

O&M Requirements	
Medium	

<b>Expected Pollutant Removals</b>				
Nutrients	High	Pesticides	High	
Sediment	High	Oil & Grease	High	
Trash	High	Metals	High	
Pathogens	High	Organic Compounds	High	

City of Bellingham, WA (source: cob.org/services/environment/lake-whatcom)

# **Description**

An infiltration trench is a rock-filled trench with no outlet, where storm water runoff is stored in the void space between the rocks and infiltrates through the bottom and into the soil matrix.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Maximum Trench Depth	feet	8
Maximum Trench Width	feet	25
Maximum Top Backfill Layer Thickness	inches	6
Maximum Bottom Sand Layer Thickness	inches	12
Drawdown (drain) Time	hours	48
Minimum Soil Infiltration Rate	inches/hour	0.5
Trench Rock Size	inches	1.5 - 3.0
Minimum Depth from trench invert to groundwater table	feet	3

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Calculate the maximum allowable water storage depth (d<sub>max</sub>) using the underlying soil infiltration rate (k) and the required drawdown time (t):

$$d_{max} = kt/(F_s \times 12)$$

Where  $d_{max} = Maximum Storage Depth (ft)$ 
 $k = Soil Infiltration Rate (in/hr)$ 
 $t = Drawdown (drain) Time (hrs)$ 
 $F_s = Infiltration Rate Factor of Safety (see Section 5)$ 

Step 3. Select a ponding depth (optional), trench rock (or alternative material) depth, and sand layer depth (optional) such that the total effective storage depth is no greater than the maximum allowable depth calculated in Step 2:

```
\begin{aligned} d_t &= d_p + l_b n_b + l_s n_s \leq d_{max} \\ \text{Where } d_t &= \text{Total Effective Water Storage Depth (ft)} \\ d_p &= \text{Ponding Depth (ft)} \\ l_b &= \text{Backfill Material Thickness Depth (ft)} \\ n_b &= \text{Backfill Material Porosity} \\ l_s &= \text{Sand Layer Thickness Depth (ft)} \\ n_s &= \text{Sand Porosity} \\ d_{max} &= \text{Maximum Storage Depth from Step 2 (ft)} \end{aligned}
```

Step 4. Calculate the trench surface area  $(A_{RMP})$ :

```
A_{BMP} = WQV/(d_t + kT/12F_s)
Where A_{BMP} = BMP Surface Area excluding Pretreatment (sq-ft)
WQV = WQV \text{ from Step 1 (cu-ft)}
d_t = Total \text{ Effective Water Storage Depth from Step 3 (ft)}
k = Soil \text{ Infiltration Rate (in/hr)}
T = Fill \text{ Time (time for the BMP to fill with water [hrs])}
F_s = Infiltration \text{ Rate Factor of Safety (see Section 5)}
```

If the calculated area does not fit in the available space, either reduce the drainage area, increase the ponding depth or trench rock depth or sand layer depth (if the total effective depth is not already equal to the maximum depth), and/or reduce the Infiltration rate factor of safety (if minimum number of test pits and permeability tests have not been performed) and repeat the calculations.

## **Pretreatment Considerations**

Infiltration facilities are highly susceptible to clogging and premature failure from sediment, trash, and other materials. Suitable pretreatment systems maintain the infiltrate rate of the device without

B-10

frequent and intensive maintenance. For measured soil infiltration rates below 3 in/hr, pretreatment is strongly recommended, and the pretreatment device should be sized for at least 25% of the WQV. For measured soil infiltration rates greater than 3 in/hr, pretreatment is mandatory to minimize groundwater contamination risks, and the pretreatment device must be sized for at least 50% of the WQV if the measured soil infiltration rate is below 5 in/hr and 100% of the WQV if the measured soil infiltration rate is greater than 5 in/hr. Pretreatment may be achieved with vegetated swales, vegetated filter strips, sedimentation basins or forebays, sedimentation manholes, and manufactured treatment devices.

# **Area Requirements**

An infiltration trench requires a footprint equivalent to 2% - 20% of its contributing impervious drainage area, excluding pretreatment. The lower value reflects the maximum allowable infiltration rate, minimum allowable factor of safety, and minimal ponding, while the upper value reflects the minimum allowable infiltration rate, maximum allowable factor of safety, and no ponding.

# Sizing Example

Calculate the size of an infiltration basin serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	70
Design Storm Depth, P	inches	1
Trench Fill Time, T	hours	2
Drawdown (drain) Time, t	hours	48
Backfill porosity, n <sub>b</sub>		0.35
Sand porosity, n <sub>s</sub>		0.40
Soil Infiltration Rate, k	inches/hour	1
Infiltration Rate Factor of Safety, F <sub>s</sub>		2

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$
  
 $C = 0.05 + 0.009 \times 70$   
 $C = 0.68$   
 $WQV = PCA \times 3630$   
 $WQV = 1 \times 0.68 \times 1 \times 3630$   
 $WOV = 2.468$  cu-ft

2. Calculate the maximum allowable water storage depth in the basin  $(d_{max})$ :

$$d_{max} = kT/12F_{s}$$
 $d_{max} = 1.0 \times 48/(12 \times 2)$ 
 $d_{max} = 2.0 \text{ ft}$ 

3. Select a design ponding depth  $(d_p)$ , trench rock depth  $(d_r)$ , and optional sand layer depth  $(d_s)$  such that the total effective storage depth  $(d_r)$  is no greater than the maximum allowable depth:

$$\begin{array}{lll} d_{p} & = & 0.0 \text{ ft} \\ l_{b} & = & 5.0 \text{ ft} \\ l_{s} & = & 0.5 \text{ ft} \\ \\ d_{t} & = & d_{p} + l_{b}n_{b} + l_{s}n_{s} \\ d_{t} & = & 0.0 + 5.0 \times 0.35 + 0.5 \times 0.40 \\ d_{t} & = & 1.95 \text{ ft} \end{array}$$

4. Calculate the BMP surface area excluding pretreatment  $(A_{BMP})$ :

$$\begin{array}{lcl} A_{BMP} & = & WQV/(d_{_t} + kT/12F_{_s}) \\ A_{BMP} & = & 2,468/[1.95 + 1.0 \times 2.0/(12 \times 2)] \\ A_{BMP} & = & 1,214 \ sq\mbox{-ft} \end{array}$$

# **Other Design Considerations**


- Observation wells are recommended at 50 ft intervals over the length of the infiltration trench. They will indicate how quickly the trench dewaters following a storm and it will provide a method of observing how quickly the trench fills up with sediments.
- Infiltration trenches should not be deeper than the longest surface area dimension. Otherwise, they meet the USEPA definition of Class V Injection Wells under the federal Underground Injection Control (UIC) Program, and are subject to applicable federal and state requirements.
- Vegetation may be planted over the infiltration trench provided that adequate soil media is provided above the trench.
- There must be an overflow route for storm water flows that overtop the facility or in case the infiltration facility becomes clogged.

# Construction/Inspection Considerations


Stabilize the entire area draining to the infiltration before construction begins. If impossible, place a diversion berm around the perimeter of the infiltration site to prevent sediment entrance during construction.

Stabilize the entire contributing drainage area before allowing any runoff to enter once construction is complete.

B-12



**Schematic of an Infiltration Trench** 



# **TC-03: Subsurface Infiltration**



BMP Category	
Retention	
Biofiltration	0
Other	0

<b>O&amp;M Requirements</b>	
Medium	

Expected Pollutant Removals			
Nutrients	High	Pesticides	High
Sediment	High	Oil & Grease	High
Trash	High	Metals	High
Pathogens	High	Organic Compounds	High

Kroc Community Center, Kapolei

# **Description**

An subsurface infiltration system is a rock storage (or alternative pre-manufactured material) bed below other surfaces such as parking lots, lawns, and playfields for temporary storage and infiltration of runoff.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Drawdown (drain) Time	hours	48
Minimum Soil Infiltration Rate	inches/hour	0.5
Minimum Depth from system invert to groundwater table	feet	3
Any applicable manufacturer's criteria		

## **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

## **Sizing Procedure**

Follow the manufacturer's guidelines for appropriate sizing calculations and selection of appropriate device/model.

#### **Pretreatment Considerations**

Infiltration facilities are highly susceptible to clogging and premature failure from sediment, trash, and other materials. Suitable pretreatment systems maintain the infiltrate rate of the device without frequent and intensive maintenance. For measured soil infiltration rates below 3 in/hr, pretreatment is strongly recommended, and the pretreatment device should be sized for at least 25% of the WQV. For

measured soil infiltration rates greater than 3 in/hr, pretreatment is mandatory to minimize groundwater contamination risks, and the pretreatment device must be sized for at least 50% of the WQV if the measured soil infiltration rate is below 5 in/hr and 100% of the WQV if the measured soil infiltration rate is greater than 5 in/hr. Pretreatment may be achieved with vegetated swales, vegetated filter strips, sedimentation basins or forebays, sedimentation manholes, and manufactured treatment devices.

# **Area Requirements**

The below-grade footprint requirements for commercially-available infiltration chambers vary by manufacturer. However, similarly to above-grade non-proprietary systems, the space will be minimized for sites with higher infiltration rates and lower infiltration rate factors of safety.

# Sizing Example


Follow the manufacturer's guidelines for appropriate sizing calculations and selection of appropriate configuration.

# **Other Design Considerations**

Refer to manufacturer guidelines.

# **Construction/Inspection Considerations**

Refer to manufacturer guidelines.



Schematic of a Subsurface Infiltration

# TC-04: Dry Well



BMP Category		
Retention		
Biofiltration	0	
Other	0	

O&M Requirements	
Medium	

<b>Expected Pollutant Removals</b>			
Nutrients	High	Pesticides	High
Sediment	High	Oil & Grease	High
Trash	High	Metals	High
Pathogens	High	Organic Compounds	High

Courtesy www.brickstoremuseum.org

# **Description**

A dry well is a subsurface aggregate-filled or prefabricated perforated storage facility, where roof runoff is stored and infiltrates into the soil matrix.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Drawdown (drain) Time	hours	48
Minimum Soil Infiltration Rate	inches/hour	0.5
Aggregate Size (if used)	inches	1.0 - 3.0
Minimum Depth from well invert to groundwater table	feet	3

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Calculate the maximum allowable water storage depth  $(d_{max})$  using the underlying soil infiltration rate (k) and the required drawdown time (t):

$$d_{max} = kt/(F_s \times 12)$$

Where  $d_{max} = Maximum Storage Depth (ft)$ 
 $k = Soil Infiltration Rate (in/hr)$ 
 $t = Drawdown (drain) Time (hrs)$ 
 $F_s = Infiltration Rate Factor of Safety (see Section 5)$ 

Step 3. Select a ponding depth (optional) and dry well backfill material depth such that the total effective storage depth is no greater than the maximum allowable depth calculated in Step 2:

```
\begin{aligned} \boldsymbol{d}_t &= \boldsymbol{d}_p + \boldsymbol{l}_b \boldsymbol{n}_b \leq \boldsymbol{d}_{max} \\ \text{Where } & \boldsymbol{d}_t &= \text{Total Effective Water Storage Depth (ft)} \\ \boldsymbol{d}_p &= \text{Ponding Depth (ft)} \\ \boldsymbol{l}_b &= \text{Backfill Material Thickness Depth (ft)} \\ \boldsymbol{n}_b &= \text{Backfill Material Porosity} \\ \boldsymbol{d}_{max} &= \text{Maximum Storage Depth from Step 2 (ft)} \end{aligned}
```

Step 4. Calculate the BMP surface area  $(A_{BMP})$ :

```
A_{BMP} = WQV/(d_t + kT/12F_s)
Where A_{BMP} = BMP Surface Area (sq-ft)
WQV = WQV \text{ from Step 1 (cu-ft)}
d_t = Total \text{ Effective Water Storage Depth from Step 3 (ft)}
k = Soil \text{ Infiltration Rate (in/hr)}
T = Fill \text{ Time (time for the BMP to fill with water [hrs])}
F = Infiltration \text{ Rate Factor of Safety (see Section 5)}
```

If the calculated area does not fit in the available space, either reduce the drainage area, increase the ponding depth or rock depth (if the total effective depth is not already equal to the maximum depth), and/or reduce the infiltration rate factor of safety (if minimum number of test pits and permeability tests have not been performed) and repeat the calculations.

#### **Pretreatment Considerations**

Roof gutter guards or leaf gutter screens are required for roof runoff to reduce dry well clogging from sediment, leaves, and other organic material. If the dry well receives non-roof runoff, pretreatment must be provided by vegetated swales, vegetated filter strips, or manufactured treatment devices.

#### **Area Requirements**

A dry well requires a footprint equivalent to 2% - 20% of its contributing impervious drainage area. The lower value reflects the maximum allowable infiltration rate, minimum allowable factor of safety,

and minimal ponding, while the upper value reflects the minimum allowable infiltration rate, maximum allowable factor of safety, and no ponding.

# Sizing Example

Calculate the size of a dry well serving the roof runoff from a 3,000 sq-ft commercial building. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	100
Design Storm Depth, P	inches	1.0
Dry Well Fill Time, T	hours	2
Drawdown (drain) Time, t	hours	48
Backfill material porosity, n <sub>b</sub>		0.35
Soil Infiltration Rate, k	inches/hour	1.0
Infiltration Rate Factor of Safety, F <sub>s</sub>		2

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.009 \times 100$$

$$C = 0.95$$

$$WQV = PCA \times 3630$$

$$WQV = 1 \times 0.95 \times (3,000/43,560) \times 3630$$

$$WQV = 238 \text{ cu-ft}$$

2. Calculate the maximum allowable water storage depth in the dry well  $(d_{max})$ :

$$d_{max} = kt/12F_s$$

$$d_{\text{max}} = 1.0 \times 48/(12 \times 2)$$

$$d_{max} = 2.0 \text{ ft}$$

3. Select a design ponding depth  $(d_p)$  and backfill material depth  $(l_b)$  such that the total effective storage depth  $(d_p)$  is no greater than the maximum allowable depth:

$$d_{p} = 0.0 \text{ ft}$$

$$l_{\rm h} = 5.5 \, {\rm ft}$$

$$d_t = d_p + l_b n_b$$

$$d_{t} = 0.0 + 5.5 \times 0.35$$

$$d_{i} = 1.925 \text{ ft}$$

## 4. Calculate the BMP surface area:


 $\begin{array}{lcl} A_{BMP} & = & WQV/(d_{_{t}} + kT/12F_{_{s}}) \\ A_{BMP} & = & 238/[1.925 + 1.0 \times 2.0/(12 \times 2)] \\ A_{BMP} & = & 118 \text{ sq-ft} \end{array}$ 

## **Other Design Considerations**

- Dry wells are typically deeper than they are wide or long, and therefore meet the USEPA definition of Class V Injection Wells under the federal Underground Injection Control (UIC) Program, and are subject to applicable federal and state requirements.
- The dry well must be able to safely convey overflows to either vegetated areas or the storm drain system.
- The design may include an intermediate box with an outflow higher to allow sediments to settle out. Water would then flow through a mesh screen and into the dry well.
- Trees and other large vegetation should be planted away from drywells such that drip lines do not overhang infiltration beds.

## Construction/Inspection Considerations

Refer to manufacturer guidelines.



Schematic of a Dry Well

# **TC-05: Bioretention Basin**



BMP Category	
Retention	
Biofiltration	0
Other	0

<b>O&amp;M Requirements</b>				
Medium				

Expected Pollutant Removals					
Nutrients	High	Pesticides	High		
Sediment	High	Oil & Grease	High		
Trash	High	Metals	High		
Pathogens	High	Organic Compounds	High		

Heeia State Park (www.huihawaii.org)

# **Description**

Sometimes referred to as a rain garden, a bioretention basin is an engineered shallow depression that collects and filters storm water runoff using conditioned planting soil beds and vegetation. The filtered runoff infiltrates through the basin invert and into the soil matrix.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Mulch Thickness	inches	2 - 4
Planting Soil Depth	feet	2 - 4
Drawdown (drain) Time	hours	48
Maximum Interior Side Slope (length per unit height)		3:1
Maximum Ponding Depth	inches	12
Minimum Depth from basin invert to groundwater table	feet	3
Minimum Freeboard	feet	1.0
Minimum Soil Infiltration Rate	inches/hour	0.5

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Calculate the maximum allowable water storage depth  $(d_{max})$  using the underlying soil infiltration rate (k) and the required drawdown time (t):

$$d_{max} = kt/(F_s \times 12)$$

Where  $d_{max} = Maximum Storage Depth (ft)$ 
 $k = Soil Infiltration Rate (in/hr)$ 
 $t = Drawdown (drain) Time (hrs)$ 
 $F_s = Infiltration Rate Factor of Safety (see Section 5)$ 

Step 3. Select a ponding depth, planting media thickness (depth), and reservoir layer thickness (depth, optional) such that the total effective storage depth is no greater than the maximum allowable depth calculated in Step 2:

$$\begin{aligned} d_t &= d_p + l_m n_m + l_r n_r \leq d_{max} \\ \text{Where } & d_t &= \text{Total Effective Water Storage Depth (ft)} \\ d_m &= \text{Ponding Depth (ft)} \\ l_m &= \text{Planting Media Thickness Depth (ft)} \\ n_m &= \text{Planting Media Porosity} \\ l_r &= \text{Reservoir Layer Thickness Depth (ft)} \\ n_r &= \text{Reservoir Layer Porosity} \\ d_{max} &= \text{Maximum Storage Depth from Step 2 (ft)} \end{aligned}$$

Step 4. Calculate the basin bottom surface area (A<sub>L</sub>):

```
A_b = WQV/(d_t + kT/12F_s)
Where A_{BMP} = Bottom Surface Area (sq-ft)
WQV = WQV  from Step 1 (cu-ft)
d_t = Total  Effective Water Storage Depth from Step 3 (ft)
k = Soil  Infiltration Rate (in/hr)
T = Fill  Time (time for the BMP to fill with water [hrs])
F_s = Infiltration Rate  Factor of Safety (see Section 5)
```

Step 5. Select a basin bottom width  $(w_k)$ , and calculate the basin bottom length  $(l_k)$ :

```
A_b = WQV/(d_t + kT/12F_s)
Where l_b = Bottom Length (ft)
A_b = Bottom Surface Area from Step 4 (sq-ft)
w_b = Bottom Width (ft)
```

Step 6. Calculate the total area occupied by the BMP excluding pretreatment (A<sub>BMP</sub>) using the basin bottom dimensions, embankment side slopes, and freeboard:

$$A_{BMP} = [w_b + 2z(d_p + f)] \times [l_b + 2z(d_p + f)]$$

Where  $A_{BMP}$  = Area Occupied by BMP Excluding Pretreatment (sq-ft)

 $w_b$  = Bottom Width from Step 5 (ft)

z = Basin Interior Side Slope (length per unit height)

d<sub>b</sub> = Design Ponding Depth from Step 3 (ft)

f = Freeboard (ft)

 $l_b$  = Bottom Length from Step 5 (ft)

If the calculated area does not fit in the available space, either reduce the drainage area, increase the ponding depth or planting soil depth or gravel depth (if the total effective depth is not already equal to the maximum depth), and/or reduce the Infiltration rate factor of safety (if minimum number of test pits and permeability tests have not been performed) and repeat the calculations.

#### **Pretreatment Considerations**

Infiltration facilities are highly susceptible to clogging and premature failure from sediment, trash, and other materials. Suitable pretreatment systems maintain the infiltrate rate of the device without frequent and intensive maintenance. For measured soil infiltration rates below 3 in/hr, pretreatment is strongly recommended, and the pretreatment device should be sized for at least 25% of the WQV. For measured soil infiltration rates greater than 3 in/hr, pretreatment is mandatory to minimize groundwater contamination risks, and the pretreatment device must be sized for at least 50% of the WQV if the measured soil infiltration rate is below 5 in/hr and 100% of the WQV if the measured soil infiltration rate is greater than 5 in/hr. Pretreatment may be achieved with vegetated swales, vegetated filter strips, sedimentation basins or forebays, sedimentation manholes, and manufactured treatment devices.

# **Area Requirements**

A bioretention basin requires a footprint equivalent to 4% - 13% of its contributing impervious drainage area, excluding pretreatment. The lower value reflects the maximum allowable infiltration rate and minimum allowable factor of safety, while the upper value reflects the minimum allowable infiltration rate and maximum allowable factor of safety.

#### Sizing Example

Calculate the size of a bioretention basin serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	70
Design Storm Depth, P	inches	1.0
Basin Fill Time, T	hours	2
Drawdown (drain) Time, t	hours	48

Design Parameter	Units	Value
Basin Interior Side Slope (length per unit height), z		3
Planting Media Porosity, n <sub>m</sub>		0.25
Reservoir Layer Porosity, n <sub>r</sub>		0.30
Soil Infiltration Rate, k	inches/hour	1.0
Freeboard, f	feet	1.0
Infiltration Rate Factor of Safety, F <sub>s</sub>		2

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.009 \times 70$$

$$C = 0.68$$

$$WQV = PCA \times 3630$$

$$WQV = 1 \times 0.68 \times 1 \times 3630$$

$$WQV = 2,468 \text{ cu-ft}$$

2. Calculate the maximum allowable water storage depth in the dry well ( $\mathbf{d}_{\max}$ ):

$$d_{max} = kt/12F_s$$

$$d_{max} = 1.0 \times 48/(12 \times 2)$$

$$d_{max} = 2.0 \text{ ft}$$

3. Select a ponding depth  $(d_p)$ , planting media depth  $(l_m)$ , and optional reservoir layer depth  $(l_r)$  such that the total effective storage depth  $(d_r)$  is no greater than the maximum allowable depth:

$$d_{p} = 0.67 \text{ ft}$$

$$l_{m} = 4.0 \text{ ft}$$

$$l_{r} = 1.0 \text{ ft}$$

$$d_t = d_p + l_m n_m + l_r n_r$$

$$d_{t} = 0.67 + 4.0 \times 0.25 + 1.0 \times 0.30$$

$$d_{.} = 1.97 \text{ ft}$$

4. Calculate the basin bottom surface area (A<sub>b</sub>):

$$A_b = WQV/(dt + kT/12Fs)$$

$$A_b = 2,468/[1.97 + 1.0 \times 2.0/(12 \times 2)]$$

$$A_b = 1,204 \text{ sq-ft}$$

5. Set the basin bottom width  $(w_k)$  to 25 ft, and calculate the basin bottom length  $(l_k)$ :

$$l_b = A_b/w_b$$
  
 $l_b = 1,204/25$   
 $l_b = 48.2 \text{ sq-ft}$ 

6. Calculate the total area excluding pretreatment  $(A_{RMP})$ :


```
\begin{array}{lcl} A_{BMP} & = & [w_b + 2z(d_p + f)] \times [l_b + 2z(d_p + f)] \\ A_{BMP} & = & [25 + 2 \times 3(0.67 + 1)] \times [48.2 + 2 \times 3(0.67 + 1)] \\ A_{BMP} & = & 2,037 \text{ sq-ft} \end{array}
```


# **Other Design Considerations**

- The plantings should emulate a terrestrial forest community ecosystem. Native species should be selected, taking into account the local climate, expected water depth in the basin, and expected tolerances to pollutant loads and varying soil moistures. The trees should be smaller ones similar to those found in the forest understory, since it is more difficult to perform maintenance with the tall trees that are normally part of the forest canopy. Ground cover, such as grasses or legumes, should be planted after the trees and shrubs are in place.
- An overflow device (e.g., domed riser, spillway) must be included to safely convey runoff from large storm events when the surface/subsurface capacity is exceeded.
- If a mulch layer is used on the surface of the planting bed, consideration should be given to problems caused by flotation during storm events.
- Observation wells are recommended. They will indicate how quickly the basin dewaters
  following a storm and it will provide a method of observing how quickly the basin fills up with
  sediments.

### **Construction/Inspection Considerations**

Bioretention basins should not be established until contributing watershed is stabilized.





# **Schematic of a Bioretention Basin**

# **TC-06: Permeable Pavement**



BMP Category	
Retention	•
Biofiltration	0
Other	0

O&M Requirements	
Low	

Expected Pollutant Removals				
Nutrients	High	Pesticides	High	
Sediment	High	Oil & Grease	High	
Trash	Trash High Metals High			
Pathogens	High	Organic Compounds	High	

UH Hale Halawai Overflow Parking

# **Description**

Sometimes referred to as pervious pavement or porous pavement, permeable pavement refers to any porous, load-bearing surface that allows for temporary rainwater storage in an underlying aggregate layer until it infiltrates into the soil matrix. It includes pervious concrete, porous asphalt, interlocking paver blocks, and reinforced turf and gravel filled grids.

# Minimum Design Criteria

Design Parameter	Units	Value
Maximum Depth of Reservoir Layer	feet	3
Drawdown (drain) Time	hours	48
Minimum Depth from Reservoir Invert to Groundwater Table	feet	3
Minimum Soil Infiltration Rate	inches/hour	0.5

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Calculate the maximum allowable water storage depth  $(d_{max})$  using the underlying soil infiltration rate (k) and the required drawdown time (t):

$$d_{max} = kt/(F_s \times 12)$$

Where  $d_{max} = Maximum Storage Depth (ft)$ 
 $k = Soil Infiltration Rate (in/hr)$ 
 $t = Drawdown (drain) Time (hrs)$ 
 $F_s = Infiltration Rate Factor of Safety (see Section 5)$ 

Step 3. Select a pavement course thickness  $(l_p)$  and reservoir course thickness  $(l_r)$  such that the total effective storage depth  $(d_r)$  is no greater than the maximum allowable depth:

```
\begin{aligned} d_t &= (l_p n_p + l_r n_r)/12 \leq d_{max} \\ \text{Where } d_t &= \text{Total Effective Water Storage Depth (ft)} \\ l_p &= \text{Pavement Course Thickness (in)} \\ n_p &= \text{Pavement Course Porosity} \\ l_r &= \text{Reservoir Layer Thickness Depth (in)} \\ n_r &= \text{Reservoir Layer Porosity} \\ d_{max} &= \text{Maximum Storage Depth from Step 2 (ft)} \end{aligned}
```

Step 4. Calculate the BMP surface area  $(A_{BMP})$ :

```
A_{BMP} = WQV/(d_t + kT/12F_s)
Where A_{BMP} = BMP Surface Area (sq-ft)
WQV = WQV \text{ from Step 1 (cu-ft)}
d_t = Total \text{ Effective Water Storage Depth from Step 3 (ft)}
k = Soil \text{ Infiltration Rate (in/hr)}
T = Fill \text{ Time (time for the BMP to fill with water [hrs])}
F_s = Infiltration \text{ Rate Factor of Safety (see Section 5)}
```

If the calculated area does not fit in the available space, either reduce the drainage area, increase the pavement course depth or reservoir course depth or gravel depth (if the total effective depth is not already equal to the maximum depth), and/or reduce the Infiltration rate factor of safety (if minimum number of test pits and permeability tests have not been performed) and repeat the calculations.

#### **Pretreatment Considerations**

Pretreatment is not required as long as the permeable pavement does not receive run-on from other surfaces. If it does, pretreatment is necessary to prevent premature failure due to clogging with fine sediment, and may be achieved with gravel filter strips, vegetated buffer strips, or vegetated swales.

### **Area Requirements**

Permeable pavement requires a footprint equivalent to 5% - 18% of its contributing impervious drainage area. The lower value reflects the maximum allowable infiltration rate and minimum allowable factor of safety, while the upper value reflects the minimum allowable infiltration rate and maximum allowable factor of safety.

# Sizing Example

Calculate the size of a section of permeable pavement serving the runoff from a 1-acre parking lot. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	100
Design Storm Depth, P	inches	1.0
Reservoir Layer Time, T	hours	2
Drawdown (drain) Time, t	hours	48
Pavement Course Porosity, n <sub>p</sub>		0.15
Reservoir Course Porosity, n <sub>r</sub>		0.35
Soil Infiltration Rate, k	inches/hour	1.0
Infiltration Rate Factor of Safety, F <sub>s</sub>		2

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.009 \times 100$$

$$C = 0.95$$

$$WQV = PCA \times 3630$$

$$WQV = 1 \times 0.95 \times 1 \times 3630$$

$$WQV = 3,449 \text{ cu-ft}$$

2. Calculate the maximum allowable water storage depth in the dry well  $(d_{max})$ :

$$d_{max} = kT/12F_s$$

$$d_{max} = 1.0 \times 48/(12 \times 2)$$

$$d_{max} = 2.0 \text{ ft}$$

3. Select a pavement course thickness  $(l_p)$  and reservoir course thickness  $(l_p)$  such that the total effective storage depth  $(d_p)$  is no greater than the maximum allowable depth:

$$l_{p} = 12.0 \text{ ft}$$

$$l_{r} = 24.0 \text{ ft}$$

$$d_{t} = (l_{p}n_{p} + l_{r}n_{r})/12$$

$$d_{t} = (12 \times 0.15 + 24.0 \times 0.35)/12$$

$$d_{t} = 0.85 \text{ ft}$$

4. Calculate the pavement surface area:

```
A_{IMP} = WQV/[d_t + (kT/12F_s)]

A_{IMP} = 3,449/[0.85 + (1.0 \times 2.0/(12 \times 2)]


A_{IMP} = 3,695 \text{ sq-ft}
```

# **Other Design Considerations**


- All porous paving and permeable paver with storage bed systems must include measures that
  will allow runoff from the design storm to enter the storage bed in the event that the porous
  or permeable paver surface course becomes clogged or otherwise incapable of conveying the
  maximum design storm runoff to the bed.
- Additional design details on specific pavement systems are provided by the National Asphalt Pavement Association, the National Ready Mix Concrete Association, the Interlocking Concrete Pavement Institute, and the American Association of State Highway and Transportation Officials.
- Perforated pipes along the bottom of the bed may be used to evenly distribute runoff over the entire bed bottom. Pipes should lay flat along the bed bottom and provide for uniform distribution of water. Depending on size, these pipes may provide additional storage volume.
- Flows in excess of the design capacity of the permeable pavement system will require an overflow system connected to a downstream conveyance or other storm water runoff BMP.

# **Construction/Inspection Considerations**

- Permeable surfaces can be laid without cross-falls or longitudinal gradients.
- The blocks should be lain level.
- They should not be used for storage of site materials, unless the surface is well protected from deposition of silt and other spillages.
- The pavement should be constructed in a single operation, as one of the last items to be built, on a development site. Landscape development should be completed before pavement construction to avoid contamination by silt or soil from this source.
- Surfaces draining to the pavement should be stabilized before construction of the pavement.
- Inappropriate construction equipment should be kept away from the pavement to prevent damage to the surface, sub-base or sub-grade.




# TYPICAL SECTION— PERVIOUS CONCRETE OR POROUS ASPHALT



TYPICAL SECTION - PERMEABLE PAVERS

#### **Schematic of a Permeable Pavement**



# **TC-07: Green Roof**



BMP Category			
Retention	0		
Biofiltration •			
Other	0		

<b>O&amp;M Requirements</b>	
Medium	

Expected Pollutant Removals			
Nutrients	Medium	Pesticides	Medium
Sediment	High	Oil & Grease	High
Trash	High	Metals	Medium
Pathogens	Medium	Organic Compounds	Medium

University of Hawaii C-MORE Hale (hahana.soest.hawaii.edu)

# **Description**

Sometimes referred to as a vegetated roof or eco-roof, a green roof is a roof that is entirely or partially covered with vegetation and soils for the purpose of filtering, absorbing, evapotranspirating, and retaining/detaining the rain that falls upon it.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Minimum Depth of Soil Media	inches	2
Minimum Depth of Drainage Layer	inches	2
Maximum Slope on Roof	percent	20

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

- Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.
- Step 2. Select initial values for the soil media thickness  $(l_m)$ , drainage layer thickness  $(l_d)$ , and allowable ponding depth  $(d_n)$ .

Step 3. Calculate the total effective storage depth based on instantaneous storage capacity using the void space in the soil media and drainage layer, and the allowable ponding:

$$d_{t} = (d_{p} + l_{m}n_{m} + l_{d}n_{d})/12$$
Where  $d_{t} = \text{Total Effective Water Storage Depth (ft)}$ 

$$d_{p} = \text{Ponding Depth (in)}$$

$$l_{m} = \text{Planting Media Thickness Depth (in)}$$

$$n_{m} = \text{Planting Media Porosity}$$

$$l_{d} = \text{Drainage Layer Thickness (in)}$$

$$n_{d} = \text{Drainage Layer Porosity}$$

Step 4. Calculate area required (A<sub>BMP</sub>) based on the instantaneous storage capacity:

$$A_{BMP} = WQV/d_t$$

Where  $A_{BMP} = BMP Area (sq-ft)$ 
 $WQV = WQV from Step 1 (cu-ft)$ 
 $d_t = Total Effective Water Storage Depth from Step 3 (ft)$ 

If the calculated area does not fit in the available space, either reduce the tributary area and/ or increase one or more of the design depths (ponding, soil media, drainage layer), and repeat the calculations.

#### **Pretreatment Considerations**

Green roofs do not require pretreatment.

# **Area Requirements**

A green roof requires a footprint equivalent to 11% - 100% of the contributing roof drainage area. The lower value corresponds to 4 inches of ponding and maximum depths for both the planting media and drainage layer depths, while the higher value corresponds to no ponding and minimum planting media and drainage layer depths.

#### Sizing Example

Calculate the size of a green roof serving the roof runoff from a 1,500 sq-ft fast food restaurant. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	100
Design Storm Depth, P	inches	1.0
Soil Media Porosity, n <sub>m</sub>		0.20
Drainage Layer Porosity, n <sub>d</sub>		0.25

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$
  
 $C = 0.05 + 0.009 \times 100$   
 $C = 0.95$   
 $WQV = PCA \times 3,630$   
 $WQV = 1 \times 0.95 \times (1,500/43,560) \times 3,630$   
 $WQV = 119 \text{ cu-ft}$ 

2. Select initial values for the soil media depth (d<sub>m</sub>), drainage layer depth (d<sub>d</sub>), and ponding depth (d<sub>n</sub>):

$$d_{m} = 3 \text{ in}$$
 $d_{d} = 2 \text{ in}$ 
 $d_{p} = 0.5 \text{ in}$ 

3. Calculate the total effective storage depth:

$$\begin{array}{lcl} d_t & = & (d_p + l_m n_m + l_d n_d)/12 \\ d_t & = & (0.5 + 3 \times 0.20 + 2 \times 0.25)/12 \\ d_t & = & 0.133 \ \mathrm{ft} \end{array}$$

4. Calculate the area  $(A_{PMP})$ :

```
A_{BMP} = WQV/d_{t}


A_{BMP} = 119/0.133

A_{BMP} = 891 \text{ sq-ft}

891 \text{ sq-ft} is available, so the design is okay.
```

#### **Other Design Considerations**

- Safety measures against wind uplift must be taken into account during design, especially for areas susceptible to high winds during the summer trade-wind period.
- The maximum load bearing capacity of the roof construction must be considered when installing vegetated roofs. The water saturated weight of the green roof system, including vegetation must be calculated as permanent load. Generally, vegetated roofs weigh between 15 and 30 lb/sq-ft depending on the thickness of the vegetated roof system. In addition, construction elements such as pergolas and walkways cause high point loads and, therefore, have to be calculated accordingly.
- The design must include adequate roof access for delivery of construction materials and for routine maintenance
- The drainage layer below the growth media should be designed to convey the flood design storm without backing water up to into the growing media. The drainage layer should convey flow to an outlet or overflow system such as a traditional rooftop drainage system with inlets set slightly above the elevation of the vegetated roof surface.





Schematic of a Green Roof

# TC-08: Vegetated Bio-Filter



BMP Category			
Retention	0		
Biofiltration •			
Other	0		

<b>O&amp;M Requirements</b>	
Low	

Expected Pollutant Removals			
Nutrients	Medium	Pesticides	Unknown
Sediment	High	Oil & Grease	High
Trash	High	Metals	High
Pathogens	Medium	Organic Compounds	High

Waikiki

# **Description**

This category of BMPs may also be referred to as a bioretention filter, storm water curb extension, tree box filter, or planter box. A vegetated bio-filter is an engineered shallow depression or above ground system that collects and filters storm water runoff using conditioned planting soil beds and vegetation. The filtered runoff discharges through an underdrain system.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Planting Soil Coefficient of Permeability	feet/day	1.0
Mulch Thickness	inches	2 – 4
Planting Soil Depth	feet	2 – 4
Drawdown (drain) Time	hours	48
Maximum Ponding Depth	inches	12
Minimum Underdrain Diameter	inches	6

For proprietary systems, follow the manufacturer's guidelines for appropriate sizing calculations and selection of appropriate device/model.

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

#### **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WOV.

- Step 2. Select initial values for the soil media thickness  $(l_m)$ , drainage layer thickness  $(l_d)$ , and allowable ponding depth  $(d_n)$ .
- Step 3. Use Darcy's Law to calculate the required Filter Bed Surface Area:

$$A_{b} = (WQV \times l_{m})/k (l_{m} + d_{p}/24) (t/24)$$
Where  $A_{b} = \text{Filter Bed Surface Area (sq-ft)}$ 

$$WQV = WQV \text{ from Step 1 (cu-ft)}$$

$$l_{m} = \text{Planting Media Depth from Step 2 (ft)}$$

$$k = \text{Planting Media Permeability Coefficient (ft/day)}$$

$$d_{p} = \text{Maximum Ponding Depth from Step 2 (in)}$$

$$t = \text{Filter Bed Drain Time (hr)}$$

Step 4. Select a filter bed width  $(w_k)$ , and calculate the filter bed length  $(l_k)$ :

$$l_b = A_b/w_b$$

Where  $l_b$  = Filter Bed Length (ft)

 $A_b$  = Filter Bed Surface Area from Step 3 (sq-ft)

 $w_b$  = Filter Bed Width (ft)

Step 5. Calculate the total area occupied by the BMP excluding pretreatment  $(A_{BMP})$  using the filter bed dimensions, embankment side slopes, and freeboard:

$$A_{BMP} = [w_b + 2z(d_p + f)] \times [l_b + 2z(d_p + f)]$$
Where  $A_{BMP} = A$  rea occupied by BMP excluding Pretreatment (sq-ft)
$$w_b = F$$
 ilter Bed Width from Step 4
$$z = F$$
 ilter Bed Interior Slope (length per unit height)
$$d_p = M$$
 Maximum Ponding Depth from Step 2 (ft)
$$f = F$$
 reeboard (ft)
$$l_p = F$$
 ilter Bed Length from Step 4 (ft)

If the calculated area does not fit in the available space, either reduce the drainage area, reduce the planting soil depth (if it's not already set to the minimum), and/or increase the ponding depth (if it's not already set to the maximum depth), and repeat the calculations.

#### **Pretreatment Considerations**

Pretreatment should be provided where sediments or trash may cause a concern or decreased BMP functionality, and when space permits. Pretreatment may be achieved with vegetated swales, vegetated buffer strips with pea gravel or stone diaphragm, or manufactured treatment device.

# **Area Requirements**

A vegetated bio-filter requires a footprint equivalent to 3.3% - 3.8% of its contributing impervious drainage area, excluding pretreatment. The lower value reflects the minimum planting media depth and maximum ponding depth, while the upper value reflects the maximum planting media depth and minimum ponding depth.

### Sizing Example

Calculate the size of a vegetated bio-filter serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	70
Design Storm Depth, P	inches	1.0
Planting Soil Coefficient of Permeability, k	feet/day	1.0
Drawdown (drain) Time, t	hours	48
Interior Side Slope (length per unit height), z		0
Freeboard, f	feet	0.5

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.0039 \times 70$$

$$C = 0.68$$

$$WQV = PCA \times 3,630$$

$$WQV = 1 \times 0.68 \times 1 \times 3,630$$

$$WQV = 2,468 \text{ cu-ft}$$

2. Select a planting soil depth (d<sub>s</sub>) and ponding depth (d<sub>n</sub>):

$$d_a = 2 \text{ ft}$$

$$d_n = 6 in$$

3. Calculate the Filter Bed Surface Area  $(A_{BMP})$ :

$$A_{BMP} = WQV \times d_s/[k(d_s + (d_p/24))(t/24)]$$

$$A_{BMP} = 2,468 \times 2/[1(2 + (6/24))(48/24)]$$

$$A_{BMP} = 1,097 \text{ sq-ft}$$

4. Set the bottom width  $(w_k)$  to 6 ft, and calculate the bottom length  $(l_k)$ :

$$l_b = A_b/W_b$$

$$l_{b} = 1,097/6$$

$$1 = 182.8 \text{ ft}$$

5. Calculate the total area excluding pretreatment  $(A_{BMP})$ :


$$\begin{array}{lll} A_{BMP} & = & \left[ \ w_b + 2z(d_p + f) \ \right] x \left[ \ l_b + 2z(d_p + f) \ \right] \\ A_{BMP} & = & \left[ \ 6 + 2 \times 0 \times (0.5 + 0.5) \ \right] \times \left[ \ 182.8 + 2 \times 0 \times (0.5 + 0.5) \ \right] \\ A_{BMP} & = & 1,097 \ sq\text{-ft} \end{array}$$


#### **Other Design Considerations**

- All bio-filters must be able to safely overflow or bypass flows in excess of the storm water quality design storm to downstream drainage systems when the surface/subsurface capacity is exceeded.
- If a mulch layer is used on the surface of the planting bed, consideration should be given to problems caused by flotation during storm events.
- A cleanout pipe should be tied into the end of all underdrain pipe runs.


#### **Construction/Inspection Considerations**


Vegetated biofilters should not be established until contributing watershed is stabilized.





Schematic of a Vegetated Bio-Filter





**Schematic of a Tree Box Filter** 

# TC-09: Enhanced Swale



BMP Category	
Retention	0
Biofiltration	•
Other	0

<b>O&amp;M Requirements</b>	
Medium	

Expected Pollutant Removals			
Nutrients	Medium	Pesticides	Unknown
Sediment	High	Oil & Grease	Medium
Trash	High	Metals	Medium
Pathogens	Unknown	Organic Compounds	Unknown

Georgia Stormwater Management Manual, 2001.

# **Description**

Sometimes referred to as a bioretention swale or dry swale, an enhanced swale is a shallow linear channel with a planting bed and covered with turf or other surface material (other than mulch or plants). Runoff filters through a planting bed, is collected in an underdrain system, and discharged at the downstream end of the swale.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Maximum Interior Side Slope (length per unit height)		3:1
Bottom width	feet	2 - 8
Maximum Longitudinal Slope without check dams	percent	2
Maximum Longitudinal Slope with check dams	percent	5
Maximum check dam height	inches	12
Maximum Ponding Depth at downstream end	inches	18
Media depth	inches	18 - 36
Minimum Freeboard	feet	0.5
Minimum Underdrain Diameter	inches	6

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

- Step 2. Select values for the planting media thickness, drainage layer thickness, planting media porosity, drainage layer porosity, maximum surface ponding depth (if check dams are used), bottom width, and interior side slope (length per unit height).
- Step 3. Calculate the total effective storage depth based on the instantaneous storage capacity using the void space in the planting media and drainage layer, and the average ponding depth (assumed to be one-half the maximum ponding depth):

```
d_{t} = [(d_{p}/2) + l_{m}n_{m} + l_{d}n_{d}]/12
Where d_{t} = Total Effective Water Storage Depth (ft)
d_{p} = Maximum Ponding Depth from Step 2 (in)
l_{m} = Planting Media Thickness from Step 2 (in)
n_{m} = Planting Media Porosity, typically around 0.25
l_{d} = Drainage Layer Thickness from Step 2 (in)
n_{d} = Drainage Layer Porosity, typically around 0.40
```

Step 4. Calculate the swale invert area required (A<sub>b</sub>) based on the instantaneous storage capacity (neglecting the additional ponding capacity due to the shape of the swale sides):

```
A_b = WQV/d_t

Where A_b = Bottom Surface Area (sq-ft)

WQV = WQV from Step 1 (cu-ft)

d_t = Total Effective Water Storage Depth from Step 3 (cu-ft)
```

Step 5. Calculate the total area required  $(A_{BMP})$  taking into account the side slopes along the length of the swale:

```
A_{BMP} = [b + 2z(f + d_p/12)] \times (A_b/b)
Where A_{BMP} = \text{Total Surface Area (sq-ft)}
b = \text{Swale Bottom Width from Step 2 (ft)}
z = \text{Interior Swale Side Slope (length per unit height) from Step 2}
d_p = \text{Ponding Depth from Step 2 (in)}
f = \text{Freeboard (ft)}
A_b = \text{Bottom Surface Area from Step 4 (sq-ft)}
```

If the minimum surface area is larger than the available space, reduce the tributary area and/or increase one or more design depths (media, gravel, ponding), and repeat the calculations.

#### **Pretreatment Considerations**

Pretreatment for enhanced swales is provided by a shallow sediment forebay at the initial point of the channel. The volume of this forebay should be equal to at least 0.05 in. per impervious acre of drainage.

A pea gravel diaphragm can be used along the top of the channel to provide pretreatment for lateral flows entering the swale.

# **Area Requirements**

An enhanced swale requires a footprint equivalent to 8% - 40% of its contributing impervious drainage area. The lower value corresponds to the maximum allowable values for the mentioned dependent variables, while the upper value reflects the minimum allowable values for all specified parameters.

# Sizing Example

Calculate the size of an enhanced swale serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	70
Design Storm Depth, P	inches	1.0
Media porosity, n <sub>m</sub>		0.25
Drainage layer porosity, n <sub>d</sub>		0.40
Freeboard, f	feet	0.5
Drawdown (drain) Time, t	hours	48

1. Calculate the volumetric runoff coefficient (C) and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.0039 \times 70$$

$$C = 0.68$$

$$WQV = PCA \times 3,630$$

$$WQV = 1 \times 0.68 \times 1 \times 3,630$$

$$WQV = 2,468 \text{ cu-ft}$$

2. Select a media thickness (l<sub>m</sub>), drainage layer thickness (l<sub>d</sub>), ponding depth (d<sub>p</sub>), bottom width (b), and interior side slope (z):

$$1 = 18 \text{ in}$$

$$l_d = 6 \text{ in}$$

$$d_{p} = 12 \text{ in}$$

$$b = 8 ft$$

$$z = 3$$

3. Calculate the total effective storage depth:

$$d_{t} = [(d_{p}/2) + l_{m}n_{m} + l_{d}n_{d}]/12$$

$$d_{\star} = (6 + 18 + 0.25 + 6 \times 0.40)/12$$

$$d_t = 1,075 \text{ sq-ft}$$

4. Calculate the minimum invert area (A<sub>L</sub>) needed for the WQV and depths:

$$A_{b} = WQV/d_{t}$$
  
 $A_{b} = 2,468/1.075$   
 $A_{b} = 2,296 \text{ sq-ft}$ 

5. Calculate the total area required  $(A_{RMP})$ :


$$\begin{array}{lcl} A_{BMP} & = & \left[ \ b + 2z(f + d_p/12) \ \right] \times (A_b/b) \\ A_{BMP} & = & \left[ \ 8 + 2 \times 3 \times (0.5 + 12/12) \ \right] \times (2,296/8) \\ A_{BMP} & = & 4,879 \ \text{sq-ft} \end{array}$$

#### **Other Design Considerations**


- Landscape design should specify proper grass species based on specific site, soils and hydric conditions present along the channel. Vegetation should be designed for regular mowing, like a typical lawn, or less frequently (annually or semi-annually).
- Enhanced swales must be adequately designed to safely pass flows that exceed the design storm flows.

# **Construction/Inspection Considerations**

- Include directions in the specifications for use of appropriate fertilizer and soil amendments based on soil properties determined through testing and compared to the needs of the vegetation requirements.
- Install swales at the time of the year when there is a reasonable chance of successful establishment without irrigation; however, it is recognized that rainfall in a given year may not be sufficient and temporary irrigation may be used.
- If sod tiles must be used, they should be placed so that there are no gaps between the tiles; stagger the ends of the tiles to prevent the formation of channels along the swale or strip.
- Use a roller on the sod to ensure that no air pockets form between the sod and the soil.
- Where seeds are used, erosion controls will be necessary to protect seeds for at least 75 days after the first rainfall of the season.



Schematic of an Enhanced Swale



# **TC-10: Vegetated Swale**



BMP Category	
Retention	0
Biofiltration	•
Other	0

O&M Requirements	
Low	

Expected Pollutant Removals			
Nutrients	Low	Pesticides	Unknown
Sediment	Medium	Oil & Grease	Medium
Trash	Low	Metals	Medium
Pathogens	Low	Organic Compounds	Unknown

Kauai Federal Credit Union (courtesy of Group 70)

# **Description**

Sometimes referred to as a grass swale, grass channel, or biofiltration swale, a vegetated swale is a broad shallow earthen channel vegetated with erosion resistant and flood tolerant grasses. Runoff typically enters the swale at one end and exits at the other end.

# **Minimum Design Criteria**

Design Parameter	Units	Value
Maximum Interior Side Slope (length per unit height)		3:1
Maximum Flow Velocity	feet/second	1
Maximum Water Depth	inches	4
Minimum Hydraulic Residence Time	minutes	7
Maximum Bottom Width	feet	10
Minimum Freeboard	feet	0.5

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

- Step 1. Use the procedure presented previously to compute the WQF Rate.
- Step 2. Select initial values for swale bottom width (b), depth of flow (y), swale side slope (z), swale longitudinal slope (s), and hydraulic residence time (T).

Step 3. Calculate the cross-sectional area (A), wetted perimeter (WP), and hydraulic radius (R) using the dimensions established in Step 2:

$$A = (by/12) + (zy^{2}/144)$$

$$WP = b (2y/12)\sqrt{(1+z^{2})}$$

$$R = A/WP$$

Where A = Cross Sectional Area (sq-ft)

WP = Wetter Perimeter (ft) R = Hydraulic Radius (ft)

b = Swale Bottom Width from Step 2 (ft) y = Depth of Flow for WQV from Step 2 (in)

z = Swale Side Slope (length per unit height) from Step 2

Step 4. Calculate the design flow rate in the swale using the selected dimensions and Manning's Equation:

$$Q = (1.49AR^{2/3}s^{1/2})/n$$

Where Q = Design Flow Rate (cu-ft/sec)

A = Cross Sectional Area from Step 3 (sq-ft)

R = Hydraulic Radius from Step 3 (ft)

s = Longitudinal Slope from Step 2 (percent)

R = Manning's n value

Unless another value can be justified, use a Manning's n value of 0.20 for water quality calculations (lower values, such as 0.035, are only applicable for flood control calculations). If the calculated flow rate is not equal to or greater than the WQF from Step 1, decrease the tributary area and/or increase one or more swale dimensions (bottom width, depth of flow, side slope, or longitudinal slope) and repeat the calculations.

Step 5. Once an appropriate design flow rate is achieved, calculate the design flow velocity using the flow continuity equation:

$$V = Q/A$$

Where V = Design Flow Velocity (ft/sec)

Q = Design Flow Rate from Step 4 (cu-ft/sec)

A = Cross Sectional Area from Step 3 (sq-ft)

If the design flow velocity is greater than the maximum allowed velocity, either include check dams with vertical drops of no more than 12 inches, or revise one or more swale dimensions and repeat the calculations.

Step 6. Multiply the velocity by the hydraulic residence time to determine the length:

$$L = 60VT$$

Where L = Swale Length (ft)

T = Hydraulic Resistance Time from Step 2 (min)

V = Design Flow Velocity from Step 5 (ft/sec)

Step 7. Calculate the total area required  $(A_{BMP})$  taking into account the side slopes along the length of the swale and the freeboard:

$$A_{RMP} = [b + 2z(f + y/12)] \times L$$

Where  $A_{BMP}$  = Total Surface Area (sq-ft)

b = Swale Bottom Width from Step 2 (ft)

z = Interior Swale Side Slope (length per unit height) from Step2

y = Depth of Flow from WQV from Step 2 (in)

f = Freeboard (ft)

L = Swale Length from Step 6 (ft)

If the calculated are does not fit in the available area, reduce the drainage area, reduce the hydraulic residence time (if it is longer than the minimum), and/or revise one or more swale dimensions, and repeat the calculations.

### **Pretreatment Considerations**

Vegetated swales do not require pretreatment.

#### **Area Requirements**

A vegetated swale requires a footprint equivalent to 2% - 4% of its contributing impervious drainage area. The lower value corresponds to maximizing the flow depth and slope, while the upper value corresponds to maximizing the bottom width and slope.

#### Sizing Example

Calculate the size of a grass swale serving the runoff from a one acre parking lot. Assume the following design parameters:

Design Parameter	Units	Value
Weighted Runoff Coefficient, C		0.95
Rainfall Intensity, i	inches/hour	0.4
Interior Side Slope (length per unit height)		3
Manning's n value	-	0.20
Longitudinal Slope, s		0.016
Hydraulic Residence Time, T	minutes	7
Freeboard, f	feet	0.5

Storm Water BMP Guide for New and Redevelopment

1. Calculate the WQF Rate:

$$WQF = CiA$$

WQF = 
$$0.95 \times 0.4 \times 1.0$$

$$WQF = 0.38 \text{ cu-ft/sec}$$

2. Select initial values for swale bottom width (b), depth of flow (y), swale side slope length per unit height (z), swale longitudinal slope (s), and hydraulic residence time (T):

$$b = 2.75 \text{ ft}$$

$$y = 3.5 \text{ in}$$

$$z = 3 in$$

$$s = 0.017$$

$$T = 7 \text{ mins}$$

3. Calculate the cross-sectional area (A), wetted perimeter (WP), and hydraulic radius (R):

$$A = (by/12) + (zy^2/144)$$

$$A = (2.75 \times 3.5/12) + (3 \times 3.5^2/144)$$

$$A = 1.06 \text{ sq-ft}$$

WP = 
$$b + (2y/12)\sqrt{1+z^2}$$

WP = 
$$2.75 + (2 \times 3.5/12)\sqrt{(1+3^2)}$$

$$WP = 4.59 \text{ ft}$$

$$R = A/WP$$

$$R = 1.06/4.59$$

$$R = 0.23 \text{ ft}$$

4. Calculate the design flow rate (Q):

$$Q = 1.49 AR^{2/3}s^{1/2}/n$$

$$Q = 1.49 \times 1.06 \times 0.23^{2/3} \times 0.017^{1/2}/0.20$$

$$Q = 0.39 \text{ cu-ft/sec} (\geq WQF, OK)$$

5. Calculate the velocity in the swale (V):

$$V = Q/A$$

$$V = 0.39/1.06$$

$$V = 0.36 \text{ ft/sec} (< 1 \text{ ft/sec}, OK)$$

6. Calculate the minimum length of the swale (L):

$$L = 60 \times VT$$

$$L = 60 \times 0.36 \times 7$$

$$L = 153 \text{ ft}$$

7. Calculate the total area required  $(A_{RMP})$ :

```
A_{BMP} = [b + 2z(f + y/12)] \times L

A_{BMP} = [2.75 + 2 \times 3(0.5 + 3.5/12)] \times 153


A_{BMP} = 1,148 \text{ sq-ft}
```


# **Other Design Considerations**


- The calculated WQF may be reduced by 25% if the soil beneath the BMP is classified as Hydrologic Soils Group (HSG) "A" or "B", as reported by the USDA Natural Resources Conservation Service (http://websoilsurvey.nrcs.usda.gov/app/HomePage.htm), or if the soil beneath the BMP is amended by incorporating 6 inches of compost/amendments and tilled up to 8 inches.
- In cases where a vegetated swale is located on-line, it should be sized as a treatment facility and as a conveyance system per the CCH's standards for flood control.
- Vegetate the swale with dense turf grass to promote sedimentation, filtration, and nutrient uptake, and to limit erosion through maintenance of low flow velocities.
- Check dams may be used to achieve flow velocity requirements. They are often employed to enhance infiltration capacity, decrease runoff volume, rate, and velocity, and promote additional filtering and settling of nutrients and other pollutants.

#### **Construction/Inspection Considerations**

- Include directions in the specifications for use of appropriate fertilizer and soil amendments based on soil properties determined through testing and compared to the needs of the vegetation requirements.
- Install swales at the time of the year when there is a reasonable chance of successful establishment without irrigation; however, it is recognized that rainfall in a given year may not be sufficient and temporary irrigation may be used.
- If sod tiles must be used, they should be placed so that there are no gaps between the tiles; stagger the ends of the tiles to prevent the formation of channels along the swale or strip.
- Use a roller on the sod to ensure that no air pockets form between the sod and the soil.
- Where seeds are used, erosion controls will be necessary to protect seeds for at least 75 days after the first rainfall of the season.







# Schematic of a Vegetated Swale

# **TC-11: Vegetated Buffer Strip**



BMP Category		
Retention	0	
Biofiltration	•	
Other	0	

<b>O&amp;M Requirements</b>		
Low		

Expected Pollutant Removals			
Nutrients	Low	Pesticides	Unknown
Sediment	Medium	Oil & Grease	Medium
Trash	Medium	Metals	Medium
Pathogens	Low	Organic Compounds	Medium

Virginia DCR Stormwater Design Specification No. 2. 2001.

### **Description**

Sometimes referred to as a vegetated filter strip or biofiltration strip, a vegetated buffer strip is a grassy slope vegetated with turf grass that is designed to accommodate sheet flow. They may resemble natural ecological communities and remove pollutants by vegetative filtration.

# Minimum Design Criteria

Design Parameter	Units	Value
Maximum Flow Velocity	feet/second	1
Maximum Upstream Area Flow Length	feet	75
Minimum Length	feet	15
Maximum Flow Depth	inches	1

# **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

# **Sizing Procedure**

- Step 1. Use the procedure presented previously to compute the WQF Rate.
- Step 2. Select values for the buffer strip width (w) and buffer strip longitudinal slope (s). Note that if a strip width is selected that is not the same as the width of the upstream flow path, a transition structure will be necessary to capture all the runoff and/ or establish uniform sheet flow across the entire strip width.

Step 3. Compute the design flow depth for the WQF using a simplified form of Manning's Equation assuming a shallow flow depth:

$$y = 12 \times [nQ/1.49\sqrt{(s/100)}]^{0.6}$$

Where y = Design Flow Depth for WQF (in)

n = Manning's n Value

Q = WQF Rate from Step one (cu-ft/sec)

w = Design Width from Step 2 (ft)

s = Longitudinal Slope from Step 2 (percent)

Unless another value can be justified, use a Manning's n value of 0.25 for water quality calculations (lower values, such as 0.035, are only applicable for flood control calculations). If the calculated depth is greater than the maximum allowed depth, reduce the tributary area, increase the design width, or increase the longitudinal slope, and repeat the calculation.

Step 4. Calculate the Design flow velocity across the strip using the flow continuity equation:

$$V = 12Q/wy$$

Where V = Design Flow Velocity (ft/sec)

Q = WQF Rate from Step 1 (cu-ft/sec)

w = Design Width from Step 2 (ft)

d = Design Flow Depth from Step 3 (in)

If the design flow velocity is greater than the maximum allowed velocity, revise one or more design parameters and repeat the calculations.

Step 5. Select a design buffer strip length (L) equal to or greater than the minimum length, and calculate the total BMP area:

$$L = 20.0 ft$$
$$A_{BMP} = L \times w$$

Where  $A_{BMP}$  = Vegetated Buffer Strip Area (sq-ft)

L = Design Length (ft)

w = Design Width from Step 2 (ft)

#### **Pretreatment Considerations**

Vegetated Buffer Strips do not require pretreatment.

#### **Area Requirements**

A vegetated buffer strip requires a footprint equivalent to no less than 0.4% of its contributing impervious drainage area. While there is no upper value because there is no maximum design width or design length, the minimum footprint corresponds to the minimum length and the maximum slope and minimum width combination that provide the maximum allowable design depth.

#### Sizing Example

Calculate the size of a vegetated buffer strip serving the runoff from a one acre parking lot. Assume the following design parameters:

Design Parameter	Units	Value
Weighted Runoff Coefficient, C		0.95
Rainfall Intensity, i	inches/hour	0.4
Manning's n value	-	0.25
Longitudinal Slope		0.06

1. Calculate the WQF Rate:

$$WQF = CiA$$

$$WQF = 0.95 \times 0.4 \times 1.0$$

$$WQF = 0.38 \text{ cu-ft/sec}$$

2. Select a design buffer strip width (w) and longitudinal slope (s):

$$w = 20.0 \text{ ft}$$
  
 $s = 0.06$ 

3. Calculate the depth of flow for the WQF (y):

```
y = 12 \times (\text{WQF} \times \text{n/1.49w/s})^{0.6}
y = 12 \times [0.38 \times 0.25/1.49 \times 20\sqrt{(0.06]})^{0.6}
y = 0.89 \text{ in } (\le 1 \text{ in, OK})
```

4. Calculate the velocity across the buffer strip (V):

$$V = 12 \times WQF/(yw)$$
  
 $V = 12 \times 0.38/(0.89 \times 20.0)$   
 $V = 0.26 \text{ cu-ft/sec} (\le 1 \text{ cu-ft/sec}, OK)$ 

5. Select a design buffer strip length (L) at least equal to the minimum required length, and calculate the total BMP area (A<sub>BMP</sub>):


$$\begin{array}{lll} A_{BMP} & = & L \times w \\ A_{BMP} & = & 20 \times 20 \\ A_{BMP} & = & 400 \text{ sq-ft} \end{array}$$


#### **Other Design Considerations**

- The calculated WQF may be reduced by 25% if the soil beneath the BMP is classified as Hydrologic Soils Group (HSG) "A" or "B," as reported by the USDA Natural Resources Conservation Service (http://websoilsurvey.nrcs.usda.gov/app/HomePage.htm), or if the soil beneath the BMP is amended by incorporating 6 inches of compost/ amendments and tilled up to 8 inches.
- A pea gravel diaphragm or engineered level spreader should be provided at the upper edge of the BMP when the width of the contributing drainage area is greater than that of the filter. Level spreader options include porous pavement strips, stabilized turf strips, slotted curbing, rock-filled trench, or concrete sills.
- The selection of plants should be based on their compatibility with climate conditions, soils and topography, and their ability to tolerate urban stresses from pollutants, variable soil moisture conditions and ponding fluctuations.

# **Construction/Inspection Considerations**

Vegetated filter strips should protected with temporary sediment and erosion control BMPs until contributing areas are stabilized.





Schematic of a Vegetated Buffer Strip

# **TC-12: Harvest/Reuse**



BMP Category		
Retention	•	
Biofiltration	0	
Other	0	

<b>O&amp;M Requirements</b>		
Low		

Expected Pollutant Removals			
Nutrients	Low	Pesticides	Unknown
Sediment	Medium	Oil & Grease	Medium
Trash	Medium	Metals	Medium
Pathogens	Low	Organic Compounds	Medium

Hawaii Baptist Academy (Courtesy of Group 70)

### **Description**

Sometimes referred to as capture/reuse or rainwater harvesting, is the collection and temporary storage of roof runoff in rain barrels or cisterns for subsequent non-potable outdoor use (landscape irrigation, vehicle washing).

# Minimum Design Criteria

One of two equivalent performance standards shall be met:

- 1. Harvest and use BMP is designed to capture at least 80% of average annual (long term) runoff volume and meet 80% of the annual overall demand.
- 2. Harvest and use BMPs are sized to drain the tank in 48 hrs following the end of rainfall. The size of the BMP is dependent on the demand at the site.

It is rare cisterns can be sized to capture the full WQV and use this volume in 48 hrs. So when using Infeasibility worksheets in the *Water Quality Rules* Appendix F, if it is determined that harvest and use BMP is feasible then the BMP should be sized to the estimated 48-hr demand. The remaining WQV not captured needs to be either retained onsite or, if infeasible, treated with biofiltration per the requirements in Section 1.3.

#### **Feasibility Criteria**

See Section 5.5: Feasibility Criteria.

### **Sizing Procedure**

Step 1. Define the irrigation demand by selecting values for the irrigation area (A<sub>i</sub>), pan evaporation coefficient (K<sub>p</sub>), landscape coefficient (K<sub>l</sub>), irrigation system efficiency (e). Unless specific data is available, use a value of 0.80 for K<sub>p</sub> (Guidelines for the Reuse of Gray Water), 0.60 for

K<sub>1</sub> (warm season turfgrass, *A Guide to Estimating Irrigation Water Needs of Landscape Plantings in California*), and 0.90 for e (well-designed system, *Estimating Irrigation Water Needs of Landscape Plantings in California*).

- Step 2. Define the non-irrigation demand (D<sub>0</sub>) which may include other non-potable use.
- Step 3. Define the runoff available for reuse by selecting values for the drainage (i.e., roof) area (A<sub>d</sub>), percent of impervious cover (I), and cistern size (C).
- Step 4. Identify the project's nearest reference point (Makakilo City, Waimanalo, Waialua, Village Park, Waianae, UH Mauka, Mililani, Opaeula, Maunawili, and Kalihi Valley) and use the corresponding monthly rainfall rates and monthly pan evaporation rates (E<sub>pap</sub>).
- Step 5. Perform a month-to-month analysis, starting with January and ending with December. Set the beginning cistern volume in January to 0.
  - Step 5a. Calculate the reference evapotranspiration rate for the month using the pan evaporation rate and the pan evaporation coefficient:

$$ET_0 = E_{pan} \times K_p$$

Where  $ET_0 = \text{Reference Evapotranspiration Rate for the Month (in)}$ 
 $E_{pan} = \text{Pan Evaporation Rate for the Month (in) from Step 4}$ 
 $K_p = \text{Pan Evaporation Coefficient from Step 1}$ 

Step 5b. Calculate the actual evapotranspiration rate for the month using the reference evapotranspiration rate and the landscape coefficient:

$$ET_a = ET_o \times K_l$$

Where  $ET_a = Actual$  Evapotranspiration Rate for the Month (in)

 $ET_o = Reference$  Evapotranspiration Rate from Step 5a

 $K_i = Landscape$  Coefficient from Step 1

Step 5c. Calculate the total demand for the month by multiplying the irrigation area by the difference between the actual evapotranspiration rate and the rainfall, and adding the non-irrigation demand:

$$\begin{aligned} \boldsymbol{D}_t &= 7.48 \times A \times (\boldsymbol{ET_a - r})/(12 \times \boldsymbol{e}) + \boldsymbol{D}_{\theta} \\ \text{Where} \quad & D_t &= \text{Total Demand for the Month (gallons)} \\ & A &= \text{Irrigation Area from Step 1 (sq-ft)} \\ & ET_a &= \text{Actual Evapotranspiration Rate from Step 5b} \\ & r &= \text{Total Rainfall for the Month (in) from Step 4} \\ & e &= \text{Irrigation System Efficiency from Step 1} \\ & D_0 &= \text{Other Non-Irrigation Demand for the Month (gallons)} \\ & \text{from Step 2} \end{aligned}$$

If the total demand for the month is negative (because the rainfall amount exceeds the evapotranspiration rate), set the total demand to 0.

Step 5d. Calculate the amount of runoff generated for the month by multiplying the drainage area by the rainfall by the volumetric runoff coefficient:

$$R_{g} = 7.48 \times A_{d} \times r \times (0.05 + 0.009 \times I)/12$$

Where  $R_{\sigma}$  = Runoff Generated for the Month (gallons)

 $A_d$  = Drainage Area from Step 2 (sq-ft)

r = Total Rainfall for the Month (in) from Step 4

I = Percent of Impervious Cover from Step 3 (percent)

Step 5e. Compare the total demand  $(D_t)$  to the amount of runoff in the cistern at the beginning of the month  $(C_b)$  plus the runoff generated during the month (R). If the monthly demand is greater, set the amount of runoff reused  $(R_u)$  to the sum of  $C_b$  and R. If the monthly demand is less, set the amount of runoff reused to  $D_t$ .

Step 5f. Compare the Cistern capacity (C) to the amount in the cistern at the beginning of the month  $(C_b)$  plus the Runoff generated during the month  $(R_g)$  minus the amount of runoff used  $(R_u)$ . Set the amount of runoff in the cistern at the end of the month  $(C_c)$  to the lower of the two values.

Step 5g. Calculate the amount of cistern overflow by the following:

$$O = C_b + R_g - D_t - C_e$$

Where O = Total Cistern Overflow for the Month (gallons)

C<sub>b</sub> = Amount of Runoff in Cistern at the beginning of the

Month (gallons)

 $R_g$  = Runoff Generated for the Month (gallons)

D<sub>t</sub> = Total Demand for the Month (gallons)

 $C_e$  = Amount of Runoff in Cistern at the end of the Month

(gallons)

If the overflow is negative (because the amount of runoff in the cistern at the end of the month is less than the cistern capacity), set the overflow to 0.

Step 5h. Calculate the amount of runoff captured in the cistern by subtracting the Overflow from the amount of runoff generated:

$$R_c = R_g - O$$

Where  $R_{c}$  = Runoff Capture in the Cistern for the Month (gallons)

 $R_{_{\sigma}}$  = Runoff Generated for the Month (gallons)

O = Total Cistern Overflow for the Month (gallons)

Step 5i. Set the beginning cistern amount for the next month equal to the ending cistern amount for the current month. Repeat Steps 5 through 13 for each subsequent month. Continue on to Step 5 after Steps 4a through 4i have been performed for all 12 months.

Step 6. Calculate the overall runoff capture efficiency by dividing the cumulative runoff captured by the cumulative runoff generated:

$$E_c = 100 \times \sum_{1}^{12} R_c / \sum_{1}^{12} R_g$$
Where  $E_c = \text{Overall Runoff Capture Efficiency (percent)}$ 

$$R_c = \text{Runoff Capture from each Month (gallons)}$$

$$R_g = \text{Runoff Generated from each Month (gallons)}$$

If the calculated efficiency is below the minimum design criteria value, revise one or more of the following parameters and return to Step 3: drainage area  $(A_d)$ , cistern size (C), irrigation area  $(A_d)$ , and other non-irrigation demand  $(D_0)$ .

Step 7. Calculate the overall demand met efficiency by dividing the cumulative runoff used by the cumulative demand:

$$E_{d} = 100 \times \sum_{1}^{12} R_{u} / \sum_{1}^{12} D_{t}$$
Where  $E_{d} = \text{Overall Demand Met Efficiency (percent)}$ 

$$R_{u} = \text{Runoff Used from each Month (gallons)}$$

$$D_{t} = \text{Total Demand from each Month (gallons)}$$

If the calculated efficiency is below the minimum design criteria value, revise one or more of the following parameters and return to Step 3: drainage area  $(A_d)$ , cistern size (C), irrigation area  $(A_i)$ , and other non-irrigation demand  $(D_0)$ .

### **Pretreatment Considerations**

Roof gutter guards or leaf gutter screens are required for roof runoff to reduce dry well clogging from sediment, leaves, and other organic material.

### **Area Requirements**

Rain barrel/cistern sizes can vary greatly depending on the project area, roof size, and irrigation area. The size can be anywhere from less than 1,000 gallons to more than 10,000 gallons per 1,000 sq-ft of roof area.

B-62

### Sizing Example

Calculate the size of a cistern serving the roof runoff from an 800 sq-ft auto repair shop in Kapolei. Assume the following design parameters:

Design Parameter	Units	Value
Minimum overall runoff capture efficiency, E <sub>c</sub>	percent	80
Minimum overall demand met efficiency, E <sub>d</sub>	percent	80

1. Select initial demand values for the Irrigation Area  $(A_i)$ , pan evaporation coefficient  $(K_p)$ , landscape coefficient  $(K_l)$ , irrigation system efficiency (e), and non-irrigation demand  $(D_0)$ :

$$A_{i}$$
 = 115 sq-ft  
 $K_{p}$  = 0.80  
 $K_{1}$  = 0.60  
 $E_{0}$  = 0.90  
 $E_{0}$  = 0

2. Select initial values for the drainage area (A<sub>d</sub>), percent of impervious cover (I), and cistern size (C):

$$A_d$$
 = 800 sq-ft  
I = 100%  
C = 5,000 gallons

- 3. The nearest reference point to Kapolei is Makakilo City.
- 4a. Calculate the monthly reference evapotranspiration rates (ET<sub>0</sub>). The calculation for January is as follows, and the results for the entire year are provided in the table in #4c.

$$\begin{array}{rcl} {\rm ET_0} & = & {\rm E_{pan}} \times {\rm K_1} \\ {\rm ET_0} & = & 5.46 \times 0.8 \\ {\rm ET_0} & = & 4.37 \ {\rm in} \end{array}$$

4b. Calculate the actual evapotranspiration rates  $(ET_a)$ . The calculation for January is as follows, and the results for the entire year are provided in the table in #4c.

$$ET_a = ET_0 \times K_1$$

$$ET_a = 4.37 \times 0.6$$

$$ET_a = 2.62 \text{ in}$$

4c. Calculate the total demand (D<sub>i</sub>). The calculation for January is as follows, and the results for the entire year are provided in the table below.

$$D_{t} = 7.48A_{i} (ET_{i} - r)/(12e) + D_{0}$$

$$D_{t} = 7.48 \times 115 \text{ x} (2.62 - 2.58)/(12 \times 0.9) + 0$$

$$D_{t} = 3 \text{ gallons}$$

Month	Rainfall (inches)	P (inches)	ET <sub>0</sub> (inches)	ET <sub>a</sub> (inches)	D <sub>t</sub> (gallons)
January	2.58	5.46	4.37	2.62	3
February	3.05	5.75	4.60	2.76	0
March	1.87	7.12	5.70	3.42	123
May	1.12	7.75	6.20	3.72	207
May	0.86	8.41	6.73	4.04	253
June	0.55	8.99	7.19	4.32	300
July	0.58	9.74	7.79	4.68	326
August	0.48	9.65	7.72	4.63	331
September	0.74	8.48	6.78	4.07	265
October	2.00	7.54	6.03	3.62	129
November	2.06	6.29	5.03	3.02	76
December	2.69	5.59	4.47	2.68	0

4d. Calculate the generated roof runoff ( $R_{\rm o}$ ). The calculation for January is as follows, and the results for the entire year are provided in the table below:

$$R_{\sigma} = 7.48 A_{d} r (0.05 + 0.009 I)/12$$

$$R_{g} = 7.48 \times 800 \times 2.58 (0.05 + 0.009 \times 100)/12$$

$$R_g = 1,222 \text{ gallons}$$

4e. Calculate the runoff used (R<sub>n</sub>) by comparing the total demand (D<sub>1</sub>) to the amount of runoff in the cistern at the beginning of the month (C<sub>b</sub>) plus the runoff generated during the month (R). The calculation for January is as follows, and the results for the entire year are provided in the table below:

$$C_b = 0$$
 gallon

$$C_b$$
 = 0 gallon  
 $R_u$  =  $D_t$  = 3 gallons [ since  $R_g + C_b > D_t$  ]

4f. Calculate the amount of runoff in the Cistern at the end of the month (C<sub>s</sub>) by setting it to the lower value of the amount of runoff in the Cistern at the beginning of the month (C<sub>b</sub>) plus the runoff generated (R<sub>o</sub>) minus the runoff used (R<sub>o</sub>), and the cistern capacity (C). The calculation for January is as follows, and the results for the entire year are provided in the table below:

$$C_e = min(C_b + R_g - R_u, C)$$

$$C_e = min(C_b + R_g - R_u, C)$$
  
 $C_e = min(0 + 1,222 - 3, 500)$ 

$$C_e = 1,219 \text{ gallons}$$

4g. Calculate the Cistern overflow (O). The calculation for January is as follows, and the results for the entire year are provided in the table below:

$$O = C_b + R_g - D_t - C_e$$

$$O = 0 + 1,222 - 3 - 1,219$$

- = 0 gallons O
- 4h. Calculate the runoff captured in Cistern (R<sub>c</sub>). The calculation for January is as follows, and the results for the entire year are provided in the table below:

$$R_c = R_g - O$$

$$R_{c} = R_{g} - O$$
 $R_{c} = 1,222 - 0$ 

$$R_c = 1,222 \text{ gallons}$$

4i. Set  $C_b$  for the next month equal to  $C_e$  of the previous month and repeat the calculations.

Month	r (inches)	D (gallong)	R <sub>g</sub>	C <sub>b</sub>	C <sub>e</sub>	R <sub>u</sub>	(gallang)	R
	(inches)	(gallons)	(gallons)	(gallons)	(gallons)	(gallons)	(gallons)	(gallons)
January	2.58	3	1,222	0	1,219	3	0	1,222
February	3.05	0	1,445	1,219	2,664	0	0	1,445
March	1.87	123	886	2,664	3,426	123	0	886
May	1.12	207	531	3,426	3,750	207	0	531
May	0.86	253	407	3,750	3,904	253	0	407
June	0.55	300	261	3,904	3,865	300	0	261
July	0.58	326	275	3,865	3,814	326	0	275
August	0.48	331	227	3,814	3,710	331	0	227
September	0.74	265	351	3,710	3,796	265	0	351
October	2.00	129	947	3,796	4,614	129	0	947
November	2.06	76	976	4,614	5,000	76	514	462
December	2.69	0	1,274	5,000	5,000	0	1,274	0
Total	18.58	2,014	8,802			2,014	1,788	7,014

5. Calculate the overall runoff capture efficiency  $(E_a)$  and overall demand efficiency  $(E_a)$ :

$$E_{c} = 100 \times \sum_{1}^{12} R_{c} / \sum_{1}^{12} R_{g}$$

$$E_c = 100 \times 7,014/8,802$$

$$E_c = 80\%$$

$$E_{d} = 100 \times \sum_{1}^{12} R_{u} / \sum_{1}^{12} D_{t}$$

$$E_d = 100 \times 2,014/2,014$$


$$E_{d} = 100\%$$


6. Calculate the WQV for which credit is received:

 $WQV = PCA \times 3,360$   $WQV = 1 \times (0.05 + 0.009 \times 100) \times (800/43,560) \times 3,360$ WQV = 63 cu-ft

### **Other Design Considerations**

- Local pan evaporation and rainfall data may be used if available.
- Tanks should have tight fitting covers to exclude contaminants and animals, and above ground tanks should not allow penetration of sunlight to limit algae growth
- In areas where the tank is to be buried partially below the water table, special design features must be employed to keep it from "floating."





Schematic of a Harvesting/Reuse System

# **TC-13: Detention Basin**



BMP Category		
Retention		
Biofiltration	0	
Other	•	

<b>O&amp;M Requirements</b>
Low

	<b>Expected Pollutant Removals</b>				
Nutrients	Low	Pesticides	Unknown		
Sediment	Medium	Oil & Grease	Medium		
Trash	High	Metals	Low/Med		
Pathogens	Low	Organic Compounds	Unknown		

Miliani Mauka

### **Description**

Sometimes referred to as a dry extended detention basin, a detention basin is a shallow man-made impoundment intended to provide for the temporary storage of storm water runoff to allow particles to settle. It does not have a permanent pool and is designed to drain between storm events.

### **Minimum Design Criteria**

Design Parameter	Units	Value
Maximum Interior Side Slope (length per unit height)		3:1
Minimum length to width ratio		2:1
Maximum depth	feet	8
Drawdown (drain) time for WQV	hours	48
Drawdown (drain) time for 50% of WQV	hours	24-36
Basin invert slope	percent	1-2
Minimum outlet size	inches	4
Minimum freeboard	feet	1

### **Feasibility Criteria**

Detention Basins are considered infeasible for any of the following conditions:

- Basin invert would be below seasonally high groundwater table.
- Unable to operate off-line and unable to operate in-line with safe overflow mechanism.
- Excavation would disturb iwi kupuna or other archaeological resources.
- Unable to meet minimum length to width ratio design criteria naturally or artificially.

### **Sizing Procedure**

Detention Basins are sized using detailed routing calculations to demonstrate that the storage volume is adequate. However, a reasonable first estimate can be determined using the following simple routing method which assumes triangular hydrographs for the inflow and outflow.

- Step 1. Use the procedure presented previously to compute the pre-project (i.e., undeveloped) and post-project (i.e., developed) weighted runoff coefficients.
- Step 2. Compute the peak inflow rate using the Rational Method:

$$q_i = C_a iA$$

Where  $q_i$  = Peak Inflow Rate into Basin (cu-ft)

 $C_a$  = Post-Project Weighted Runoff Coefficient

 $i$  = Peak Rainfall Intensity (in/hr)

Step 3. Compute the peak outflow rate using the pre-project runoff coefficient, which effectively forces the detention basin to maintain pre-project discharge rates:

= Drainage Area (acres)

$$q_o = C_b iA$$

Where  $q_o = Peak$  Inflow Rate leaving Basin (cu-ft)

 $C_b = Pre-Project$  Weighted Runoff Coefficient

 $i = Peak$  Rainfall Intensity (in/hr)

 $A = Drainage$  Area (acres)

Step 4. Calculate the estimated basin storage volume:

```
s = 3,630 \times PA \left[1 - \left(\frac{q}{o} / q_i\right)\right]
Where s = Storage Volume in the Basin (cu-ft)
P = Design Storm Runoff Depth (in)
A = Drainage Area (acres)
q_o = Peak Outflow Rate from Step 3 (cu-ft)
q_i = Peak Inflow Rate from Step 2 (cu-ft)
```

Step 5. Select initial values for the detention basin total width (w<sub>t</sub>), total length (l<sub>t</sub>), and depth (d) based on space availability, topography and existing drainage facilities. Also select values for the interior side slopes (z) and required freeboard (f). Calculate the basin invert width and invert length:

$$w_b = w_t - 2z(d+f)$$

$$l_b = l_t - 2z(d+f)$$
Where  $w_b$  = Basin Bottom Width (ft)
$$l_b = Basin Bottom Length (ft)$$

$$w_t = Basin Total Width (ft)$$

$$l_t = Basin Total Length (ft)$$

$$z = Basin Interior Side Slope (length per unit height)$$

$$d = Depth of Flow for Storage Volume (ft)$$

$$f = Freeboard (ft)$$

Step 6. Calculate the resulting storage volume using the prismoidal formula for trapezoidal basins:

```
V = w_b l_b d + (w_b + l_b) z d^2 + 4z^2 d^3/3

Where V = \text{Volume of Trapezoidal Basin (cu-ft)}

w_b = \text{Basin Bottom Width from Step 5 (ft)}

l_b = \text{Basin Bottom Length from Step 5 (ft)}

d = \text{Depth of Flow for Storage Volume from Step 5 (ft)}

z = \text{Basin Interior Side Slope from Step 5}
```

Compare the calculated volume (V) to the required volume (s) from Step 4. If the calculated volume is greater than or equal to the required volume, the selected dimensions  $(w_t$  and  $l_t$ ) and depth (d) are adequate for preliminary design. If the calculated volume is less than the required volume, increase one or both of the dimensions and/or the depth (d) and repeat Steps 5 and 6. If the footprint area and depth are set to maximum allowable values based on site characteristics and the calculated volume is still less than the required volume, reduce the drainage area (A) and repeat Steps 2 through 6.

### **Pretreatment Considerations**

If significant amounts of sediment or sand are anticipated at the site, sediment forebays should be located at each major inlet to provide pretreatment, preserve the capacity of the basin, and reduce maintenance requirements in the basin. The forebay consists of a separate cell that drains into the main basin, formed by an acceptable barrier, such as an earthen berm or gabion baskets, etc.). If used, the total volume of all forebays should be at least 5% of the total WQV.

### **Area Requirements**

A detention basin requires a footprint equivalent to 1% - 9% of its contributing impervious drainage area. The actual value is dependent on a number of variables, including the drainage area, pre-project and post-

project runoff coefficients, and basin depth. Footprints at the lower range reflect deep basins (e.g., 8 ft) serving large drainage areas (e.g., 50 acres), while footprints at the upper range reflect shallow basins (e.g., 1 ft) serving small drainage areas (e.g., 1 acre).

### Sizing Example

Calculate the preliminary size of a detention basin serving the runoff from a one acre parking lot. Assume the following design parameters:

Design Parameter	Units	Value
Rainfall Intensity, i	inches/hour	0.4
Runoff Volume, Q	inches	1
Basin Interior Side Slope (length per unit height), z		3
Freeboard, f	feet	1

1. Compute the pre-project (i.e., undeveloped) and post-project (i.e., developed) weighted runoff coefficients:

$$C_b = 0.20$$
  
 $C_a = 0.95$ 

2. Compute the peak inflow rate:

$$\begin{array}{lll} q_{_{i}} & = & C_{_{a}}iA \\ q_{_{i}} & = & 0.95 \times 0.40 \times 1 \\ q_{_{i}} & = & 0.38 \; cu\mbox{-ft} \end{array}$$

3. Compute the peak outflow rate:

$$q_o = C_b iA$$
  
 $q_o = 0.20 \times 0.40 \times 1$   
 $q_o = 0.08 \text{ cu-ft}$ 

4. Calculate the estimated basin storage volume:

```
s = 3,630 \times PA[1 - (q_o/q_i)]

s = 3,630 \times 1 \times 1 \times [1 - (0.08/0.38)]

s = 2,866 cu-ft
```

5. Select initial values for the detention basin total width (w<sub>t</sub>), total length (l<sub>t</sub>), depth (d), interior side slopes (z) and required freeboard (f):

$$w_t = 38 \text{ ft}$$
 $l_t = 53 \text{ ft}$ 
 $d = 3.5 \text{ ft}$ 
 $z = 3 \text{ ft}$ 
 $f = 1 \text{ ft}$ 

Calculate the basin bottom width and length:

$$w_{b} = w_{t} - 2z(d + f)$$

$$w_{b} = 38 - 2 \times 3 \times (3.5 + 1)$$

$$w_{b} = 11 \text{ ft}$$

$$l_{b} = l_{t} - 2z(d + f)$$

$$l_{b} = 53 - 2 \times 3 \times (3.5 + 1)$$

$$l_{b} = 26 \text{ ft}$$

6. Calculate the resulting storage volume using the prismoidal formula for trapezoidal basins:

$$V = w_b l_b d + (w_b + l_b) z d^2 + 4 z^2 d^3 / 3$$

$$l_t = 11 \times 26 \times 3.5 + (11 + 26) \times 3 \times 3.5^2 + 4 \times 3^2 \times 3.5^3 / 3$$

$$d = 2.875 \text{ cu-ft}$$

The calculated volume is greater than the required volume, so the preliminary design is acceptable.


### **Other Design Considerations**

- Credit for infiltration may be given if the soils beneath the detention basin invert have a measured infiltration rate of at least 0.5 inches per hour and none of the infeasibility criteria for infiltration basins are applicable. However, low flow channels should not be included if infiltration is expected.
- If a temporarily-filled pond creates a potential public safety issue, perimeter fencing may be considered. Warning signs should be used wherever appropriate
- In order to meet designs storm requirements, detention basins should have a multistage outlet structure. Three elements are typically included in this design:
  - 1. A low-flow outlet that controls the extended detention and functions to slowly release the water quality design storm.
  - 2. A primary outlet that functions to attenuate the peak of larger design storms.
  - 3. An emergency overflow outlet/spillway
- Design methodology options are provided in manuals included in the References, including the Georgia Stormwater Management Manual, the Urban Storm Drainage Criteria Manual, and the USEPA Stormwater Best Management Practice Design Guide.

### **Construction/Inspection Considerations**

- Inspect facility after first large storm to determine whether the desired residence time has been achieved.
- When constructed with small tributary area, orifice sizing is critical and inspection should verify that flow through additional openings such as bolt holes does not occur.

B-71



**Schematic of a Detention Basin** 

# **TC-14: Manufactured Treatment Device**



BMP Category	
Retention	
Biofiltration	0
Other	•

<b>O&amp;M Requirements</b>	
Low to Medium	
<u> </u>	

Expected Pollutant Removals	
Varies based on System	

### **Description**

A manufactured treatment device is a proprietary water quality structure utilizing settling, filtration, adsorptive/absorptive materials, vortex separation, vegetative components, or other appropriate technology to remove pollutants from storm water runoff.

## **Minimum Design Criteria**

Design Parameter	Units	Value
Minimum Total Suspended Solids water (TSS) Removal	Percent	80

### **Feasibility Criteria**

Manufactured treatment devices are considered infeasible for any of the following conditions:

- Bottom of BMP is below seasonally high groundwater table.
- Unable to operate off-line and unable to operate in-line with safe overflow mechanism.
- Excavation would disturb iwi kupuna or other archaeological resources.

### **Sizing Procedure**

Follow the manufacturer's guidelines for appropriate sizing calculations and selection of appropriate device/model.

### **Pretreatment Considerations**

No pretreatment is required.

### **Area Requirements**

The footprint requirements for proprietary manufactured treatment devices vary by manufacturer.

### Sizing Example

No example is provided as sizing procedures vary by manufacturer, and presenting any specific product might be interpreted as an endorsement.

### **Other Design Considerations**

- The device must provide a TSS removal rate of 80%, certified for general use by the Washington State Department of Ecology Technology Assessment Protocol (TAPE) or certified by the New Jersey Department of Environmental Planning (NJDEP).
- Systems not meeting the required TSS removal criteria can be used as pre-treatment for other BMPs.
- Although the device must meet TSS requirements, many manufactured treatment devices also treat other pollutants. The City recommends selecting devices capable of treating the potential pollutants at your site.
- All manufactured treatment devices must be able to safely overflow or bypass flows in excess of the storm water quality design storm to downstream drainage systems.

### **Construction/Inspection Considerations**

Follow manufacturer's recommendations.

B-74

# **TC-15: Sand Filter**



BMP Category	
Retention	0
Biofiltration	0
Other	•

O&M Requirements	
Medium	
Medium	

Expected Pollutant Removals			
Nutrients	Low/Med	Pesticides	Unknown
Sediment	High	Oil & Grease	High
Trash	High	Metals	Med/High
Pathogens	Medium	Organic Compounds	Med/High

Portland Stormwater Management Manual, 2004.

### **Description**

A sand filter is an open chambered structure that captures, temporarily stores, and treats storm water runoff by passing it through sand.

### Minimum Design Criteria

Design Parameter	Units	Value
Sand Coefficient of Permeability	feet/day	3.5
Filter media depth	inches	18
Drawdown (drain) Time	hours	48
Maximum Interior Side Slope if earthen (length per unit height)		3:1
Minimum Underdrain Diameter	inches	6

## **Feasibility Criteria**

Sand filters are considered infeasible for any of the following conditions:

- Bottom of BMP is below seasonally high groundwater table.
- Unable to operate off-line and unable to operate in-line with safe overflow mechanism.
- Excavation would disturb iwi kupuna or other archaeological resources.
- Site lacks sufficient hydraulic head to support BMP operation by gravity.

### **Sizing Procedure**

Step 1. Use the procedure presented previously to compute the Volumetric Runoff Coefficient and WQV.

Step 2. Select values for the filter media depth (l<sub>m</sub>) and maximum ponding depth (d<sub>n</sub>).

Step 3. Use Darcy's Law to calculate the required Filter Bed Surface Area:

$$A_{fb} = (WQV \times l_m)/[k(l_m + d_p/24)(t/24)]$$
Where  $A_{fb}$  = Filter Bed Surface Area (sq-ft)
$$WQV = WQV \text{ from Step 1 (cu-ft)}$$

$$l_m = \text{Filter Media Depth from Step 2 (ft)}$$

$$k = \text{Filter Media Permeability Coefficient (ft/day)}$$

$$d_p = \text{Maximum Ponding Depth from Step 2 (in)}$$

$$t = \text{Filter Bed Drain Time (hr)}$$

Step 4. Calculate the total area occupied by the BMP  $(A_{BMP})$  using the embankment side slopes and assuming a square basin:

$$A_{BMP} = [\sqrt{A_{fb}}] + 2z(d_p/12 + f)]^2$$
Where  $A_{BMP} = A$  rea Occupied by BMP (sq-ft)
$$A_{fb} = F$$
 ilter Bed Surface Area from Step 3 (sq-ft)
$$z = F$$
 ilter Bed Interior Side Slope (length per unit height)
$$d_p = M$$
 maximum Ponding Depth from Step 2 (in)
$$f = F$$
 reeboard (ft)

If the calculated area does not fit in the available space, either reduce the drainage area, increase the ponding depth, and/or increase the interior side slope (if it's not already set to the maximum) and repeat the calculations.

### **Pretreatment Considerations**

Pretreatment is required for sand filters in order to reduce the sediment load entering the sand bed, prevent premature clogging, and ensure filter longevity. The pretreatment device must be sized for at least 25% of the WQV, and may be achieved with vegetated swales, vegetated filter strips, sedimentation basins or forebays, sedimentation manholes, and manufactured treatment devices. The typical method is a sedimentation basin that has a length to width ratio of 2:1, and is sized using the Camp-Hazen equation.

### **Area Requirements**

A sand filter requires a footprint equivalent to 1.5% - 3% of its contributing impervious drainage area, excluding pretreatment. The lower value reflects minimum filter media and ponding depths, while the upper value reflects higher filter media and ponding depths.

B-76

### Sizing Example

Calculate the size of a sand filter serving a 1-acre residential development. Assume the following design parameters:

Design Parameter	Units	Value
Percent Impervious Cover, I	percent	70
Design Storm Depth, P	inches	1.0
Sand Coefficient of Permeability, k	feet/day	3.5
Interior Side Slope (length per unit height)		3:1
Freeboard	feet	0.5
Drawdown (drain) Time, t	hours	48

1. Calculate the volumetric runoff coefficient and WQV:

$$C = 0.05 + 0.009I$$

$$C = 0.05 + 0.009 \times 70$$

$$C = 0.68$$

$$WQV = PCA \times 3,630$$

$$WQV = 1 \times 0.68 \times 1 \times 3,630$$

$$WQV = 2,468 \text{ cu-ft}$$

2. Select a filter media depth  $(l_m)$  and maximum ponding depth  $(d_n)$ :

$$l_m = 1.5 \text{ ft}$$

$$d_p = 24 \text{ in}$$

3. Calculate the Filter Bed Surface Area (A<sub>ft</sub>):

$$A_{fb} = (WQV \times l_m)/[k(l_m + d_p/24)(t/24)]$$

$$A_{fb} = (2,468 \times 1.5)/[3.5(1.5 + 24/24)(48/24)]$$

$$A_{fb} = 212 \text{ sq-ft}$$

4. Calculate the total area occupied by the BMP  $(A_{BMP})$ :

$$A_{BMP} = [\sqrt{(A_{fb})} + 2z(d_p/12 + f)]^2$$

$$A_{BMP} = [\sqrt{(212)} + 2 \times 3(24/12 + 0.5)]^2$$


$$A_{BMP} = 873 \text{ sq-ft}$$

### **Other Design Considerations**

- A flow spreader should be installed at the inlet along one side of the filter to evenly distribute incoming runoff across the filter and to prevent erosion of the filter device.
- A cleanout pipe should be tied into the end of all underdrain pipe runs.

### **Construction/Inspection Considerations**

Tributary area should be completely stabilized before media is installed to prevent premature clogging.



**Schematic of a Sand Filter** 

# **Appendix C: O&M Fact Sheets**


This section describes minimum inspection and maintenance requirements for post-construction BMPs. Actually inspection and maintenance may be more frequent to ensure long-term performance of post-construction BMPs then what is suggested. Maintenance should be performed whenever needed, based on maintenance indicators presented in the fact sheets below.

The fact sheets have been grouped into the following categories based on common maintenance requirements:

- Bio-Retention Basin
- Detention Basin
- Green Roof
- Infiltration Trench/Basin
- Manufactured Treatment Device

- Pervious Pavement
- Rainwater Harvesting
- Sand Filter
- Vegetated Biofilter
- Vegetated Swale/Strip

C-1



# **OM-01: Bio-Retention Basin**

• Bio-Retention Basin • Rain Garden

This category includes BMPs that treat storm water by infiltrating it through vegetation and/or soil. Regular inspection and maintenance is needed to ensure flow is unobstructed, erosion is prevented, and soils are biologically active. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Monthly or as Needed After Storm Event

- Remove obstructions, debris and trash from bio-retention area and dispose of properly.
- Inspection bio-retention area for ponded water.
- Inspect inlets for channeling, soil exposure or other evidence of erosion. Clear obstructions and remove sediment.
- Inspect depth of mulch and replenish as necessary (2 inches per soil specifications).

## Bi-Annually

- Maintain vegetation and irrigation system.
- Prune, weed and remove/replace any dead plants.

### Annually

• Inspect energy dissipation at the inlet.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands in the bio-retention area between storms and does not drain within 24 hrs after rainfall.	Any of the following results could apply: sediment or trash blockages removed, improved grade from head to foot of bio-retention area, and drains per design specification.
Trash and Debris	
Trash and debris accumulated in the bio-retention area and around the inlet and outlet.	Trash and debris removed from the bio-retention area and disposed of properly.
Sediment	
Evidence of accumulated sediment in the basin. Visual evidence of dumping.	Material removed so that there is no clogging or blockage. Material is disposed of properly.
Erosion	
Channels have formed around inlets, there are areas of bare soil, or there is other evidence of erosion.	Obstructions and sediment removed so that water flows freely and disperses over a wide area. Obstructions and sediment are disposed of properly.
Vegetation	
Vegetation is dead, diseased or overgrown.	Vegetation is healthy and attractive. Grass is maintained at least 3 inches in height.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Mulch	
Mulch is missing or patchy. Areas of bare earth are exposed or mulch layer is less than 3 inches deep.	All bare earth is covered, except mulch is kept 6 inches away from trunks of trees and shrubs. Mulch is even at a depth of 3 inches.
Inlet/Outlet	
Sediment accumulations.	Inlet/outlet is clear of sediment and debris and allows water to flow freely.
Miscellaneous	
Any condition not covered above that needs attention for the bio-retention area to function as designed.	The design specifications are met.

# **OM-02: Detention Basin**

• Detention Basin • Constructed Wetlands • Wet Ponds • Wetlands

This category includes BMPs that are designed to treat storm water by allows pollutants to settle out and gradually release detained storm water through an orifice. Maintenance primarily consists of vegetation management, sediment removal, and mosquito abatement when there is standing water. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

## Monthly or as Needed After Storm Event

- Inspect for clogging and that it drains between storms per design specifications.
- Trim vegetation and inspect for woody vegetation.
- Inspect the level of sediment in the forebay.

### Bi-Annually

- Evaluate the health of vegetation.
- Remove sediment, litter and debris.
- Inspect the outlet, embankment, dikes, berms, and side slopes for structural integrity and signs of erosion or rodent burrows.
- Inspect outlets and overflow structures for plugging and signs of erosion.
- Check inlets to ensure the piping is intact and not plugged.
- Inspect security measures around the facility.

### Annually

Harvest vegetation during dry periods.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands in the basin between storms and does not drain per design specifications.	Corrected any circumstances that restrict the flow of water from the system and drainage is restored to design condition.
Tree/Brush Growth, Woody Vegetation	
Growth does not allow maintenance access or interferes with maintenance activity, dead, diseased, or dying trees.	Trees do not hinder maintenance activities. Vegetation harvested annually, during dry periods.
Sediment	
Accumulated sediment >10% of design basin depth.	Sediment cleaned out to design shape and depth.  Basin reseeded to control erosion, if needed.  Sediment disposed of properly.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Erosion	
Erosion on compacted berm embankment. Rodent burrows on slope.	Cause of erosion is managed appropriately. Side slopes or berm restored to design specifications, as needed. Rodent burrows filled.
Inlet/Outlet	
Piping broken or inlet/outlet blocked.	Piping fixed. Debris/sediment removed and disposed of properly.
Fences/Security Measures	
Fences/security measures broken or missing.	Fences/security measures around facility are secure.
Miscellaneous	
Any condition not covered above that needs attention for the detention basin to function as designed.	The design specifications are met.

## **OM-03: Green Roof**

#### • Green Roof

Green roofs are designed to reduce storm water runoff volume and improve water quality by intercepting, filtering, absorbing, retaining or detaining storm water. Green roofs consist of the following components: waterproof membrane, drainage layer, vegetated media and vegetation. Regular inspection and maintenance is needed to ensure water flows unimpeded through the green roof and vegetation is healthy. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Monthly or as Needed After Storm Event

- Inspect media for runoff or wind scouring/exposed underlayment components.
- Inspect for standing water.


## **Bi-Annually**

- Inspect inlet outlet for litter and debris accumulation.
- Inspect vegetation. Prune, weed and remove/replace any dead plants.
- Replenish mulch.

### Annually

- Inspect for exposure of liner.
- Inspect for roof leaks.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Roof drainage system is clogged.	There should be no areas of standing water on the green roof. The drainage system is inspected for clogging conditions and repaired or replaced as needed.
Erosion	
Areas of scoured media or bare roof.	Green roof media stays in place and does not migrate across or erode from roof surface. Eroded media replaced and re-vegetated. If problem is recurrent, consider media more resistant to wind erosion or installing media retention components.
Leaky Roof	
Roof liner has failed.	Evaluate liner for cause of leaks. Repair or replace as necessary.
Miscellaneous	
Any condition not covered above that needs attention for the green roof to function as designed.	The design specifications are met.



# **OM-04: Infiltration Trench/Basin**

• Dry Well • Infiltration Basin • Infiltration Trench

This category includes BMPs that are designed to detain storm water by storing it in the void spaces of the aggregate and then infiltrated into the underlying soil. Infiltration trenches/basins are prone to clogging and maintenance consists primarily of preventing sediment buildup and clogging. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Monthly or as Needed After Storm Event

- Remove obstructions, debris and trash from treatment device and perimeter.
- Check observation well 2 to 3 days after storm to confirm drainage.
- Mow and trim surrounding vegetation.
- Inspect inflow and outflow structures for erosion. Repair as needed.

### Annually

- Monitor observation well to confirm that trench is draining properly.
- Inspect the trench for clogging and restore to design conditions, if needed.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands in the infiltration trench between storms and does not drain within 24 hrs after rainfall.	There should be no areas of standing water once inflow has ceased. Any of the following can apply: sediment or trash blockages removed, grade improved, or removed clogging at check dams.
Trash and Debris	
Trash and debris accumulated in the infiltration trench and around the inlet and outlet.	Trash and debris removed and disposed of properly.
Sediment	
Evidence of accumulated sediment in the infiltration trench.	Material removed so that there is no clogging or blockage. Material is disposed of properly.
Erosion	
Channels have formed around inlets, there are areas of bare soil, or there is other evidence of erosion.	Obstructions and sediment removed so that water flows freely and disperses over a wide area. Obstructions and sediment are disposed of properly.
Inlet/Outlet	
Sediment accumulations.	Inlet/outlet is clear of sediment and debris and allows water to flow freely.

Storm Water BMP Guide for New and Redevelopment

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Surface Materials	
Material is missing or patchy; areas of bare earth are exposed.	All bare earth is covered, except mulch is kept 6 inches away from trunks of trees and shrubs. Mulch is even at a depth of 3 inches.
Miscellaneous	
Any condition not covered above that needs attention for the infiltration trench to function as designed.	The design specifications are met.

# **OM-05: Manufactured Treatment Device**

• Hydrodynamic/Vortex Separator


• Other Devices Approved by TAP or NJCAT with a TSS Removal Rate of 80 or more

This category includes manufactured treatment devices. Each BMP is designed differently to treatment storm water and has different maintenance needs. Please refer to the manufacture's requirements for maintenance for more detailed information on inspection and maintenance activities and frequencies. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Follow manufacture's requirement. Typical maintenance requirements may include:

- Inspect for clogging and standing water.
- Remove accumulated sediment, trash and debris.
- Replace media material, if applicable.

Condition When Maintenance is Needed	Results When Maintenance is Performed
Standing Water	
When water stands over the manufactured treatment device between storms and does not drain per design specifications.	There should be no areas of standing water after inflow has ceased Filer drains per design specification. Any of the following could apply: sediment or trash blockage removed, mulch media replaced, and/or overflow pipe flushed/repaired in manner that does not cause an illegal discharge.
Sediment, Trash, and Debris Accumulation	
Sediment, trash and debris accumulated in the media material, vault, or piping.	Sediment, trash and debris removed and disposed of properly.
Mosquitoes	
Evidence of mosquito larvae in treatment unit.	No evidence of mosquito larvae.
Miscellaneous	
Any condition not covered above that needs attend in order for the manufactured treatment device to function as designed.	The design specifications are met.



## **OM-06: Pervious Pavement**

Pervious Concrete
 Porous Asphalt
 Interlocking Paver Blocks
 Reinforced Turf Grassing/Gravel Filled Grids

This category includes BMPs that are designed to treat storm water by detaining storm water in the void spaces and then infiltrated into the underlying soil. Pervious pavement is prone to clogging and maintenance consists primarily of preventing sediment buildup and clogging. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Quarterly or as Needed After Storm Event

- Check for sediment and debris accumulation. Prevent soil from washing or flowing onto the
  pavement. Do not store sand, soil, mulch or other landscaping materials on pervious pavement
  surfaces.
- Use commercially available regenerative air or vacuum sweeper to remove sediment and debris from the surface.
- Perform vacuum sweeping, power washing, and/or reconstruction to restore surface permeability as needed.
- Inspect for signs of pavement failure. Repair any surface deformations or broken pavers.
- Check for standing water on pavement within 30 minutes following a storm event.
- Inspect underdrain outlets. Remove trash and debris.
- Remove weeds. Mow vegetation in grid pavement (i.e., turf block) as needed.
- Replenish aggregate in joints or grids as needed.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands on the surface of the permeable pavement and 48 hrs has passed since the last rainfall.	There should be no areas of ponded/standing water more than 48 hrs after a rain event. Any of the following can apply: surface swept or vacuumed, underdrains added, underdrains flushed in manner that does not cause an illegal discharge.
Trash and Debris	
Leaves, grass clippings, trash, etc., are preventing water from draining into the permeable pavement and are unsightly.	Area is free of all debris and the permeable pavement is draining properly.
Vegetation	
Vegetation around the perimeter of the permeable pavement is dead, diseased, or overgrown. Weeds are growing on the surface of the permeable pavement.	Area adjacent to pavement is well-maintained and no bare/exposed areas exist; grass is maintained at a height of 3–6 inches.  No weeds present in the pavement area.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Deteriorating Surface	
The pavement is cracked; paver blocks are misaligned or have settled.	The surface area is stabilized, exhibiting no signs of cracks or uneven areas in the pavement area.
Miscellaneous	
Any condition not covered above that needs attention for the pervious pavement to function as designed.	The design specifications are met.

# **OM-07: Rainwater Harvesting**

• Cisterns • Rain Barrels • Vehicle Washing


• Other Non-Potable Water uses Approved by the Building Code

This category includes BMPs that are designed to store water a specific volume of water to use later for irrigation, non-potable water plumbing, vehicle washing, or other non-potable water uses. Maintenance is primarily focused on preventing sediment buildup and clogging, which reduces the capacity of the system. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Quarterly or as Needed After Storm Event

- Inspect, clean and replace filters and screens, as needed.
- Inspect and clean debris from roof, gutters, downspouts, first flush devices, roof washers, or other collection surfaces.
- Inspect for and repair leaks.
- If rainwater is used for indoor use, inspect and verify that treatment systems are operational and maintaining minimum water quality requirements as determined by DPP or DOH.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Sediment and Debris Accumulation	
Sediment or debris accumulated in filter, screens, gutters, downspouts, first flush device, or roof washers or on roof or other collection surfaces. Sediment accumulated in cisterns(s).	Sediment removed. Collection surfaces do not contribute sediment and debris.
Leaks	
Water leaking from system.	No leakage.
Water Quality	
Treatment system is not working properly.	Treatment system is operational and maintaining minimum water quality requirements.
First Flush Diverter	
First flush filter is full or clogged causing permanent flow to the cistern.	First flush is diverted away from the cistern when the first flush diverter valve is removed and cleaned.
Cistern does not Drain within 48 hours	
Outlet is clogged.	Cistern completely drains in less than 48 hrs.
Cistern Drain under 24 hours	
Cistern leaks or outlet allows excessive flows.	Cistern drains in 24 to 48 hrs.
Miscellaneous	
Any condition not covered above that needs attention for the pervious pavement to function as designed.	The design specifications are met.



# **OM-08: Sand Filter**

#### Sand Filter

Sand Filters are designed to treat storm water by removing pollutants as the storm water flows through the media. Regular inspection and maintenance is needed to prevent sediment buildup and clogging, which reduces pollutant removal efficiency. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

### Monthly or as Needed After Storm Event

- Inspect for standing water, sediment, trash and debris.
- Remove accumulated trash and debris in the unit during routine inspections.

### Annually

• Inspect to ensure that the facility is draining completely within five days and per manufacturer's specifications.

## Per Manufacturer's Specification

• Replace the media per manufacturer's inspection or as indicated by the condition of the unit.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
When water stands over the sand filter media between storms and does not drain within 24 hours after rainfall.	There should be no areas of standing water after inflow has ceased. Any of the following could apply: sediment or trash blockages removed, filter media surface scarified, media replaced underdrains flushed in manner that does not cause an illegal discharge.
Mosquitoes	
Evidence of mosquito larvae in treatment unit.	No evidence of mosquito larvae.
Sediment, Trash, and Debris Accumulation	
Sediment, trash and debris accumulated in the sand filter unit and around the inlet and outlet.	Sediment, trash, and debris removed so there is no clogging.
Erosion	
Channels have formed around inlets, there are areas of bare soil, or there is other evidence of erosion.	Obstructions and sediment removed so that water flows freely and disperses throughout the sand filter media. Obstructions and sediment are disposed of properly.
Inlet/Outlet	
Sediment accumulations.	Inlet/outlet is clear of sediment and debris and allows water to flow freely.

# Condition When Maintenance is Needed Results When Maintenance is Performed Miscellaneous Any condition not covered above that needs attention for the sand filter to function as designed. The design specifications are met.

### **OM-09: Vegetated Biofilter**

• Stormwater Curb Extension • Tree Box Filter • Planter Box

This category includes BMPs that are designed to detain and treat runoff without draining into the underlying soil. Maintenance is primarily focused on maintaining healthy vegetation, avoiding clogging and proper functioning of inlets, outlet and high-low bypass. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

#### Monthly or as Needed After Storm Event

- Inspect bio-filter system, overflow pipe, inlets, and sheet flow areas for clogging and impediments to flow. Repair damaged pipes.
- Remove accumulated sediment, debris, sediment and repair damaged pipes.
- Inspect and repair/replace or replenish splash blocks or rocks, as needed.

#### Bi-Annually

- Inspect vegetation. Prune, weed and remove/replace any dead plants. Replenish mulch.
- Inspection irrigation system.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands in the vegetated biofilter between storms and does not drain within 24 hrs after rainfall.	There should be no areas of standing water after inflow has ceased. Any of the following could apply: sediment or trash blockages removed, mulch replaced, underdrains flushed in manner that does not cause an illegal discharge.
Trash and Debris	
Trash and debris accumulated in and around the inlet and outlet.	Trash and debris removed and disposed of properly.
Sediment	
Evidence of accumulated sediment.	Material removed so that there is no clogging or blockage. Material is disposed of properly.
Erosion	
Channels have formed around inlets, there are areas of bare soil, or there is other evidence of erosion.	Obstructions and sediment removed so that water flows freely and disperses over a wide area. Obstructions and sediment are disposed of properly.
Vegetation	
Vegetation is dead, diseased, or overgrown.	Vegetation is healthy and attractive. Grass is maintained at least 3 inches in height.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

Condition When Maintenance is Needed	Results When Maintenance is Performed
Mulch	
Mulch is missing or patchy. Areas of bare earth are exposed or mulch layer is less than 3 inches deep.	All bare earth is covered, except mulch is kept 6 inches away from trunks of trees and shrubs. Mulch is even at a depth of 3 inches.
Inlet/Outlet	
Sediment accumulations.	Inlet/outlet is clear of sediment and debris and allows water to flow freely.
Affected Impervious Areas of Structures	
Obvious effects on surrounding impervious areas or structures.	Hydraulic restriction layers prevent impacts from infiltration to surrounding structures.
Miscellaneous	
Any condition not covered above that needs attention for the vegetated bio-filter to function as designed.	The design specifications are met.

### **OM-10:** Vegetated Swale/Strip

• Dry Swale • Vegetated Buffer Strip • Vegetated Swale

This category includes BMPs that are designed to provide to remove pollutants by physically straining and filtering water through vegetation or cobble within the swale/strip. Maintenance is primarily focused on maintaining healthy vegetation and avoiding clogging. General conditions when maintenance is needed and the associated maintenance action triggered by those conditions are provided below.

#### Monthly or as Needed After Storm Event

- Inspect swale/strip for ponding.
- Inspect inlets and sheet flow areas for impediments.
- Remove accumulated sediment, litter and debris.

#### Bi-Annually

- Inspect vegetation. Prune, mow, weed and remove/replace any dead plants.
- Replenish mulch.
- Inspection irrigation system.

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Standing Water	
Water stands in the vegetated swale/strip between storms and does not drain within 24 hrs after rainfall.	There should be no areas of standing water once inflow has ceased. Any of the following could apply: improved grading or underdrains flushed in manner that does not cause an illegal discharge.
Sediment, Trash, and Debris Accumulation	
Sediment, trash and debris accumulated in the swale and around the inlet and outlet.	Material removed so that there is no clogging or blockage. Sediment deposits removed without significant disturbance of the vegetation.
Erosion	
Channels have formed around inlets, there are areas of bare soil, or there is other evidence of erosion.	No erosion or scouring evident. Damaged areas repaired with crushed gravel. Over time grass will start to cover over rock.
Vegetation	
Vegetation is dead, diseased, or overgrown.	Vegetation is healthy and attractive. Grass is maintained at least 3 inches in height.
Mulch (if used)	
Mulch is missing or patchy. Areas of bare earth are exposed or mulch layer is less than 3 inches deep.	All bare earth is covered, except mulch is kept 6 inches away from trunks of trees and shrubs. Mulch is even at a depth of 3 inches.
Inlet/Outlet	
Sediment or debris accumulations.	Inlet/outlet is clear of sediment and debris and allows water to flow freely.

Storm Water BMP Guide for New and Redevelopment Revised: July 2017

<b>Condition When Maintenance is Needed</b>	Results When Maintenance is Performed
Flow Spreader (if applicable)	
Flow spreader uneven or clogged so that flows are not uniformly distributed through entire swale width.	Spreader leveled and cleaned such that flows are distributed evenly over the entire swale width.
Visual Contaminants and Pollution	
Visual evidence of oil, gasoline, contaminants, or other pollutants.	No visual evidence of contaminants or pollutants present.
Miscellaneous	
Any condition not covered above that needs attention for the vegetated swale/strip to function as designed.	The design specifications are met.

# Appendix D CCH Rules Relating to Water Quality

## DEPARTMENT OF PLANNING AND PERMITTING CITY AND COUNTY OF HONOLULU

## ADOPT THE PROPOSED AMENDMENTS TO THE RULES RELATING TO WATER QUALITY (ADOPTED AUGUST 16, 2016, AMENDED JULY 14, 2017)

- 1) Amended the Rules Relating to Water Quality (Rules) to reflect minor corrections and clarifications, including revisions to the following Sections: §20-3-2 Purpose – added language to clarify the Rules also apply to projects that do not discharge into the City's MS4, §20-3-3 Definitions – added the terms Authorized Agent, Certified Erosion and Sediment Control Plan Preparer, Repair, and Routine Maintenance; and revised the terms Industrial Park, Development, Redevelopment, and Replacement of Impervious Surface; §20-3-4 Construction - Revised language to exempt an entity that is covered by a large MS4 NPDES permit to comply with a separate NPDES construction and postconstruction runoff control program if approved by DPP; §20-3-14 Project Categories for Development - Revised the description of Category 1B and Category 2 projects; and added description and requirements for the new Minor Development Category; §20-3-16 Processing and Approval of Erosion and Sediment Control Plan – clarified regulated Development; §20-3-17 Requirements for Trenching Projects – revised; §20-3-18 Requirement for Category 1A Projects – revised; §20-3-19 Requirement for Category 1B Projects – revised; §20-3-20 Requirement for Category 1C Projects – revised; §20-3-21 Requirement for Category 2 Projects – revised; §20-3-22 Requirement for Category 3 Projects – revised; §20-3-23 Requirement for Category 4 Projects – revised; §20-3-24 Requirement for Category 5 Projects – revised; §20-3-28 Project Schedule – clarified method of notifying the City of the scheduled start date. §20-3-31 Permanent Stabilization – clarified requirements; §20-3-32 Diversion BMP – clarified requirements; §20-3-38 Sediment Barriers – clarified requirements; §20-3-45(4) Dust Control – omitted spray on chemical soil treatment; §20-3-48 Priority Projects – revised the term "Industrial Park", redefined Priority B2 projects, and added language to clarify exempted projects; §20-3-49 Post-Construction Storm Water Requirements – omitted vortex separator; §20-3-52 Storm Water Quality Checklists – revised O&M plan requirement for Priority B2 projects, §20-3-53 Operation And Maintenance (O&M) Plans – clarified O&M Plan requirement; §20-3-54 Post-Construction BMP Certification and Recording – clarified requirements for Priority B2; §20-3-54(b) Post-Construct BMP Certification and Recording – clarified requirements for regional Post Construction BMPs; §20-3-55 BMP Selection – added Retail Malls to the POC table; §20-3-56 Site Design Strategies & §20-3-58 Treatment Control BMP numerical sizing criteria – added Self Retaining Area and revised size criteria of the De Minimis area; §20-3-60 (g) Harvest/ Reuse - clarified method of storage volume calculation; §20-3-62 Alternative Compliance BMPs – revised description.
- 2) The templates in Appendices A, B, C, D, E, F, and G were reformatted and the contents were revised to be consistent with the proposed amendments listed above.

#### CITY AND COUNTY OF HONOLULU

#### ADMINISTRATIVE RULES

#### TITLE 20

#### DEPARTMENT OF PLANNING AND PERMITTING

#### CHAPTER 3

#### RULES RELATING TO WATER QUALITY

#### SUBCHAPTER 1 GENERAL PROVISIONS AND REQUIREMENTS

§20-3-1	Short Title	
§20-3-2	Purpose	
§20-3-3	Definitions	
§20-3-4	Construction	
§20-3-5	Enforcement A	
§20-3-6		of Post-Construction Violations
§20-3-7	Responsible P	
§20-3-8	Additional Sta	andards
SUBC	CHAPTER 2	GENERAL REQUIREMENTS FOR DEVELOPMENT
		AND LAND DISTURBING ACTIVITIES
§20-3-9	Best Manager	ment Practices Required
§20-3-10		IP Requirements
§20-3-11	Conditions of	* *
§20-3-12	BMP Use and	Maintenance Required
SUBC	CHAPTER 3	PROJECT CATEGORIES AND CLASSIFICATIONS
§20-3-13	Projects	
§20-3-14	Project Categor	ories for Development
CLUD	ULA DEED A	DECLUDENCE TO DECLUATED DOCUMENTS AND
SUBC	CHAPTER 4	REQUIREMENTS FOR REGULATED PROJECTS AND ACTIVITIES DURING CONSTRUCTION
§20-3-15	Erosion and S	ediment Control Plans for Development
§20-3-16		d Approval of Erosion and Sediment Control Plans
§20-3-17		for Trenching Projects
§20-3-18	Requirements	for Category 1A Projects

Requirements for Category 1B Projects
Requirements for Category 1C Projects
Requirements for Category 2 Projects
Requirements for Category 3 Projects
Requirements for Category 4 Projects
Requirements for Category 5 Projects
Additional Requirements for Development
BMP Inspections

# SUBCHAPTER 5 BMPS, STANDARDS, AND SPECIFICATIONS FOR ACTIVITIES DURING CONSTRUCTION

§20-3-27	Project Planning and Design
§20-3-28	Project Scheduling
§20-3-29	Slope Management and Protection
§20-3-30	Temporary Stabilization
§20-3-31	Permanent Stabilization
§20-3-32	Diversion BMPs
§20-3-33	Preservation of Existing Vegetation
§20-3-34	Minimize Soil Compaction
§20-3-35	Velocity Dissipation Devices
§20-3-36	Perimeter Control
§20-3-37	Silt Fences
§20-3-38	Sediment Barriers
§20-3-39	Storm Drain Inlet Protection
§20-3-40	Vegetated Buffers
§20-3-41	Sediment Basins
§20-3-42	Sediment Traps
§20-3-43	Tracking Control
§20-3-44	Stabilized Construction Entrances and Exits
§20-3-45	Dust Control
§20-3-46	Good Housekeeping Practices
§20-3-47	Dewatering Operations

#### SUBCHAPTER 6 POST-CONSTRUCTION REQUIREMENTS

§20-3-48	Priority Projects
§20-3-49	Post-Construction Storm Water Requirements
§20-3-50	Storm Water Quality Strategic Plans
§20-3-51	Storm Water Quality Reports
§20-3-52	Storm Water Quality Checklists
§20-3-53	Operations and Maintenance Plans
§20-3-54	Post-Construction BMP Certification and Recording

# SUBCHAPTER 7 BMPS, STANDARDS, AND SPECIFICATIONS FOR PERMANENT POST-CONSTRUCTION BMPS AND LOW IMPACT DEVELOPMENT

§20-3-55	BMP Selection
§20-3-56	Site Design Strategies
§20-3-57	Source Control BMPs
§20-3-58	Treatment Control BMPs Numeric Sizing Criteria
§20-3-59	Infiltration Testing
§20-3-60	Retention BMPs
§20-3-61	Biofiltration BMPs
§20-3-62	Alternative Compliance BMPs
§20-3-63	Feasibility Criteria

#### SUBCHAPTER 8 VARIANCES

§20-3-64 Variances

#### SUBCHAPTER 9 VIOLATIONS AND ENFORCEMENT

§20-3-65	BMP Deficiencies
§20-3-66	Enforcement
§20-3-67	Penalties

#### SUBCHAPTER 10 APPEALS

§20-3-68	Appeals
§20-3-69	Computation of Time
§20-3-70	Mandatory Filing Deadline
§20-3-71	Representation in Contested Case Hearings
§20-3-72	Prehearing Procedure
§20-3-73	Intervention
§20-3-74	Withdrawal of Petition
§20-3-75	Contested Case Hearing
§20-3-76	Decision and Order
§20-3-77	Judicial Remand

#### SUBCHAPTER 1 GENERAL PROVISIONS AND REQUIREMENTS

§20-3-1	Short Title
§20-3-2	Purpose
§20-3-3	Definitions
§20-3-4	Construction
§20-3-5	Enforcement Authority
§20-3-6	<b>Enforcement of Post-Construction Violations</b>
§20-3-7	Responsible Parties
§20-3-8	Additional Standards

§20-3-1 <u>Short Title</u>. This document and its provisions, inclusive of any additions and/or amendments hereto, shall be known as the *Rules Relating to Water Quality* and may from time to time be referred to herein as the "Rules."

[Eff August 16, 2017] (Auth: ROH §§ 1-9.1, 14-12.1 et. seq., ROH § 14-13.1 et. seq., ROH § 14-16.1 et. seq.) (Imp: ROH § 14-12.1 et. seq.).

§20-3-2 <u>Purpose</u>. The Rules Relating to Water Quality are adopted to further the City and County of Honolulu's compliance with, and, performance of duties under Article XI, Section 1 of the Hawaii State Constitution, Hawaii Revised Statutes Chapters 180C and 342D, Chapter 14 of the Revised Ordinances of Honolulu 1990 (*as amended*), and the City and County of Honolulu's National Pollutant Discharge Elimination System Permit, NPDES Permit No. HI S000002, 2015 (*as amended*).

The Rules Relating to Water Quality apply to all Development and Land Disturbing Activities within the City and County of Honolulu and establish minimum requirements for the selection, design, implementation and maintenance of best management practices ("BMPs") to protect the MS4 and Receiving Waters from Pollutants that are associated with land disturbance, surface hardening, and land use activities. The pollutants of concern ("POC") addressed by these Rules include, but are not limited to, sediment, nutrients, trash, pathogens, pesticides, oil, grease, hazardous waste, toxic waste, metals, and organic compounds.

The standards and requirements established by these Rules are not a maximum limit to the design requirements for BMPs. Compliance with the minimum requirements and standards established by these Rules does not guarantee that selected BMPs will meet their pollution control and/or drainage objectives. Land owners, design professionals, developers, and contractors are encouraged to implement BMPs that go beyond that requirements of these Rules and seek the advice of other agencies that are responsible for water quality, pollution control, Receiving Waters, water rights, flood plains, and storm water.

Compliance with these rules does not excuse violations of State or Federal law, City Ordinances, or permits issued by Department of Planning and Permitting or other permitting authorities. These Rules shall not be limited to only those areas that drain to the City's drainage facilities or those natural drainage ways that the City has ownership and/or responsibility for.

[Eff December 24, 2018] (Auth: ROH §§ 1-9.1, 14-12.1 et. seq., ROH § 14-13.1 et. seq., ROH §

§20-3-3 <u>Definitions</u>. As used in this Chapter, unless the context clearly requires otherwise:

"Action of the Director" or "Director's Action" means a written decision by the Director of Planning and Permitting or his authorized agent regarding an application submitted to the Department pursuant to Chapter 14 of the Revised Ordinances of Honolulu or the Rules Relating to Water Quality.

"Architect" means an Architect licensed in the State of Hawai'i.

"Authorized Agent" means a person authorized in writing by the owner of the property to sign for erosion and sediment control requirements on their behalf including Erosion and Sediment Control Plans, designation of the Erosion and Sediment Control Plan Coordinator.

"Best Management Practices" or "BMPs" means schedules of activities, prohibitions of practices, maintenance procedures, management practices, treatments, and temporary or permanent Structures or devices that are intended and designed to eliminate and Minimize the Discharge of Pollutants, directly or indirectly, to Receiving Waters, to the maximum extent practicable.

"Biofiltration" means a pollution control technique that uses living material to capture, and absorb or biologically degrade Pollutants.

"Bonded Fiber Matrix" means a matrix consisting of strands of continuous, elongated wood fibers combined with a stabilizing emulsion and water. Bonded fiber matrix must be 100 percent biodegradable, mixed with water in a hydraulic mulcher, and applied as liquid slurry.

"Certified Erosion and Sediment Control Plan Preparer" or "CESCPP" means a Civil Engineer licensed in the State of Hawaii who has a current Erosion and Sediment Control Plan Preparer Certificate from the Department.

"Certified Water Pollution Plan Preparer" or "CWPPP" means an Architect, Engineer, Land Surveyor, or Landscape Architect licensed in the State of Hawaii who has a current Water Pollution Plan Preparer Certificate from the Department.

"City" means the City and County of Honolulu.

"Contested case" means a proceeding in which the legal rights, duties, or privileges of specific parties are required by law to be determined after a hearing before the Department.

"Days" means calendar days, including weekends and holidays, unless otherwise indicated.

"Department" or "DPP" means the City and County of Honolulu Department of Planning and Permitting.

"Department of Health" or "DOH" means the State of Hawai'i Department of Health.

"Design Engineer" means a licensed Civil Engineer in the State of Hawaii who stamps or certifies plans that are submitted to the Department for review and approval.

"Developer" means the owner of Real property subject to Development and includes any person that causes, contributes to, or participates in the actions necessary to accomplish Development.

"Development" means the sum of any and all actions that are undertaken to alter the natural or existing condition of Real property or improvements on Real property if a building, electric, grading, grubbing, plumbing, stockpiling or trenching permit is required for the Project. Development does not include the installation of signs and traffic control devices, emergency

work necessary to repair surfaces that are in immediate need of stabilization, and the marking of improved surfaces with striping or signage. "Director" means the director of the City and County of Honolulu Department of Planning and Permitting or the Director's authorized agent or representative.

"Discharge" means the deposit, disposal, injection, dumping, spilling, leaking, tracking or placing of any substance into the MS4 or Receiving Waters, directly or indirectly, and includes allowing the foregoing to occur.

"Disturbed Area" means any and all portions of Project Site affected by Land Disturbing Activities. Disturbed Areas include, but are not limited to, soils and surface areas affected by excavation, areas that are graded, grubbed, or cleared by uprooting vegetation, areas affected by the demolition of foundations, areas used for equipment staging and materials storage, and areas affected by heavy pedestrian or vehicular traffic that disrupts ground covers or surface soil conditions.

"Engineer" means an Engineer licensed in the State of Hawai'i.

"Erosion and Sediment Control Plan" or "ESCP" means a plan prepared to prevent and control erosion and sediment Discharges from a construction Site. ESCPs also include good housekeeping BMPs to limit or reduce other Pollutants associated with construction activities.

"ESCP Coordinator" means the designee responsible for the implementation of an ESCP who has a current ESCP coordinator certificate from the Department. The designation of an ESCP Coordinator does not relieve the property owner or other responsible parties from compliance with these Rules or liability for violations of the same.

"Erosion Control" means practices and devices that are intended and designed to prevent wind and water erosion, water pollution, soil loss, and Pollutant Discharges to the MS4 and Receiving Water. Erosion Control may be achieved, among other things, by the appropriate and effective use of BMPs to address energy and/or velocity dissipation, slope and surface stabilization, and the creation of physical barriers that separate erodible soils from factors that cause or contribute to erosion. Erosion control BMPs include, but are not limited to: Rolled Erosion Control Products, fiber matrix devices, mulching, hydroseeding, and the preservation of existing vegetation.

"Erosion Control Blankets" means biodegradable or photodegradable blankets that are designed to Minimize and/or prevent erosion.

"Evapotranspiration" means the loss of water from soil by evaporation and vegetative transpiration.

"Excavation" or "cut" means any act by which earth material is dug into or moved, and shall include conditions resulting therefrom.

"Final action" means placing an Action of the Director in the U.S. mail for delivery to a person.

"Geotextiles" or "Geotextile Mats" means woven non-biodegradable polypropylene fabric designed for use on Disturbed Areas where high strength materials are needed to endure abrasive forces through the life of a Project. Geotextiles can be used for drainage control and slope stabilization.

"Grading" means any excavation or fill, or combination thereof.

"Grubbing" means the uprooting of vegetation, including trees, shrubbery, and plant life from the surface of the ground.

"Hearings officer" means a person appointed by the Director to preside over a Contested case hearing.

"Hydraulic Matrix" means a matrix consisting of stabilizing emulsion combined with wood fiber, paper fiber, and water.

"Impervious Surface" means a surface covering or pavement of a developed parcel of land that prevents the land's natural ability to absorb and infiltrate rainfall/ storm water. Impervious surfaces include, but are not limited to rooftops, walkways, patios, driveways, parking lots, storage areas, impervious concrete and asphalt, and any other continuous watertight pavement or covering.

"Improvement" means any structure or work on Real property that increases the usefulness or value of the realty.

"Industrial facility" means an area of land used or zoned for industrial use as set forth under the City and County of Honolulu Land Use Ordinance, ROH Chapter 21.

"Infeasible" means not technologically possible, or, cost prohibitive and not achievable in light of best industry practices.

"Infiltration" means practices which capture and temporarily store a design storm volume of water before allowing it to infiltrate into the soil.

"Land Disturbing Activity" or "Land Disturbance" means any action, activity, or land use that alters the integrity, structure, texture, density, permeability, contents, or stress conditions of soil or ground surfaces if a building, electric, grading, grubbing, plumbing, stockpiling or trenching permit is required for the Project. Land disturbing activities include, but are not limited to actions that result in the turning, penetration, or moving of soil, the resurfacing of pavement that involves the exposure of the base course or subsurface soils, and the use of portions of a Project Site as staging areas or base yards.

"Low Impact Development" or "LID" means systems and practices that use or mimic natural processes that result in the Infiltration, evapotranspiration or use storm water in order to protect water quality and the aquatic habitat. At both site and regional scales, LID aims to preserve, restore, and create green space using soils, vegetation, and rain harvest techniques.

"Maximum Extent Practicable" or "MEP" means economically achievable measures that prevent or reduce the addition of Pollutants to the environment to the greatest degree achievable through the application of the best available pollution control practices, technologies, processes, siting criteria, operating methods and other alternatives.

"Minimize" means to reduce and/or eliminate to the extent achievable using BMPs and storm water controls that are technologically available and economically practicable and achievable in light of the best industry practices.

"Minor Development" means Development that requires a trenching, building, grading, grubbing or stockpiling permit where the total Project scope is limited to the activities listed in \$20-3-14(i).

"Municipal Separate Storm Sewer System" or "MS4" means the City's drainage infrastructure that is designed or intended to collect and convey storm water and includes, but is not limited to, City roads with drainage improvements, City streets, catch basins, curbs, gutters, ditches, man-made channels, and storm drains.

"National Pollutant Discharge Elimination System permit" or "NPDES permit" means the permit issued to the City pursuant to *Title 40, Code of Federal Regulations, Part 122,* Subpart B, Section 122.26(a) (1) (iii), for storm water Discharge from the City's separate storm sewer systems; or the permit issued to a person or property owner for a storm water Discharge associated with industrial activity pursuant to *Title 40, Code of Federal Regulations, Part 122*, Subpart B, Section 122.26(a) (1) (ii), or other applicable section of Part 122; or the permit issued

to a person or property owner for the Discharge of any Pollutant from a point source into the State Waters through the City's separate storm sewer system pursuant to *Hawaii Administrative Rules*, Chapter 11-55, "Water Pollution Control".

"Netting" means plastic or geotextile netting that is biodegradable or photodegradable and designed to secure loose mulches to the ground.

"Permanent BMP" or "Post-Construction BMP" means a BMP that will remain on site after the completion of a Project in order to prevent or reduce the Discharge of Pollutants to the MS4 and/or Receiving Waters.

"Person" means an individual, association, partnership, corporation, municipality, State or Federal agency, or an officer, agent or employee thereof. Person also includes trusts, estates, associations, groups of individuals and legal entities. Where person refers to a corporation, association, or other legal entity that has directors or corporate officers, person shall also refer to the individual directors or corporate officers that authorize, allow, or direct actions governed by these rules.

"Plastic Sheeting" means covers comprised of plastic that are impervious, non-biodegradable, and designed for short-term drainage control, slope stabilization, or stockpile and/or materials management.

"Pollutant" means any dredge, spoil, solid refuse, incinerator residue, sewage, garbage, sewage sludge, munitions, chemical waste, biological materials, radioactive materials, heat, wrecked or dismantled equipment, rock, sand, soil, sediment, dirt, industrial, municipal, or agricultural waste and substances of similar nature.

"Project" means all planned or intended Development, Land Disturbing Activities, construction activities, and Improvements to Real property and includes any unplanned construction, Developments, and/or Improvements that occur on Site.

"Real property" means realty, real estate, or land and includes all Structures and Improvements upon the same.

"Receiving Waters" or "State Waters" means all waters, fresh, brackish, or salt, around and within the State of Hawai'i, including but not limited to coastal waters, streams, rivers, ponds, estuaries, reservoirs, canals, ground waters, and lakes. Waters in drainage ditches, drainage ponds, and drainage reservoirs required as part of a water pollution control system are excluded.

"Redevelopment" means the creation, addition, and/or Replacement of Impervious Surface on improved Real property. Redevelopment also includes changes in land use that may result in increased Pollutant Discharges to the MS4 or Receiving Waters. Redevelopment does not include Minor Development as described in §20-3-14(i).

"Repair" means activities to mend, fix, or restore existing Improvements on Real property to an acceptable operating or useable condition after damage has occurred.

"Replacement of Impervious Surface" includes any activity that is not part of Routine Maintenance and Repair and where impervious materials are removed, exposing underlying soil or base course during construction.

"Routine Maintenance" means activities performed for the regular upkeep of existing Improvements to Real property including recurring, preventative and on-going maintenance necessary to delay or prevent the failure of existing Improvements.

"Retail Mall" or "Commercial mall" means one or more buildings that house or form a complex of retail stores with interconnecting walkways. Retail and Commercial malls include, but are not limited to, mini-malls, strip malls, retail complexes, and enclosed shopping malls or

shopping centers.

"Rolled Erosion Control Products" means geotextiles, Plastic Sheeting, Erosion Control blankets, Netting, and mats used to protect disturbed soil areas from erosion by water and wind. Rolled Erosion Control products can be used as stand-alone soil stabilization BMPs, in conjunction with re-vegetation, or to reinforce mulch.

"Sediment Control" means practices and devices that are intended and designed to prevent soils on a Project Site from being transported to the MS4 and Receiving Waters. Sediment Control may be achieved, among other things, by the appropriate and effective use of silt fences, fiber rolls, gravel bags, drain inlet protection devices, and dewatering filtration.

"Self-Mitigating Area" means a natural or landscaped area, including green roofs, which retains and/or treats rainfall within its perimeter without accepting runoff from other areas. Self-Mitigating Areas must retain all collected storm water or drain directly to the MS4.

"Site" means the Real property on which Development, construction, or other Land Disturbing Activities occur and/or are intended to occur.

"Site Design Strategies" means LID design techniques that are intended to maintain or restore the Site's hydrologic and hydraulic functions with the intent of minimizing runoff volume and preserving existing flow paths.

"Source Control BMPs" means BMPs that are designed to prevent Pollutants from contacting storm water runoff and prevent their Discharge into the MS4 or Receiving Waters.

"Structure" means a building, improvement on Real property, or arrangement of items on property that has or requires a fixed location on the ground.

"Temporary BMPs" means BMPs that will discontinue or be removed from the Site after construction or land disturbing activities are complete.

"Treatment Control BMPs" means engineered technologies designed to remove Pollutants from storm water runoff prior to Discharge to the storm drain system or Receiving Waters.

- §20-3-4 <u>Construction</u>. In the interpretation and application of these Rules, the following shall be observed unless it is apparent from the context of the Rules that a different construction is intended:
- (a) General Rule. All words and phrases shall be construed and understood according to the common and approved usage of the language, but technical words and phrases that have acquired a peculiar and appropriate meaning in the law shall be construed and understood according to such peculiar and appropriate meaning.
  - (b) Construction of Ambiguous Words. Where the words are ambiguous:
    - (1) The meaning of the ambiguous words may be sought by examining the context, with which the ambiguous words, phrases, and sentences may be compared, in order to ascertain their true meaning.
    - (2) The reason and spirit of the rule and the cause which induced enactment or promulgation of the rule may be considered to discover its true meaning.
    - (3) Every construction which leads to an absurdity shall be rejected.
  - (c) Rules in pari materia. Rules in pari materia, or upon the same subject matter, shall

be construed with reference to each other. What is clear in one ordinance may be called in aid to explain what is doubtful in another.

- (d) Number and Gender. Words in the masculine gender signify both the masculine and feminine gender, those in the singular or plural number signify both the singular and plural number, and words importing adults include youths or children.
  - (e) Tenses. Every word used in the present tense shall include the future.
- (f) Acts by Subordinate Officer. When any provision herein requires an act to be done, which may by law as well be done by a subordinate officer as by the superior officer, such requirement shall be construed to include all such acts when done by an authorized subordinate officer.
- (g) Rules Not Retrospective. No rule or regulation herein has any retrospective operation, unless otherwise expressed or obviously intended.
- (h) Persons Subject to Rules and Regulations. The Rules and regulations are obligatory upon all persons within the jurisdiction of the City. Entities who hold a Large MS4 NPDES Permit may request an exemption from these Rules to comply with a NPDES construction and post-construction runoff control program approved by DOH. The exemption must be approved by the Director prior to the approval of any permit issued by the Department.
- (i) Effect of Prohibitory Rules. Whatever is done in contravention of a prohibitory Rule is void, although the nullity be not formally directed.
- (j) References Apply to Amendments. Whenever reference is made to any portion of the Revised Ordinances of Honolulu, any permit issued to the City, or of any other law, the reference applies to all amendments thereto.
- (k) References Inclusive. Whenever reference is made to a series of sections in the Revised Ordinances of Honolulu by citing only the numbers of the first and last sections connected by the word "to," the reference includes both the first and last sections.
- (l) Effect of Rules. In requirements of these Rules are to be regarded as minimum requirements for the protection of the public health, safety, and welfare.
- (m) Use of capitalized terms. Defined words and phrases have been capitalized in the body of these Rules to ensure that the reader is aware of the intended use and meaning of defined words and phrases. The failure to capitalize any defined term or phrase does indicate an intention to apply a meaning or definition to a defined word or phrase other than that provided in §20-3-3 of these Rules. All defined terms and phrases shall be construed in accordance with their defined meanings unless such construction will necessarily lead to an absurd result.
- (n) Conflicts with Other Laws or Standards. If other laws, ordinances, rules or regulations cover the same subject as these Rules, conflicts shall be resolved by applying the stricter standard as between conflicting authorities.
- (o) No abrogation. These Rules shall not abrogate or annul any permits or approved drainage reports, construction plans, easements, or covenants issued or approved by the Director before the effective date of the Rules unless the permit or approved construction plans is expired. Approved construction plans expire two years after the Director's approval.
- (p) Appendices. Appendices to the Rules may be amended by the Director without a public hearing. All current appendices to the Rules shall be available on the Department website.

§20-3-5 <u>Enforcement Authority</u>. Except as otherwise specified in these Rules, the Director shall be responsible for the administration and enforcement of the requirements and regulations contained in these Rules.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-6 <u>Enforcement of Post-Construction Violations</u>. Violations involving the failure to effectively prevent Pollutant Discharges to the MS4 or Receiving Waters and violations involving the failure to properly inspect, document, implement, monitor, use, or maintain Permanent BMPs may be enforced by the Director of the Department of Facility Maintenance.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-7 Responsible Parties. The owner of Real property located within the City and County of Honolulu is absolutely responsible for compliance with these Rules and shall be held liable for any violations occurring on, or, arising from, their property. In addition, the Director may hold any person that causes, contributes to, or fails to prevent a violation of these Rules responsible for the violation and any penalties for the same. Where more than one person is deemed responsible for a violation, the Director may cite and penalize each responsible person separately or hold one or more responsible parties jointly and severally responsible for the violation and penalty.

[Eff December 24, 2018] (Auth: ROH §§ 1-9.1, 14-12.1 et. seq., ROH § 14-13.1 et. seq., ROH § 14-16.1 et. seq.) (Imp: ROH § 14-12.1 et. seq).

- §20-3-8 <u>Additional Standards</u>. The reader is advised to review the documents listed below for informational purposes:
- (a) City and County of Honolulu, Storm Water Best Management Practices Manual, Construction, 2011 (as amended);
  - (b) City and County of Honolulu, Storm Water BMP Guide, 2012 (as amended);
- (c) City and County of Honolulu, Storm Water Management Program Plan, 2016 (as amended);
- (d) Hawaii Administrative Rules, Title 11, Chapter 54, Water Quality Standards, 2014 (as amended); and
- (e) Hawaii Administrative Rules, Title 11, Chapter 55, Water Pollution Control, 2014 (as amended).

[ Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2).

# SUBCHAPTER 2 GENERAL REQUIREMENTS FOR DEVELOPMENT AND LAND DISTURBING ACTIVITIES

§20-3-9	Best Management Practices Required
§20-3-10	Minimum BMP Requirements
§20-3-11	Conditions of Approval
§20-3-12	BMP Use and Maintenance Required

§20-3-9 <u>Best Management Practices Required</u>. All persons who engage in Development or Land Disturbing Activities shall install, implement, and maintain appropriate BMPs to prevent the Discharge of Pollutants to the MS4 and Receiving Waters.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 18-4.1) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-10 <u>Minimum BMP Requirements</u>. BMPs for all Development and Land Disturbing Activities must effectively prevent the Discharge of the following to the MS4 and Receiving Waters:
  - (a) Material that will settle to form objectionable sludge or bottom deposits;
  - (b) Floating debris, oil, grease, scum or particulates;
- (c) Substances in amounts sufficient to produce taste in the water or detectable flavor in the flesh of aquatic life, or in amounts sufficient to produce objectionable color, turbidity, or other conditions in Receiving Waters;
- (d) High or low temperatures; biocides, pathogenic organisms, toxic, radioactive, corrosive, or other deleterious substances at levels or in combinations sufficient to be toxic or harmful to human, animal, or plant life, or in amounts to interfere with the beneficial uses of water;
- (e) Substances or conditions or combinations thereof in concentrations that produce undesirable aquatic life;
- (f) Soil particles resulting from erosion on land involved in earthwork, such as the construction of public works, highways, subdivisions, recreational, commercial, or industrial Developments, or the cultivation and management of agricultural lands; and
- (g) Discharges that cause or contribute to a violation of Chapter 11-54 of the Hawaii Administrative Rules.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 18-4.1) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-11 <u>Conditions of Approval</u>. The Director may condition the approval of any permit issued by the Department on the implementation and maintenance of temporary or permanent BMPs to address the following to the Maximum Extent Practicable:
  - (a) Erosion Control;

- (b) Run-on Control;
- (c) Run-off Control;
- (d) Sediment Control;
- (e) Pollution Control;
- (f) Post-Construction Pollutant Control;
- (g) Low Impact Development objectives; and
- (h) Water treatment and/or remediation.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 18-4.1) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-12 <u>BMP Use and Maintenance Required.</u> (a) All BMPs must be designed, used, and maintained in compliance with the standards and specifications set forth in these rules at all times. Where these Rules do not provide standards and specifications for a BMP, the BMP must be installed and maintained in compliance with the manufacturer's specifications, which must be kept onsite and immediately made available for inspection upon request by the Director. If BMPs fail, notwithstanding their intent or design, the BMPs shall be modified or upgraded to prevent any further failure in the same or similar circumstances.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 18-4.1) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

## SUBCHAPTER 3 PROJECT CATEGORIES AND CLASSIFICATIONS

- §20-3-13 Projects
- §20-3-14 Project Categories for Development
- §20-3-13 <u>Projects.</u> (a) A Project is the sum of all Development and Land Disturbing Activities that are planned or conducted on a Project Site. Individual actions, Project phases, and incremental improvements to Real property shall be construed as a single Project where:
  - (1) The Development and any associated Land Disturbing Activities are phases or increments of a larger total Project or undertaking;
  - (2) The Development and any associated Land Disturbing Activities are a necessary precedent for a larger total Project or undertaking;
  - (3) The Development and any associated Land Disturbing Activities represent a commitment to a larger Project or undertaking; or
  - (4) The combined effects of Development and Land Disturbing Activities on adjoining lots cannot be adequately addressed by separate BMP planning and/or implementation.
- (b) All Development shall be categorized as a Trenching Project, Category 1A, Category 1B, Category 1C, Category 2, Category 3, Category 4, Category 5 Project, or as Minor Development.

(c) Where Development qualifies a Project for placement in more than one Project category, the higher Project category shall apply to that Project unless it meets the criteria to be categorized as Minor Development.

- §20-3-14 <u>Project Categories for Development</u>. (a) Trenching Projects. Development that requires a trenching permit for excavation work in the City owned or City maintained roads and thoroughfare but does not require a building, grading, grubbing, or stockpiling permit.
- (b) Category 1A Projects. Development that requires a building permit but does not require a grading, grubbing, or stockpiling permit shall be classified as a Category 1A Project if it meets all of the following criteria:
  - (1) The Development is for single-family or two-family dwellings;
  - (2) The total Disturbed Area for the Project is less than 1,000 square feet; and
  - (3) Land Disturbing Activities will not occur on slopes equal to or greater than 15 percent at the Site.
  - (c) Category 1B Projects. The following shall be classified as a Category 1B:
    - (1) Development with less than one acre of Disturbed Area that requires a building permit, which does not meet the Category 1A Project criteria, and does not require a grading, grubbing, or stockpiling permit; or
    - (2) Development of the zoning lot or portion thereof subject to the permit is less than 15,000 square feet for single-family or two-family dwelling uses and less than 7,500 square feet for other uses that requires a building permit and a grading or stockpiling permit.
- (d) Category 1C Projects. Development that requires a building permit but is not required to obtain a grading, grubbing, or stockpiling permit shall be classified as a Category 1C Project if it involves a Disturbed Area of one acre or more or requires a NPDES General/Individual Permit Authorizing Discharges of Storm Water Associated with Construction Activity, issued by the DOH.
- (e) Category 2 Projects. Development requiring a grading or stockpiling permit but does not require a building permit shall be classified as a Category 2 Project if the area of the zoning lot or portion thereof subject to the permit is less than 15,000 square feet for single-family or two-family dwelling uses and less than 7,500 square feet for other uses.
- (f) Category 3 Projects. Development requiring a grading, grubbing, or stockpiling permit shall be classified as a Category 3 Project if the area of the zoning lot or portion thereof subject to the permit is 15,000 square feet or more for single-family or two-family dwelling uses, or 7,500 square feet or more for other uses, but where the total area graded or stockpiled upon is less than 15,000 square feet for single-family or two-family dwellings uses and less than 7,500 square feet for other uses.
- (g) Category 4 Projects. Development requiring a grading, grubbing, or stockpiling permit shall be classified as a Category 4 Project if the total area including any areas developed incrementally that is to be graded, grubbed, or stockpiled upon is 15,000 square feet or more for single-family or two-family dwelling uses, or 7,500 square feet or more for other uses, or in the

event a proposed cut or fill is greater than 15 feet in height for single-family or two-family dwelling uses, or 7.5 feet in height for other uses.

- (h) Category 5 Projects. Development requiring a grading, grubbing, or stockpiling permit shall be classified as a Category 5 Project if it involves a Disturbed Area of one acre or more and which requires a NPDES General/Individual Permit Authorizing Discharges of Storm Water Associated with Construction Activity issued by the DOH.
  - (i) Minor Development.
    - (1) Development that requires a trenching, building, grading, grubbing or stockpiling permit where the Project scope is limited to the following activities shall be classified as Minor Development:
      - (i) Work where Land Disturbing Activities are limited to incidental equipment and material staging for permitted work which is not land disturbing. Examples include enclosing existing outdoor patios or lanais and second story additions where the existing concrete slab will remain;
      - (ii) The installation of temporary BMPs;
      - (iii) Land Disturbing Activity that takes place completely under a roof or other enclosure and where existing site conditions preclude storm water run-on to the Disturbed Area;
      - (iv) The construction of individual bus shelters;
      - (v) The installation of footings or posts for the construction of fences, decks, roof coverings, and trellises for single-family or two-family dwelling use;
      - (vi) Trenching project that takes place in the City right-of-way for laterals serving one property;
      - (vii) Borings; and
      - (viii) Work not listed above that disturbs no greater than 120 square feet of land, except for fence wall, retaining wall, and driveway apron projects.
    - (2) The Director may require the Owner of a Minor Development Project to develop and implement an ESCP if necessary to achieve compliance with the requirements of these Rules to reduce Pollutant Discharges to the MS4 and/or Receiving Waters to the MEP. A Minor Development Project may be recategorized as a Category 1A, 1B or Trenching Project and subject to the requirements in Subchapters 4 and 5 if the Director determines that an ESCP is necessary.
    - (3) Minor Development Projects must include the following notes with the approved construction plans.
      - (i) Use Best Management Practices (BMPs) to prevent and reduce the discharge of pollutants from the project site onto off-site streets, storm drains, streams and the ocean. Potential pollutants include but are not limited to soil, oil products, paint, solvents, construction demolition waste, trash, portable toilets, AC materials, concrete, and any other liquid, paving or washout material that could be detrimental if released to the environment.
      - (ii) Any exposed soil from this activity must be permanently or

- temporarily stabilized immediately using vegetation, gravel, pavers, rolled erosion control products, or an equivalent method unless active work is scheduled within 14 days.
- (iii) All construction waste and washout water must be properly contained and disposed of.
- (iv) Sediment tracked off site must be swept or vacuumed daily.
- (v) Dust from the project site shall not be transported or discharged to off-site areas. The work must be in conformance with air pollution control standards contained in the Hawaii Administrative Rules: Title 11 Chapter 60.1, "Air Pollution Control."

# SUBCHAPTER 4 REQUIREMENTS FOR REGULATED PROJECTS AND ACTIVITIES DURING CONSTRUCTION

§20-3-15	Erosion and Sediment Control Plans for Development
§20-3-16	Processing and Approval of Erosion and Sediment Control Plans
§20-3-17	Requirements for Trenching Projects
§20-3-18	Requirements for Category 1A Projects
§20-3-19	Requirements for Category 1B Projects
§20-3-20	Requirements for Category 1C Projects
§20-3-21	Requirements for Category 2 Projects
§20-3-22	Requirements for Category 3 Projects
§20-3-23	Requirements for Category 4 Projects
§20-3-24	Requirements for Category 5 Projects
§20-3-25	Additional Requirements for Development Projects
§20-3-26	BMP Inspections

- §20-3-15 <u>Erosion and Sediment Control Plans for Development</u>. (a) No person shall conduct, participate in, or allow any Development categorized as a Trenching Project, Category 1A, 1B, 1C, 2, 3, 4 or 5 Project without an Erosion and Sediment Control Plan (ESCP) approved by the Director.
- (b) It is a violation of these Rules to conduct, participate in, or allow any Development categorized as a Trenching Project, Category 1A, 1B, 1C, 2, 3, 4 or 5 Project that is not conducted in accordance with an ESCP approved by the Director.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-16 Processing and Approval of Erosion and Sediment Control Plans. (a)

ESCPs must be reviewed and approved by the Director prior to issuance of a building, grading, grubbing, stockpiling, or trenching permit for Development categorized as a Trenching Project, Category 1A, 1B, 1C, 2, 3, 4 or 5 Project.

- (b) ESCPs shall be submitted to the Director for review and approval with the first set of plans for a building, grading, grubbing, stockpiling, or trenching permit for work on the Project or Site.
- (c) The Director shall review ESCPs for conformance with the requirements of these Rules and require any revisions necessary to achieve compliance with these Rules. The Director may condition the approval of an ESCP on the implementation, use, and/or maintenance of BMPs not expressly required by these Rules if additional BMPs are necessary to reduce Pollutant Discharges to the MS4 and/or Receiving Waters to the MEP.
- (d) Minor changes to an ESCP may be made during construction if approved by a Department Inspector. Minor changes to an ESCP shall be noted on the Site copy of the ESCP and initialed by the approving inspector.
- (e) Major changes to an ESCP must be proposed to the Director in writing and approved by the Director before work resumes.
- (f) Each failure to comply with the requirements of an ESCP approved by the Director shall be a separate violation of these rules. In addition, each day continuance of a violation shall be separate offense.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 18-4.1) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1 18-5.1).

- §20-3-17 <u>Requirements for Trenching Projects.</u> (a) Projects which require a trenching permit but do not require a building, grading, grubbing, or stockpiling permit must include, at a minimum, the following BMPs as part of their trenching plan and notes which shall constitute the ESCP:
  - (1) Project Scheduling;
  - (2) Storm Drain Inlet Protection for storm drains that may receive runoff from the Disturbed Area;
  - (3) Stockpile Management BMPs;
  - (4) Perimeter Controls;
  - (5) Dewatering Operations BMPs; and
  - (6) Good Housekeeping Practices for work area and staging areas.
- (b) The owner of the property or their Authorized Agent must sign the Trenching Project ESCP and must designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") using the form provided as Appendix A to these Rules. The form must include the name, phone number, mailing address, and email address of the ESCP Coordinator and must be signed by the owner of the property or their Authorized Agent and the ESCP Coordinator prior to permit issuance. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.

- §20-3-18 Requirements for Category 1A Projects. (a) ESCPs for Category 1A Projects may be prepared by the owner of the property subject to Development or their Authorized Agent. The owner or their Authorized Agent must sign the ESCP and shall designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules or the Small Project ESCP Template provided as Appendix B to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
- (b) ESCPs for Category 1A Projects shall include, at a minimum, a BMP Site Plan, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs and any drainage Structures and Receiving Waters located within 50 feet of the Project Site.
  - (c) ESCPs for Category 1A Projects shall include, at a minimum, BMPs to address and achieve:
    - (1) Erosion Control which shall include the following BMPs:
      - (i) Project Planning and Design;
      - (ii) Project Scheduling; and
      - (iii) Permanent Stabilization.
    - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
      - (i) Storm Drain Inlet Protection; and
      - (ii) Perimeter Controls.
    - (3) Good Housekeeping practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
      - (i) BMP and Site Maintenance;
      - (ii) Dust Control;
      - (iii) Material Delivery, Storage, and Use BMPs;
      - (iv) Stockpile Management BMPs;
      - (v) Spill Prevention and Control BMPs;
      - (vi) Solid Waste Management BMPs:
      - (vii) Hazardous Waste Management BMPs;
      - (viii) Contaminated Soil Management BMPs:
      - (ix) Concrete Waste Management BMPs;
      - (x) Sanitary/Septic Waste Management BMPs;
      - (xi) Liquid Waste Management BMPs;
      - (xii) Vehicle and Equipment Cleaning BMPs;
      - (xiii) Vehicle and Equipment Fueling BMPs;
      - (xiv) Vehicle and Equipment Maintenance BMPs; and
      - (xv) Tracking Control.
- (d) ESCPs for Category 1A Projects shall be completed using the Small Project ESCP template provided as Appendix B to these Rules or as a set of drawings, design details and notes with equivalent information to Appendix B, and may include additional plans and materials to aid the Director's review.
- (e) If any of the BMPs listed above are not included in an ESCP for a Category 1A Project, the ESCP narrative shall provide a brief explanation of why the omitted BMP is unnecessary or impracticable for the Project.

- (f) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (g) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

- §20-3-19 Requirements for Category 1B Projects. (a) ESCPs for Category 1B Projects may be prepared by the owner of the property subject to Development or their Authorized Agent. The owner or Authorized Agent must sign the ESCP and shall designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules or the Small Project ESCP Template provided as Appendix B to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
- (b) ESCPs for Category 1B Projects shall include, at a minimum, a BMP Site Plan, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs and any drainage Structures and Receiving Waters located within 50 feet of the Project Site.
  - (c) ESCPs for Category 1B Projects shall include, at a minimum, BMPs to address and achieve:
    - (1) Erosion Control which shall include the following BMPs:
      - (i) Project Planning and Design;
      - (ii) Project Scheduling;
      - (iii) Slope Management and Protection;
      - (iv) Temporary Stabilization; and
      - (v) Permanent Stabilization.
    - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
      - (i) Storm Drain Inlet Protection; and
      - (ii) Perimeter Controls.
    - (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
      - (i) BMP and Site Maintenance;
      - (ii) Dust Control;
      - (iii) Material Delivery, Storage, and Use BMPs;
      - (iv) Stockpile Management BMPs;
      - (v) Spill Prevention and Control BMPs;
      - (vi) Solid Waste Management BMPs;
      - (vii) Hazardous Waste Management BMPs;
      - (viii) Contaminated Soil Management BMPs;

- (ix) Concrete Waste Management BMPs;
- (x) Sanitary/Septic Waste Management BMPs;
- (xi) Liquid Waste Management BMPs;
- (xii) Vehicle and Equipment Cleaning BMPs;
- (xiii) Vehicle and Equipment Fueling BMPs;
- (xiv) Vehicle and Equipment Maintenance BMPs; and
- (xv) Tracking Control.
- (d) ESCPs for Category 1B Projects shall be completed using the Small Project ESCP template provided as Appendix B to these Rules or as a set of drawings, design details and notes with equivalent information to Appendix B, and may include additional plans and materials to aid the Director's review.
- (e) If any of the BMPs listed above are not included in an ESCP for a Category 1B Project, the ESCP narrative shall provide a brief explanation of why the omitted BMP is unnecessary or impracticable for the Project.
- (f) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (g) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

- §20-3-20 Requirements for Category 1C Projects. (a) ESCPs for Category 1C Projects must be prepared by a Certified Erosion and Sediment Control Plan Preparer. The owner of the property or their Authorized Agent must designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
  - (b) The ESCP shall include, at a minimum:
    - (1) A location map showing the name, coordinate, and classification (e.g., Class 1, 2, Class A, Class AA waters) of Receiving Waters, as identified through the DOH State Water Quality Map, available at the DOH Clean Water Branch website;
    - (2) A vicinity map showing the location of streams, channels, and drainage Structures located within 100 feet of the Project Site;
    - (3) The location of the 100-year flood plain as shown on the FEMA Map Service Center website;
    - (4) The location of drainage Structures located within 100 feet of the Project Site;
    - (5) Topographic maps showing the existing and finished contours of the Site;
    - (6) Existing and final drainage patterns and Discharge points;
    - (7) Proposed Structures, impervious areas, existing vegetation, final

- landscaping conditions, and appurtenant improvements;
- (8) Erosion Control construction notes including non-structural BMPs that cannot be shown on a Site plan;
- (9) A BMP Site Plan, drawn to scale, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs;
- (10) BMP design details and notes clearly identifying temporary BMPs, permanent BMPs, a schedule for BMP implementation, and BMP maintenance activities;
- (11) A list or table of preconstruction, during construction, and post-construction BMPs;
- (12) Any additional information required by the Director.
- (c) ESCPs for Category 1C Projects shall include, at a minimum, BMPs to address and achieve:
  - (1) Erosion Control which shall include the following BMPs:
    - (i) Project Planning and Design;
    - (ii) Project Scheduling;
    - (iii) Slope Management and Protection;
    - (iv) Temporary Stabilization;
    - (v) Permanent Stabilization;
    - (vi) Diversion BMPs to divert runoff from upstream areas around Disturbed Areas of the Site;
    - (vii) Velocity Dissipation Devices;
    - (viii) Preserve Existing Vegetation; and
    - (ix) Minimize Soil Compaction.
  - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include following BMPs:
    - (i) Storm Drain Inlet Protection:
    - (ii) Perimeter Controls;
    - (iii) Buffer Zones; and
    - (iv) Sediment Barriers.
  - (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
    - (i) BMP and Site Maintenance;
    - (ii) Dust Control;
    - (iii) Material Delivery, Storage and Use BMPs;
    - (iv) Stockpile Management BMPs;
    - (v) Spill Prevention and Control BMPs;
    - (vi) Solid Waste Management BMPs;
    - (vii) Hazardous Waste Management BMPs;
    - (viii) Contaminated Soil Management BMPs;
    - (ix) Concrete Waste Management BMPs;
    - (x) Sanitary/Septic Waste Management BMPs;
    - (xi) Liquid Waste Management BMPs;
    - (xii) Vehicle and Equipment Cleaning BMPs;

- (xiii) Vehicle and Equipment Fueling BMPs;
- (xiv) Vehicle and Equipment Maintenance BMPs;
- (xv) Tracking Control;
- (xvi) Stabilized Construction Entrance and Exit; and
- (xvii) Dewatering Operations BMPs.
- (d) If any of the BMPs listed above are not included in an ESCP for a Category 1C Project, the ESCP notes shall provide a list of the omitted BMPs with a brief explanation of why each omitted BMP is unnecessary or impracticable for the Project.
- (e) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (f) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

- §20-3-21 Requirements for Category 2 Projects. (a) ESCPs for Category 2 Projects may be prepared by the owner of the property subject to Development or their Authorized Agent. The owner or Authorized Agent must sign the ESCP and shall designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules or the Small Project ESCP Template provided as Appendix B to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
- (b) ESCPs for Category 2 Projects shall include, at a minimum, a BMP Site Plan, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs and any drainage Structures and Receiving Waters located within 50 feet of the Project Site.
- (c) ESCPs for Category 2 Projects shall include, at a minimum, BMPs to address and achieve:
  - (1) Erosion Control which shall include the following BMPs:
    - (i) Project Planning and Design;
    - (ii) Project Scheduling;
    - (iii) Slope Management and Protection;
    - (iv) Temporary Stabilization; and
    - (v) Permanent Stabilization.
  - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
    - (i) Storm Drain Inlet Protection; and
    - (ii) Perimeter Controls.
  - (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:

- (i) BMP and Site Maintenance;
- (ii) Dust Control;
- (iii) Material Delivery, Storage, and Use BMPs;
- (iv) Stockpile Management BMPs;
- (v) Spill Prevention and Control BMPs;
- (vi) Solid Waste Management BMPs;
- (vii) Hazardous Waste Management BMPs;
- (viii) Contaminated Soil Management BMPs;
- (ix) Concrete Waste Management BMPs;
- (x) Sanitary/Septic Waste Management BMPs;
- (xi) Liquid Waste Management BMPs;
- (xii) Vehicle and Equipment Cleaning BMPs;
- (xiii) Vehicle and Equipment Fueling BMPs;
- (xiv) Vehicle and Equipment Maintenance; and
- (xv) Tracking Control.
- (d) ESCPs for Category 2 Projects shall be completed using the Small Project ESCP template provided as Appendix B to these Rules or as a set of drawings, design details and notes with equivalent information to Appendix B, and may include additional plans and materials to aid the Director's review.
- (e) If any of the BMPs listed above are not included in an ESCP for a Category 2 Project, the ESCP notes shall provide a list of the omitted BMPs that are unnecessary or impracticable for the Project.
- (f) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (g) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

- §20-3-22 Requirements for Category 3 Projects. (a) ESCPs for Category 3 Projects must be prepared by a Certified Erosion and Sediment Control Plan Preparer. The owner of the property or their Authorized Agent must designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
  - (b) The ESCP shall include, at a minimum:
    - (1) A BMP Site Plan, drawn to scale, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs;
    - (2) Construction notes with a narrative description of any BMPs that cannot be shown on a Site plan; and

- (3) A vicinity map showing any drainage Structures and Receiving Waters located within 50 feet of the Project Site.
- (c) ESCPs for Category 3 Projects must include, at a minimum, BMPs to address and achieve:
  - (1) Erosion Control which shall include the following BMPs:
    - (i) Project Planning and Design;
    - (ii) Project Scheduling;
    - (iii) Slope Management and Protection;
    - (iv) Temporary Stabilization;
    - (v) Permanent Stabilization; and
    - (vi) Velocity Dissipation Devices.
  - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
    - (i) Storm Drain Inlet Protection;
    - (ii) Perimeter Controls; and
    - (iii) Sediment Barriers.
  - (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
    - (i) BMP and Site Maintenance;
    - (ii) Dust Control;
    - (iii) Material Delivery, Storage, and Use BMPs;
    - (iv) Stockpile Management BMPs;
    - (v) Spill Prevention and Control BMPs;
    - (vi) Solid Waste Management BMPs;
    - (vii) Hazardous Waste Management BMPs;
    - (viii) Contaminated Soil Management BMPs;
    - (ix) Concrete Waste Management BMPs;
    - (x) Sanitary/Septic Waste Management BMPs;
    - (xi) Liquid Waste Management BMPs:
    - (xii) Vehicle and Equipment Cleaning BMPs;
    - (xiii) Vehicle and Equipment Fueling BMPs:
    - (xiv) Vehicle and Equipment Maintenance;
    - (xv) Tracking Control;
    - (xvi) Stabilized Construction Entrance and Exit; and
    - (xvii) Dewatering Operations BMPs.
- (d) If any of the BMPs listed above are not included in an ESCP for a Category 3 Project, the ESCP notes shall provide a list of omitted BMPs with a brief explanation of why each omitted BMP is unnecessary or impracticable for the Project.
- (e) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (f) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

- §20-3-23 Requirements for Category 4 Projects. (a) ESCPs for Category 4 Projects must be prepared by a Certified Erosion and Sediment Control Plan Preparer. The owner of the property or their Authorized Agent must designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules. Changes to the ESCP Coordinator shall be submitted to the Director in writing immediately for the Department's acceptance.
  - (b) The ESCP shall include, at a minimum:
    - (1) A location map showing the name, coordinate, and classification (e.g., Class 1, 2, Class A, Class AA waters) of Receiving Waters, as identified through the DOH State Water Quality Map, available at available at the DOH Clean Water Branch website;
    - (2) A vicinity map showing the location of streams, channels, and drainage Structures located within 100 feet of the Project Site;
    - (3) The location of the 100-year flood plain as shown on the FEMA Map Service Center website;
    - (4) The location of drainage Structures located within 100 feet of the Project Site;
    - (5) Topographic maps showing the existing and finished contours of the Site;
    - (6) Existing and final drainage patterns and Discharge points;
    - (7) Proposed Structures, impervious areas, existing vegetation, final landscaping conditions, and appurtenant improvements;
    - (8) Erosion Control construction notes including non-structural BMPs that cannot be shown on a Site plan;
    - (9) A BMP Site Plan, drawn to scale, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs;
    - (10) BMP design details and notes clearly identifying temporary BMPs, permanent BMPs, a schedule for BMP implementation, and BMP maintenance activities;
    - (11) A list or table of preconstruction, during construction, and post-construction BMPs; and
    - (12) Any additional information required by the Director.
  - (c) ESCPs for Category 4 shall include, at a minimum, BMPs to address and achieve:
    - (1) Erosion Control which shall include the following BMPs:
      - (i) Project Planning and Design;
      - (ii) Project Scheduling;
      - (iii) Slope Management and Protection;
      - (iv) Temporary Stabilization;
      - (v) Permanent Stabilization;
      - (vi) Velocity Dissipation Devices; and
      - (vii) Diversion BMPs to divert runoff from upstream areas around

Disturbed Areas of the Site.

- (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
  - (i) Storm Drain Inlet Protection;
  - (ii) Perimeter Controls; and
  - (iii) Sediment Barriers.
- (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
  - (i) BMP and Site Maintenance;
  - (ii) Dust Control;
  - (iii) Material Delivery, Storage and Use BMPs;
  - (iv) Stockpile Management BMPs;
  - (v) Spill Prevention and Control BMPs;
  - (vi) Solid Waste Management BMPs;
  - (vii) Hazardous Waste Management BMPs;
  - (viii) Contaminated Soil Management BMPs;
  - (ix) Concrete Waste Management BMPs;
  - (x) Sanitary/Septic Waste Management BMPs;
  - (xi) Liquid Waste Management BMPs;
  - (xii) Vehicle and Equipment Cleaning BMPs;
  - (xiii) Vehicle and Equipment Fueling BMPs;
  - (xiv) Vehicle and Equipment Maintenance BMPs;
  - (xv) Tracking Control;
  - (xvi) Stabilized Construction Entrance and Exit; and
  - (xvii) Dewatering Operations BMPs.
- (d) If any of the BMPs listed above are not included in an ESCP for a Category 4 Project, the ESCP notes shall provide a list of the omitted BMPs with a brief explanation of why each omitted BMP is unnecessary or impracticable for the Project.
- (e) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (f) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

§20-3-24 Requirements for Category 5 Projects. (a) ESCPs for Category 5 Projects must be prepared by a Certified Erosion and Sediment Control Plan Preparer. The owner of the property or their Authorized Agent must designate a person responsible for implementing the ESCP at the Project Site ("ESCP Coordinator") prior to permit issuance using the form provided as Appendix A to these Rules. Changes to the ESCP Coordinator shall be submitted to the

Director in writing immediately for the Department's acceptance.

- (b) The ESCP shall include, at a minimum:
  - (1) A location map showing the name, coordinate, and classification (e.g., Class 1, 2, Class A, Class AA waters) of Receiving Waters, as identified through the DOH State Water Quality Map, available at the DOH Clean Water Branch website;
  - (2) A vicinity map showing the location of streams, channels, and drainage Structures located within 100 feet of the Project Site;
  - (3) The location of the 100-year flood plain as shown on the FEMA Map Service Center website;
  - (4) The location of drainage Structures located within 100 feet of the Project Site;
  - (5) Topographic maps showing the existing and finished contours of the Site;
  - (6) Existing and final drainage patterns and Discharge points;
  - (7) Proposed Structures, impervious areas, existing vegetation, final landscaping conditions, and appurtenant improvements;
  - (8) Erosion Control construction notes including non-structural BMPs that cannot be shown on a Site plan;
  - (9) A BMP Site Plan, drawn to scale, which depicts the outline of buildings and Structures, provides a clear delineation of Disturbed Areas, and the proximate location of proposed BMPs;
  - (10) BMP design details and notes clearly identifying temporary BMPs, permanent BMPs, a schedule for BMP implementation, and BMP maintenance activities;
  - (11) A list or table of preconstruction, during construction, and post-construction BMPs; and
  - (12) Any additional information required by the Director.
- (c) ESCPs shall include, at a minimum, BMPs to address and achieve:
  - (1) Erosion Control which shall include the following BMPs:
    - (i) Project Planning and Design:
    - (ii) Project Scheduling;
    - (iii) Slope Management and Protection;
    - (iv) Temporary Stabilization;
    - (v) Permanent Stabilization;
    - (vi) Diversion BMPs to divert runoff from upstream areas around Disturbed Areas of the Site;
    - (vii) Velocity Dissipation Devices;
    - (viii) Preserve Existing Vegetation; and
    - (ix) Minimize Soil Compaction.
  - (2) Sediment Control to prevent release of sediment laden waters to the MS4 and Receiving Waters, which shall include the following BMPs:
    - (i) Storm Drain Inlet Protection;
    - (ii) Perimeter Controls;
    - (iii) Buffer Zones;
    - (iv) Sediment Traps;
    - (v) Sediment Basins; and

- (vi) Sediment Barriers.
- (3) Good Housekeeping Practices to prevent and Minimize Pollutant Discharges to the MS4 and Receiving Waters, which shall include the following BMPs:
  - (i) BMP and Site Maintenance;
  - (ii) Dust Control;
  - (iii) Material Delivery, Storage and Use BMPs;
  - (iv) Stockpile Management BMPs;
  - (v) Spill Prevention and Control BMPs;
  - (vi) Solid Waste Management BMPs;
  - (vii) Hazardous Waste Management BMPs;
  - (viii) Contaminated Soil Management BMPs;
  - (ix) Concrete Waste Management BMPs;
  - (x) Sanitary/Septic Waste Management BMPs;
  - (xi) Liquid Waste Management BMPs;
  - (xii) Vehicle and Equipment Cleaning BMPs;
  - (xiii) Vehicle and Equipment Fueling BMPs;
  - (xiv) Vehicle and Equipment Maintenance BMPs;
  - (xv) Tracking Control;
  - (xvi) Stabilized Construction Entrance and Exit; and
  - (xvii) Dewatering Operations BMPs.
- (d) If any of the BMPs listed above are not included in an ESCP for a Category 5 Project, the ESCP notes shall provide a list of the omitted BMPs with a brief explanation of why each omitted BMP is unnecessary or impracticable for the Project.
- (e) The Director shall approve an ESCP if it complies with the requirements of these Rules and reduces the risk of onsite erosion, off-site sedimentation, and Pollutant Discharges to the MS4 and Receiving Waters to the MEP. The Director may require revisions to ESCPs and Project schedules or approve the same subject to conditions in order to achieve practicable reductions to the risk of Pollutant Discharges to the MS4 and/or Receiving Waters.
- (f) Copies of the approved ESCP and Project schedule must be kept on the Project Site at all times and immediately made available for review by the Director upon request.

#### §20-3-25 Additional Requirements for Development Projects.

- (a) Category 1C and Category 5 Projects may not begin work unless an NPDES General/Individual Permit Authorizing Discharges of Storm Water Associated with Construction Activity has been issued by the DOH.
- (b) Dewatering non-storm water. For all categories, including work for trenching permits only, non-storm water from dewatering activities shall not be Discharged from the Site unless an NPDES Permit Authorizing Discharges Associated with Construction Activity Dewatering has been issued by the DOH.
- (c) Hydrotesting water. For all categories, including work for trenching permits only, hydrotesting water shall not be Discharged from the Site unless an NPDES Permit Authorizing

Discharges of Hydrotesting Waters has been issued by the DOH.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

- §20-3-26 <u>BMP Inspections.</u> (a) All Projects involving Development or Land Disturbing Activities shall be inspected on a regular basis to ensure that BMPs are properly installed, used, and maintained.
- (b) A preconstruction inspection must be performed for Trenching Projects and all Categories 1A to 5 Projects by the ESCP Coordinator prior to commencing ground-disturbing activities, to confirm that BMPs are installed correctly and according to the ESCP.
- (c) Requirements for Category 1A, 1B, and 2 Projects. Category 1A, 1B and 2 Projects must be inspected once every 30 days by the ESCP Coordinator. However, if the Project will be completed in less than thirty days, inspection shall occur midway through the Project. Inspection results and corrective actions shall be documented with photographs and by completing the form provided as Appendix C to these Rules.
- (d) Requirements for Category 3 and 4 Projects and Trenching Projects. Category 3 and 4 Projects and Trenching Projects must be inspected by the ESCP Coordinator once every seven days. Inspection results and corrective actions shall be documented with photographs and by completing the form provided as Appendix C to these Rules.
- (e) Requirements for Category 1C and 5 Projects. Category 1C and 5 Projects must be inspected by the ESCP Coordinator once every seven days. Inspection results and corrective actions shall be documented with photographs and by completing the form provided as Appendix D to these Rules.
- (f) Any deficiencies or BMPs that may violate any provision of these Rules or may result in Pollutant Discharges to the MS4 or State Waters and requires corrective actions shall be addressed immediately.
- (g) All photographs and inspection reports must be compiled in a 3-ring folder or binder or kept electronically, which shall be the Project Log. The Project Log shall be kept on Site or electronically accessible from the Site at all times, in a complete condition, and immediately produced for inspection if request by the Director.
- (h) At the conclusion of the Project, the property owner, Authorized Agent, or ESCP Coordinator shall inspect the Site and confirm that all Disturbed Areas have been stabilized and all temporary BMPs have been removed. An electronic copy of the final Project Log and a letter confirming compliance with this subsection shall be provided to the Director within 5 business days of completing work on the Project. Permits for work on the Project Site will not be closed until compliance with this subsection is achieved.

# SUBCHAPTER 5 BMPS, STANDARDS, AND SPECIFICATIONS FOR ACTIVITIES DURING CONSTRUCTION

§20-3-27	Project Planning and Design
§20-3-28	Project Scheduling
§20-3-29	Slope Management and Protection
§20-3-30	Temporary Stabilization
§20-3-31	Permanent Stabilization
§20-3-32	Diversion BMPs
§20-3-33	Preservation of Existing Vegetation
§20-3-34	Minimize Soil Compaction
§20-3-35	Velocity Dissipation Devices
§20-3-36	Perimeter Control
§20-3-37	Silt Fences
§20-3-38	Sediment Barriers
§20-3-39	Storm Drain Inlet Protection
§20-3-40	Vegetated Buffers
§20-3-41	Sediment Basins
§20-3-42	Sediment Traps
§20-3-43	Tracking Control
§20-3-44	Stabilized Construction Entrances and Exits
§20-3-45	Dust Control
§20-3-46	Good Housekeeping Practices
§20-3-47	Dewatering Operations

§20-3-27 <u>Project Planning and Design</u>. (a) Projects should be planned and designed to eliminate and prevent Pollutant Discharges to the MS4 and Receiving Waters to the MEP. All Project planning and design should be executed in a manner that prioritizes the following to the MEP:

- (1) Preserve native topsoil;
- (2) Minimization of soil compaction;
- (3) Directing Discharges from storm water controls to vegetated areas;
- (4) Preservation and use of natural buffers;
- (5) Restriction of vehicle use to necessary areas;
- (6) Location of materials and stockpiles outside of buffers;
- (7) Effective primary and secondary containment for potential sources of pollution;
- (8) Establishment of effective perimeter controls;
- (9) Protection of storm drain inlets; and
- (10) Effective prohibition of off-site Discharges from wastewater and concrete washout, washout or cleanout water containing stucco, paint, release oils, curing compounds, and waste from construction materials, and Discharges containing fuels, oils, soaps, solvents, detergents, and toxic and/or hazardous substances.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

- §20-3-28 <u>Project Scheduling</u>. (a) All Trenching Permit and Category 1A, 1B, 1C, 2, 3, 4 and 5 Projects must be performed according to a written Project schedule approved by the Director.
- (b) Project schedules must establish a sequence of all planned actions and activities on the Project Site, including, but not limited to, all Land Disturbing Activities, the implementation of the BMPs identified in the Project ESCP, scheduled inspections and maintenance of BMPs, and the removal of temporary BMPs. Deadlines for the implementation and removal of BMPs shall be provided in the form of specific dates or Project milestones. The scheduled start date shall be submitted to the Director in writing or by telephone 2 weeks prior to commencing any work governed by these Rules.
- (c) Project schedules must be designed to reduce the amount and duration of soil exposed to erosion by wind, rain, runoff and vehicle tracking to the MEP and sequence Land Disturbing Activities to Minimize onsite storage of equipment, materials and wastes that may cause or contribute to pollution Discharges to the MS4 and/or Receiving Waters. In addition, all Project Schedules shall include a rain response plan that identifies work that will not be performed during defined rain conditions and/or events.
- (d) The Director may require DPP approval of BMPs and/or Site conditions at one or more points on a Project schedule before work may commence on the next sequenced action or event.
- (e) Project schedules must be revised if delays or disruptions to the Project necessitate changes to the sequence of work or BMPs. Revisions to a Project schedule must be proposed by the submission of a revised Project schedule to DPP and approved by the Director before work may be performed pursuant to the revised schedule.
- (f) A copy of the original Project schedule and all revised Project schedules must be kept on Site, in chronological order, and stored in a three-ring folder or binder or electronically, which shall be the Project Log. A complete version of the Project Log shall be on Site or electronically accessible from the Site at all times and immediately made available for inspection by the Director upon request.

- §20-3-29 <u>Slope Management and Protection</u>. (a) Land Disturbing Activities on slopes with a grade of 15 percent or greater must be Minimized to the MEP. Where necessary, work on slopes with a grade of 15 percent or more should be phased to Minimize the amount disturbed to no greater than 5 acres at any time.
- (b) Slopes with a grade of 15 percent or more must be stabilized at all times unless the slopes are being actively worked. Slope Stabilization must be initiated immediately unless active work is scheduled on the slope within 7 calendar days or where necessary due to anticipated weather conditions.

- (c) Minimum stabilization of slopes 15 percent or greater shall consist of one or more of the following:
  - (1) Rolled Erosion Control Products that conform to the requirements of the American Association of State Highway and Transportation Officials M288 may be installed and maintained per the manufacturer's specifications, which must be kept onsite at all times and immediately made available for inspection by the Director upon request;
  - (2) Hydraulic mulch or hydroseed consisting of at least 5 percent soil binder and applied at a minimum of rate of 2000 lb/acre, unless otherwise required by the manufacturer's instructions, which shall be kept onsite at all times and immediately produced for inspection upon request;
  - (3) Hydraulic or Bonded Fiber Matrix installed and maintained per the manufacturer's specifications, which must be kept onsite at all times and immediately made available for inspection by the Director upon request; or
  - (4) Planting and/or vegetation providing at least 70 percent surface cover for Temporary Stabilization and at least 90 percent surface cover for Permanent Stabilization.
- (d) Category 1C, 4 and 5 Projects with slopes with a grade of 15 percent or more must provide at minimum a 10-foot buffer with a maximum slope of 5 percent at the toe of the slope.
- (e) Category 1C, 4, and 5 Projects must provide upstream runoff diversion using such measures as earth dikes, drainage swales and/or slope drains to intercept and direct surface flow away from disturbed slope areas of 15 percent or more.

- §20-3-30 <u>Temporary Stabilization</u>. (a) Temporary Stabilization must be initiated immediately for Disturbed Areas that are not on slopes with a grade of 15 percent or more when they reach final grade or when active work is not scheduled within 14 calendar days.
- (b) Minimum stabilization of Disturbed Areas shall consist of one or more of the following:
  - (1) Rolled Erosion Control Products that conform to the requirements of the American Association of State Highway and Transportation Officials M288 may be installed and maintained per the manufacturer's specifications, which must be kept onsite at all times and immediately made available for inspection by the Director upon request;
  - (2) Hydraulic mulch or hydroseed consisting of at least 5 percent soil binder and applied at a minimum of rate of 2000 lb/acre, unless otherwise required by the manufacturer's instructions, which shall be kept onsite at all times and immediately produced for inspection upon request;
  - (3) Hydraulic or Bonded Fiber Matrix installed and maintained per the manufacturer's specifications, which must be kept onsite at all times and immediately made available for inspection by the Director upon request;

or

(4) Planting and/or vegetation providing at least 70 percent surface cover for Temporary Stabilization and at least 90 percent surface cover for Permanent Stabilization.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

- §20-3-31 <u>Permanent Stabilization</u>. (a) Prior to final approval and closing of the permits for work on the Site, permanent stabilization must be in place.
- (b) All Disturbed Areas must be stabilized with permanent Erosion Control BMPs such as vegetation, gravel, or pavers;
- (c) Rain gutters, downspouts, and channelized flows must be installed and functioning as designed;
- (d) In seeded areas, grass or vegetation must cover at least 90 percent of the disturbed soils;
- (e) Seeded areas that have not achieved 90 percent ground cover must be stabilized by tackifiers, mulch, turf reinforcement mats, or Rolled Erosion Control Products until 90 percent vegetative cover is established;
- (f) Temporary Erosion Control measures, such as sediment fences, should be removed when permanent measures are in place;
- (g) Ditches and areas of concentrated flow must be lined with rock, appropriately installed geosynthetics, or similar materials to prevent scour;
  - (h) All paved surfaces must be clean; and
- (i) Storm drain inlet filters must be removed after all cleanup activities have been completed.

- §20-3-32 <u>Diversion BMPs.</u> (a) Diversion BMPs consist of Earth Dikes, Drainage Swales and Slope Drains. Category 1C, 4, and 5 Projects must provide runoff diversion upstream of disturbed areas on slopes of 15 percent or more as described in §20-3-29(e).
- (b) Earth dikes are ridges of compacted soil that may be placed at the top or base of a disturbed slope or along the perimeter of a Disturbed Area to intercept runoff and direct flows to areas where erosion can be controlled. The tributary area addressed by a single earth dike may not exceed 5 acres. Design capacity for earth dikes must be equal to or greater than the peak flow from a 10-year, 1-hour storm. The upslope side of the dike must provide positive drainage to the dike outlet. No erosion shall occur at the outlet. Earth dikes must be fully compacted and stabilized with vegetation and/or riprap.
- (c) Drainage swales are sloped depressions in the soil surface to convey runoff to a desired location. The tributary area addressed by a single drainage swale may not exceed 5 acres. Design capacity for drainage swale must be equal to or greater than the peak flow from a 10-year, 1-hour storm. Drainage swale must be fully stabilized with vegetation and/or riprap.

(d) Earth dikes and drainage swales can be used with slope drains to divert water from the top of a slope to the bottom of a slope. Slope Drains may be a rigid pipe, such as corrugated metal, a flexible conduit, or a lined terrace drain with the inlet placed on the top of a slope and the outlet at the bottom of the slope. The capacity for temporary slope drains intercepting offsite or on-site runoff should be sufficient to convey at least the peak runoff from a 10-year, 1-hour storm. The tributary area addressed by a single slope drain may not exceed 10 acres. Outlets should be stabilized with riprap, concrete or other type of Velocity Dissipation Device, or directed into a stable sediment trap or basin.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

§20-3-33 <u>Preservation of Existing Vegetation</u>. (a) Preservation of existing vegetation is to Minimize the potential of removing or injuring existing trees, vines, shrubs, and grasses that protect soil erosion. Clearly mark the areas to be preserved with flags or temporary fencing. Where temporary fencing is used, fencing must be adequately supported by posts and maintained in an upright position.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

§20-3-34 <u>Minimize Soil Compaction</u>. (a) Areas where the final stabilization will occur and areas where Infiltration practices will be installed must be protected from excessive compaction by restricting the vehicle and equipment use to appropriate areas or implementing soil conditioning techniques.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

- §20-3-35 <u>Velocity Dissipation Devices</u>. (a) Velocity dissipation devices are channel linings, Structures, or flow barriers that are placed at outlets for storm drains, pipes, culverts, steep ditches, flumes and areas of contacted flow to lower flow velocities, prevent scour and dissipate energy.
- (b) Velocity dissipation devices are required where the Director, Engineer, or preparer of the ESCP determines that Discharge velocities and energies are sufficient to erode the immediate downstream reach of Discharges.
- (c) The apron length and materials for velocity dissipation devices must be adequate to accommodate the peak flow of a 10-year, 1-hour storm without resulting in scour or erosion in immediate downstream areas.

- §20-3-36 <u>Perimeter Controls</u>. (a) Perimeter Controls shall be required if a Project involves any Land Disturbing Activities within 50 feet of State Waters unless the Project has obtained a CWA 404 Permit for the work or the Land Disturbing Activities relate to a water-dependent structure such as a pier or boat ramp. Perimeter Controls shall also be required if the Director, Engineer, or ESCP Coordinator determines that Pollutant Discharges to the MS4 or State Waters are likely to occur based on Site conditions, the nature of planned construction activities, or the location of planned Land Disturbing Activities, or expected weather conditions.
- (b) At a minimum, perimeter controls shall consist of vegetated buffers, sediment barriers, or silt fences along those perimeter areas of the Site that will receive storm water from earth disturbing activities.
- (c) For Category 1C and 5 Projects that are within 50 feet of State Waters, perimeter controls must be installed along the perimeter of the Site along areas that will receive storm water from Disturbed Areas and consist of a 50 foot wide, undisturbed, natural buffer or in-series perimeter controls consisting of two or more sediment barriers or silt fences with spacing of at least 5 feet between the sediment barriers or silt fences (refer to §20-3-40 Vegetated Buffers).

- §20-3-37 <u>Silt Fences</u>. (a) Silt fences are temporary, linear sediment barriers that are composed of permeable fabric and vertical posts. Silt fence fabric shall conform to the requirements set forth under American Society for Testing and Materials (ASTM) designation D4632, or an approved equal, and shall have an integral reinforcement layer. The reinforcement layer shall be a polypropylene or equivalent provided by the manufacturer.
- (b) Silt fences may be used as sediment barriers on the face of slopes, at the toe of slopes, down-slope from exposed soil areas, around temporary stockpiles, along streams and channels, and along the perimeter of a Project Site.
- (c) Silt fences may not be used at the toe of slopes subject to creep, slumping, or landslides, or, in streams, channels, drain inlets and areas of concentrated flow. Slit fences may not be used to divert flows.
- (d) Silt fences used for erosion and runoff control shall comply with the following minimum design standards and criteria:
  - (1) Silt fence fabric shall be woven polypropylene with a minimum width of 36 inches and a minimum tensile strength of 100 lbs. force. The fabric shall conform to the requirements set forth under ASTM designation D4632 and shall have an integral reinforcement layer. The reinforcement layer shall be a polypropylene or equivalent provided by the manufacturer.
  - (2) Silt fence fabric shall retain 85 percent of soil by weight, based on sieve analysis. The permittivity of the fabric shall be between 0.1 sec.<sup>-1</sup> and 0.15 sec.<sup>-1</sup>
  - (3) Silt fences shall be installed along a trench line at least 6 inches wide and 6 inches deep, set back a minimum of 3 feet from the toe of an abutting slope. Silt fences shall be keyed to a minimum depth of 12 inches. Fence posts shall be no more than 6 feet apart and driven securely to a depth of no less than 18 inches from top soil or 12 inches below the trench line.

When overlap is necessary, silt fence fabric shall be spliced together securely at a fence post and overlap by no less than 6 inches. Staples used to fasten fabric to posts shall be no less than 1.75 inches long and composed of 15 gauge or heavier wire. Wire used at fence joints shall be 9 gauge or heavier. Metal stakes with holders for silt fence must have No. 4 or greater bar reinforcement.

- (4) Silt fences shall not be the only Sediment or Erosion Control BMP on slopes greater than 2:1.
- (e) Silt fence fabric has a general life of 5 to 8 months. All spilt, torn, weathered or slumping portions of any fence shall be replaced immediately.
- (f) Water depth along a silt fence may not exceed 1.5 feet at any point and accumulated sediments may not exceed one third of the fence height at any time.

- §20-3-38 <u>Sediment Barriers</u>. (a) Sediment barriers are temporary BMPs that intercept sediment-laden runoff from small drainage areas in order to slow runoff velocities and allow suspended solids to settle out of storm water. Sediment barriers may consist of gravel bags, sandbags, fiber rolls, compost filter socks a minimum of 8 inches in diameter or an equivalent BMP approved by the Director.
- (b) Sediment barriers must be used to protect disturbed or denuded soils that are not scheduled for active work within 24 hours if the Engineer, preparer of the ESCP, or Director determines that sediment Discharge to State Waters or the MS4 is likely due to Site conditions, the nature of work that will occur in the vicinity of the Disturbed Area, or the proximity of the Disturbed Area to State Waters or portions of the MS4.
- (c) Unless more specific criteria apply to the specific type of sediment barrier selected, the contributing drainage area addressed by a single sediment barrier may not exceed 1/4 acre per 100 feet of barrier length. In addition, the maximum length of slope above a barrier may not exceed 100 feet. Unless more specific criteria apply to the type of sediment barrier selected, the spacing between sediment barriers along the slopes must follow the following requirements:

Slope	Minimum Sediment Barrier Spacing			
< 5 percent	50 feet			
5 to 15 percent	30 feet			
> 15 percent	20 feet			

- (d) Sediment barriers may not be used in areas of concentrated flows, such as drainage channels, live streams or in swales where there is the possibility of a washout.
- (e) Sediment levels shall not exceed one half of the height of a sediment barrier at any point along the length of the sediment barrier.
- (f) Sediment collected from sediment barriers must be reincorporated into the Project Site or disposed of at off-site locations that are approved by the Director (refer to Solid Waste

Management §20-3-46(i)).

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

- §20-3-39 <u>Storm Drain Inlet Protection</u>. (a) All drain inlets and catch basins that are not connected to a sediment basin or trap must be protected by sediment barriers or inlet protection devices if they are capable of receiving sediment or runoff from the Project Site unless severe weather conditions make the use of such devices unsafe or Infeasible.
- (b) Sediment levels may not exceed one third of the height of a sediment barrier or inlet protection device at any point along the length of the sediment barrier or the inlet protection device.
- (c) Sediment barriers and inlet protection devices must be unclogged and cleaned when performance is compromised.
- (d) Torn, weathered or sagging sediment barriers or inlet protection devices must be repaired or replaced immediately.
- (e) Sediment collected from sediment barriers and inlet protection devices must be reincorporated into the Project Site or disposed of at off-site locations that are approved by the Director (refer to Solid Waste Management §20-3-46(i)).

- §20-3-40 <u>Vegetated Buffers</u>. (a) Vegetated buffer strips are vegetated surfaces that are designed to treat sheet flow from adjacent surfaces by slowing runoff velocities and allowing sediment and other Pollutants to settle and partially infiltrate into underlying soils.
- (b) The width of the vegetative buffer strips must have slope of 5 percent or less. The vegetative buffer must be one foot wide for every 3 feet of upslope drainage area directed to the vegetative buffer.
- (c) Categories 1C and 5 Projects must maintain a 50-foot undisturbed natural buffer and sediment control between State Waters and the Construction Site. If a 50-foot natural buffer zone cannot be maintained, provide a natural undisturbed buffer zone that is less than 50 feet and either double sediment barriers or silt fences spaced at a minimum of 5 feet apart. If it is Infeasible to provide and maintain an undisturbed natural buffer of any size, provide double sediment barriers or silt fences spaced a minimum of five feet apart and complete stabilization within 7 consecutive days of the temporary or permanent cessation of earth disturbing activities. All Discharges from the area of earth disturbance to the natural buffer must be treated by the Site's erosion and sediment controls before release to buffer areas.
- (d) Planned vegetated buffer strips must be shown in the ESCP for a Project. During clearing and grubbing, vegetation designated for use in a vegetated buffer must be enclosed by temporary fencing made of orange polypropylene that is stabilized against ultraviolet light. The temporary fencing must be at least 4 feet tall and have openings not larger than 2 inches by 2 inches. Fence posts must be comprised of wood or metal, driven securely to a depth of no less than one foot, and spacing to completely support the fence in an upright position without sagging

at all times.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 14-12.32) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 14-12.32, 18-4.1, 18-5.1).

- §20-3-41 <u>Sediment Basins</u>. (a) Sediment basins are excavated or depressed areas that are used to collect and detain runoff to allow suspended solids to settle out of storm water before storm water is Discharged to off-site areas.
- (b) The use of sediment basins shall be mandatory for Category 5 Projects with 5 acres of Disturbed Area or greater
- (c) Sediment basins shall provide sufficient storage to accommodate the volume of runoff for the 2-year, 24-hour storm for the Project Site or at least 3,600 cubic feet per acre area to be drained.
- (d) The embankment slopes must be no steeper than 3 horizontal to 1 vertical. Basin depth must be no less than 3 feet and the length to settling depth ratio must be less than 200, where length is the average distance between the inlet and outlet structure of the basin. Discharges from sediment basins shall pass though outlet Structures that withdraw surface waters from the basin in order to Minimize Pollutant Discharges. Outlet Structures shall be sized to Minimize clogging and achieve a draw-down time between 36 and 72 hours.
- (e) Sediment basins shall use stabilization controls such as Erosion Control blankets to prevent erosion of exterior basin surfaces and use velocity dissipation devices to reduce flow rates at inlets and outlets.
- (f) Sediment basins shall have emergency spillways to accommodate overflow bypass. Emergency spillways may not direct overflow to sloped areas or other areas of concentrated flow. Emergency spillways and outlets require erosion protection such as velocity dissipation devices.
- (g) Sediment basins must be kept in effective operating condition and sediment shall be removed to maintain at least one half of the design capacity of the sediment basin at all times.

- § 20-3-42 <u>Sediment Traps</u>. (a) Sediment traps are excavated or depressed areas that are used to collect and detain sediments from areas of the Site that were cleared or graded during construction.
- (b) The use of Sediment traps shall be mandatory for Category 5 Projects with [less than] 5 acres of Disturbed Area.
  - (c) The drainage area addressed by a single sediment trap shall not exceed 5 acres.
- (d) The traps must be designed to provide storage for calculated volume of runoff for the 2-year, 24-hour storm for the Project Site or at least 3,600 cubic feet per acre to be drained.
  - (e) The embankment slopes shall be no steeper than 3 horizontal to 1 vertical.
- (f) Sediment traps shall have an emergency spillway to accommodate overflow or bypass flows that exceed the design storm event. Emergency spillways and outlets require erosion protection such as velocity dissipation devices.

(g) Sediment traps must be kept in effective operating condition and sediment shall be removed when the sediment accumulation reaches one third of the trap capacity.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-43 <u>Tracking Control</u> (a) All Projects must Minimize sediment track-out onto off-site streets, other paved areas, and sidewalks from vehicles exiting the construction Site by restricting vehicle traffic to properly designated areas and using additional controls to remove sediment from vehicle tires prior to exiting the Site.
- (b) Vehicular parking and movements on Project sites must be confined to paved surfaces or predefined parking areas and vehicle paths, which shall be marked with flags or boundary fencing.
- (c) All Pollutants and materials that are dropped, washed, tracked, spilled, or otherwise Discharged from a Project Site to off-site streets, other paved areas, sidewalks or the MS4 must be cleaned immediately using dry methods such as sweeping or vacuuming. Washing Pollutants and materials that are Discharged from the Project Site to the MS4 into drain inlets or catch basins is prohibited unless the material is sediment and the inlets are directed to a sediment basin or sediment trap.

- §20-3-44 <u>Stabilized Construction Entrance and Exits</u>. (a) Except where vehicular traffic is limited to paved surfaces, all construction entrances and exits for Categories 1C, 3, 4, and 5 shall provide an effective buffer for the deposit of mud and sediment from the Project Site prior to vehicles entering a paved or public road.
- (b) Unpaved construction entrances and exits for Categories 1C, 4 and 5 Projects must consist of 3-6 inch diameter gravel placed upon a geotextile mat. The gravel must have a minimum depth of 12 inches above geotextile mat. The graveled entrance must be at least 50 feet long and 30 feet wide. Entrances and exits must provide a turning radius sufficient to accommodate the construction vehicles entering and exiting the Project Site.
- (c) Unpaved construction entrances and exits for Categories 3 Projects must consist of 3-6 inch diameter gravel placed upon a geotextile mat. The gravel must have a minimum depth of 8 inches above geotextile mat. The graveled entrance must be at least 30 feet long and 20 feet wide. Entrances and exits must provide a turning radius sufficient to accommodate the construction vehicles entering and exiting the Project Site.
- (d) Where Site conditions prevent the removal of all sediment and mud from tires traveling across construction entrances and exits, tire wash facilities must be provided to allow for the removal of mud and sediments from vehicle tires before they are allowed to enter a public road. Tire wash racks and facilities must direct all wash water and sediments away from the construction entrance or exit to a designated settling area located on the Project Site. The Discharge of wash water or sediment from the wash area to the MS4 or State Waters is prohibited.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-45 <u>Dust Control</u>. (a) Dust from a Project Site shall not be transported or Discharged to off-site areas. The work must be in conformance with air pollution control standards contained in the Hawaii Administrative Rules: Title 11 Chapter 60.1, "Air Pollution Control." All ESCPs shall provide for the control of dust by one or more of the following:
  - (1) Mulching to a depth of no less than 1 inch;
  - (2) Sprinkling exposed soils with water to maintain moistness at a depth of 2-3 inches during working hours and not to generate any runoff; and
  - (3) Vertical dust barriers no less than 6 feet in height, constructed of materials capable of effectively preventing the spread of dust particles.

- §20-3-46 <u>Good Housekeeping Practices</u>. All Projects must implement and maintain Good Housekeeping Practices to eliminate and Minimize Pollutant Discharges to the MEP. Mandatory Good Housekeeping Practices include, but are not limited to:
- (a) Street Sweeping and Vacuuming. All Pollutants Discharged from a construction Site to off-site areas must be swept or vacuumed each day before leaving the job site.
- (b) Materials Delivery, Storage and Use Management. Prevent, reduce, or eliminate the Discharge of Pollutants from material delivery, storage, and use to the storm water system or watercourses by minimizing the storage of hazardous materials onsite, storing materials in a designated area, installing secondary containment. Construction materials, waste, toxic and hazardous substances, stockpiles and other sources of pollution shall not be stored in buffer areas, near areas of concentrated flow, or areas abutting the MS4, Receiving Waters, or drainage improvements that Discharge off-site. Primary and secondary containment controls and covers shall be implemented to the MEP.
- (c) Spill Prevention and Control. Projects shall create and implement spill prevention and response plans to eliminate and Minimize the Discharge of Pollutants to the MS4 and Receiving Waters from leaks and spills by reducing the chance for spills, absorbing, containing, and cleaning up spills and properly disposing of spill materials. At a minimum, all Projects shall cleanup all leaks and spills immediately.
- (d) Hazardous Materials. Prevent or reduce the Discharge of Pollutants to storm water from hazardous waste through proper material use and waste disposal. In the event that hazardous materials are Discharged to the MS4, the property owner or ESCP Coordinator shall immediately notify the Department of Facilities Maintenance, Honolulu Fire Department, and Honolulu Police Department of the Discharge by telephone. A written report describing the Pollutants that were Discharged, the reasons for the Discharge, and the measures that have been taken or will be taken to prevent a reoccurrence of the Discharge shall be submitted to the Director no less than 3 days after notification by phone.
- (e) Nonhazardous Materials. In the event that nonhazardous materials are Discharged to the MS4, the property owner or ESCP Coordinator shall notify the City Department of

Facilities Maintenance by telephone no later than the next business day. A written report describing the Pollutants that were Discharged, the reasons for the Discharge, and the measures that have been taken or will be taken to prevent a reoccurrence of the Discharge shall be submitted to the Director no less than 3 days after notification by phone.

- (f) Vehicle and Equipment Cleaning. Eliminate and Minimize the Discharge of Pollutants to storm water from vehicle and equipment cleaning operations by using off-site facilities when feasible, washing in designated, contained areas only, and eliminating Discharges to the storm drain system by evaporating and/or treating wash water, as appropriate or infiltrating wash water for exterior cleaning activities that use water only.
- (g) Vehicle and Equipment Fueling. Prevent fuel spills and leaks by using off-site facilities, fueling only in designated areas, enclosing or covering stored fuel, and implementing spill controls such as secondary containment and active measures using spill response kits.
- (h) Vehicle and Equipment Maintenance. Eliminate and Minimize the Discharge of Pollutants to storm water from vehicle and equipment maintenance operations by using off-site facilities when feasible, performing work in designated areas only, using spill pads under vehicles and equipment, checking for leaks and spills, and containing and cleaning up spills immediately.
- (i) Solid Waste Management. Prevent or reduce Discharge of Pollutants to the land, groundwater, and in storm water from solid waste or construction and demolition waste by providing designated waste collection areas, collect Site trash daily, and ensuring that construction waste is collected, removed, and disposed of only at authorized disposal areas.
- (j) Sanitary/Septic Waste Management. Temporary and portable sanitary and septic waste systems shall be mounted or staked in, well-maintained and scheduled for regular waste disposal and servicing. Sources of sanitary and/or septic waste shall not be stored near the MS4 or Receiving Waters.
- (k) Stockpile Management. Stockpiles shall not be located in drainage ways, within 50 feet from areas of concentrated flows, and are not allowed in the City right-of-way. Sediment barriers or silt fences shall be used around the base of all stockpiles. Stockpiles shall not exceed 15 feet in height. Stockpiles greater than 15 feet in height shall require 8-foot wide benching in accordance with ROH Chapter 14, Article 15. Stockpiles must be covered with Plastic Sheeting or a comparable material if they will not be actively used within 7 days.
- (l) Liquid Waste Management. Liquid waste shall be contained in a controlled area such as a holding pit, sediment basin, roll-off bin, or portable tank of sufficient volume and to contain the liquid wastes generated. Containment areas or devices must be impermeable and leak free and should not be located where accidental release of the contained liquid can Discharge to water bodies, channels, or storm drains.
- (m) Concrete Waste Management. Prevent or reduce the Discharge of Pollutants to storm water from concrete waste by conducting washout offsite or performing onsite washout in a designated area constructed and maintained in sufficient quantity and size to contain all liquid and concrete waste generated by washout operations. Plastic lining material should be a minimum of 10-millimeter polyethylene sheeting and should be free of holes, tears, or other defects that compromise the impermeability of the material. Containment areas or devices should not be located where accidental release of the contained liquid can Discharge to water bodies, channels, or storm drains. Washout facilities must be cleaned, or new facilities must be constructed and ready for use once the washout is 75 percent full. Once concrete wastes are washed into the designated area and allowed to harden, the concrete should be broken up,

removed, and disposed of as solid wastes.

(n) Contaminated Soil Management. At minimum contain contaminated material soil by surrounding with impermeable lined berms or cover exposed contaminated material with Plastic Sheeting. Contaminated soil should be disposed of properly in accordance with all applicable regulations.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

§20-3-47 <u>Dewatering Operations</u>. (a) Dewatering Operations are practices that manage the Discharge of Pollutants when non-storm water and accumulated precipitation must be removed from a work location so that construction work may be accomplished and may include sediment basins, sediment traps, weir tanks, dewatering tanks, filtration systems, or other manufactured systems. Dewatering non-storm water cannot be Discharged from the Site without prior notice to and approval from the DOH.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

# SUBCHAPTER 6 POST-CONSTRUCTION REQUIREMENTS

§20-3-48	Priority Projects
§20-3-49	Post-Construction Storm Water Requirements
§20-3-50	Storm Water Quality Strategic Plans
§20-3-51	Storm Water Quality Reports
§20-3-52	Storm Water Quality Checklists
§20-3-53	Operations and Maintenance Plans
§20-3-54	Post-Construction BMP Certification and Recording

- §20-3-48 <u>Priority Projects</u>. (a) Priority Projects must include or provide permanent structural BMPs to effectively prevent the Discharges of Pollutants to the MS4 and State Waters by implementing Low Impact Development (LID) Site Design Strategies, Source Control BMPs, and Treatment Control BMPs which retain and/or treat storm water on Site. All Projects that meet one or more of the following criteria are Priority Projects:
  - (1) Priority A: All new Development and Redevelopment, including any incremental Development, that proposes Land Disturbing Activities of one acre or more, excluding contractor staging areas and base yards.
  - (2) Priority B1: Any new Development and Redevelopment Project that results in 5,000 square feet or greater of Impervious Surface area that may have significant water quality impacts due to its location or associated land use activities, including but not limited to the Development or Redevelopment of:
    - (i) Retail gas outlets;

- (ii) Automotive repair shops;
- (iii) Restaurants;
- (iv) Parking lots with 20 stalls or more;
- (v) Buildings greater than 100 feet in height;
- (vi) Retail malls; and
- (vii) Facilities used or zoned for industrial use.
- (3) Priority B2: Any new Development and Redevelopment Project that results in between 500 and 5,000 square feet of Impervious Surface area that may have significant water quality impacts due to its location or associated land use activities, including but not limited to the Development or Redevelopment of:
  - (i) Retail gas outlets;
  - (ii) Automotive repair shops;
  - (iii) Restaurants;
  - (iv) Parking lots with 20 stalls or more;
  - (v) Buildings greater than 100 feet in height;
  - (vi) Retail malls; and
  - (vii) Facilities used or zoned for industrial use.
- (b) Where 50 percent or more of the Impervious Surface of a previously developed Site will be altered, the entire Development Site must meet the requirements of these Rules.
- (c) Where less than 50 percent of the Impervious Surface of a previously developed Site will be altered, only the proposed alteration must meet the requirements of these Rules.
- (d) Priority Projects do not include Routine Maintenance and Repair of Impervious Surfaces, trenching and resurfacing work associated with utility installation in Real property or public and private streets, and the construction of temporary or permanent basins and drainage ways.
- (e) A Priority Project is not determined by the cumulative areas of multiple noncontiguous and unrelated work.

- §20-3-49 <u>Post-Construction Storm Water Requirements</u>. (a) The criteria must be met for Priority A, Priority B1, and Priority B2 Projects as follows:
  - (1) Incorporate appropriate LID Site Design Strategies to the MEP.
  - (2) Incorporate appropriate Source Control BMPs to the MEP.
  - (b) The criteria must be met for Priority A and B1 Projects as follows:
    - (1) Retain on-site by Infiltration, Evapotranspiration or Harvest/Reuse, as much of the Water Quality Volume or "WQV" as feasible, with appropriate LID Retention Post-Construction Treatment Control BMPs. The WQV is defined in §20-3-58.
    - (2) Biofilter the remaining portion of the WQV that is not retained on-site with appropriate LID Biofiltration Post-Construction Treatment Control BMPs as much as feasible.
    - (3) If it is demonstrated to be Infeasible to retain and/or biofilter the Water

Quality Volume (WQV) by the criteria in §20-3-63 one of the following alternative compliance measures is required:

- (i) Treat (by detention, filtration, or settling) and Discharge with appropriate Alternative Compliance Post-Construction Treatment Control BMPs, any portion of the Water Quality Volume that is not retained on-site or biofiltered.
- (ii) Retain or biofilter at an offsite location, the volume of runoff from a non-tributary drainage area equivalent to the difference between the Project's WQV and the amount retained on-site or biofiltered. Offsite mitigation Projects must be submitted for City approval.
- (c) Post-Construction Treatment Control BMPs are categorized as Retention BMPs, Biofiltration BMPs, and BMPs for Alternative Compliance according to the following:

<b>Treatment Control</b>	Retention	Biofiltration	Alternative
I Cluster Design			Compliance
Infiltration Basin	•		
Infiltration Trench	•		
Subsurface Infiltration <sup>1</sup>	•		
Dry Well	•		
Bioretention Basin	•		
Permeable Pavement	•		
Harvest / Reuse	•		
Green Roof		•	
Vegetated Bio-Filter <sup>1</sup>		•	
Enhanced Swale		•	
Vegetated Swale		•	
Vegetated Buffer Strip		•	
Detention Basin			•
Manufactured Treatment Device			•
Sand Filter			•

<sup>&</sup>lt;sup>1</sup>Includes both proprietary and non-proprietary systems

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-50 <u>Storm Water Quality Strategic Plans</u>. (a) Priority A Projects must submit a Storm Water Quality Strategic Plan with or as a part of the Master Development Plan for Department review. The Strategic Plan shall include a written description of the proposed Development, expected activities and Pollutants that will be generated by activities at the Site, and LID Site Design Strategies that will be used to comply with these Rules. The Strategic Plan must include a Development schedule.

- §20-3-51 <u>Storm Water Quality Reports</u>. (a) Priority A and Priority B1 Projects must submit a Storm Water Quality Report (SWQR) prepared by a Certified Water Pollution Plan Preparer (CWPPP), which must be reviewed and approved by the Director prior to issuance of a building, grading, grubbing, or stockpiling permit for Development. The CWPPP must be designated by the owner of the property using the form provided as Appendix A to these Rules.
- (b) SWQRs shall be submitted using the report template provided as Appendix E to these Rules. The SWQR must address the requirements in §20-3-49 and must include the following information:
  - (1) Project Name;
  - (2) Master Plan Development Name;
  - (3) Project Address;
  - (4) Project size (acres);
  - (5) Impervious Area (square feet);
  - (6) Tax Map Key;
  - (7) The name, address, and telephone number of the owner(s)/ developers of the property;
  - (8) A description of Site characteristics including drainage patterns, soils, vegetation, and steep or unstable slopes that may be of concern;
  - (9) A description of the future activities at the Site including those that would require Source Control BMPs;
  - (10) A description of the Pollutants of concern (POC) expected to be generated at the Site (see §20-3-55); and
  - (11) A description of the BMPs that will be implemented including Site Design, Self-Mitigating Areas, Self-Retaining Areas, Source Control, Retention, Biofiltration, and Alternative Compliance and which POCs are addressed by those BMPs.
  - (12) The following reports and plans shall be included as attachments:
    - (i) Location Map and Site Plans:
    - (ii) Existing and Proposed Runoff Maps with Drainage Management Areas;
    - (iii) Permanent BMP Plan including locations of all Source Control and Treatment Control BMPs and a clear and definite delineation of areas covered by vegetation or trees that will be saved;
    - (iv) Treatment Control BMP Sizing Calculations or Spreadsheets;
    - (v) Infiltration testing results;
    - (vi) Operation and Maintenance Plan;
    - (vii) Proprietary Treatment Device Washington State Department of Ecology Technology Assessment Protocol (TAPE) Certification or New Jersey Corporation for Advanced Technology (NJCAT) Verification Documentation; and
    - (viii) Evidence or explanation for any feasibility and/or infeasibility criteria claimed in order to comply with the requirements for Infiltration, Harvest/ Reuse, and Biofiltration. Infeasibility criteria must be documented on the form provided as Appendix F to these Rules.
  - (c) SWQRs shall be submitted to the Director for review and approval with the first

set of building, grading, or construction plans for work on the Project or Site.

- (d) The Director shall review SWQRs for conformance with the requirements of these Rules and require any revisions necessary to achieve compliance with these Rules. The Director may condition the approval of an SWQR on the implementation, use, and/or maintenance of BMPs not expressly required by these Rules if additional BMPs are necessary to reduce Pollutant Discharges to the MS4 and/or Receiving Waters to the MEP.
- (e) Changes to an SWQR must be proposed to the Director in writing and approved by the Director before work resumes.
- (f) Each failure to comply with the requirements of an SWQR approved by the Director shall be a separate violation of these rules. In addition, each day continuance of a violation shall be separate offense.

- §20-3-52 <u>Storm Water Quality Checklists.</u> (a) Priority B2 Projects must submit a Storm Water Quality Checklist (SWQC) prepared by a CWPPP, which must be reviewed and approved by the Director prior to issuance of a building, grading, grubbing, or stockpiling permit for Development. The CWPPP must be designated by the owner of the property using the form provided as Appendix A to these Rules.
- (b) SWQCs shall be submitted using the report template provided as Appendix G to these Rules. The SWQC must address the requirements in §20-3-49 and must include the following information:
  - (1) Project Name;
  - (2) Master Plan Development Name;
  - (3) Project Address:
  - (4) Total Project Size (acres or square feet);
  - (5) Impervious Area (square feet);
  - (6) Tax Map Key:
  - (7) The name, address, and telephone number of the owner(s)/ developers of the property;
  - (8) BMPs that will be implemented including Site Design Strategies, Self-Mitigating Areas, and Source Control BMPs;
  - (9) The Permanent BMP Plan including locations of all Site Design Strategies, Source Control BMPs, and vegetated or landscaped areas.
- (c) SWQCs shall be submitted to the Director for review and approval with the first set of building, grading, or construction plans for work on the Project or Site.
- (d) The Director shall review SWQCs for conformance with the requirements of these Rules and require any revisions necessary to achieve compliance with these Rules. The Director may condition the approval of an SWQC on the implementation, use, inspection, documentation, monitoring, and/or maintenance of BMPs not expressly required by these Rules if additional BMPs are necessary to reduce Pollutant Discharges to the MS4 and/or Receiving Waters to the MEP.
- (e) Changes to an SWQC must be proposed to the Director in writing and approved by the Director before work resumes.

(f) Each failure to comply with the requirements of an SWQC approved by the Director shall be a separate violation of these rules. In addition, each day continuance of a violation shall be a separate offense.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-53 Operation and Maintenance Plans. (a) The owner of the property or the designated easement on which a permanent structural BMP is located must submit to the Director for acceptance an Operation and Maintenance Plan for all permanent structural BMPs. The Operation and Maintenance Plan must provide contact information for the individual(s), association, management company, or other responsible entity who shall inspect, document, implement, monitor, and maintain each of the BMPs, excluding those that are designated within limited common areas of individual subdivided lots or condominium property regimes (CPR), in compliance with the Operation and Maintenance Plan. Permanent structural BMPs include Self-Mitigating Areas, Self-Retaining Areas, Source Control BMPs, and Treatment Control BMPs. An Operation and Maintenance Plan is required for Priority A and Priority B1 projects.
  - (b) Operation and Maintenance Plans shall include:
    - (1) Name, phone number and mailing address for the owner of the property;
    - (2) Name and phone number for the individual(s), association, or management company responsible ensuring maintenance is being performed;
    - (3) Maintenance activities for each BMP;
    - (4) Inspection frequencies for each BMP;
    - (5) A Post-Construction BMP plan showing the location of each BMP with a summary of the maintenance activities and inspection schedule for each BMP; and
    - (6) Identification of the source of funds and/or revenue for implementation of the Operations and Maintenance Plan.
- (c) Inspections of post-construction BMPs must be performed regularly and maintenance performed as needed. At a minimum, inspections shall be performed quarterly (4 times per year) and maintenance of all post-construction BMPs performed at least once annually.
- (d) For facilities that will be dedicated to the City, the City reserves the right to alter the maintenance plan to conform to its practices.
- (e) Modifications to the Operations and Maintenance plan after Department acceptance are permitted before closing applicable building and/or grading, grubbing, stockpiling, or trench permits.
- (f) A record of inspection and maintenance activities must be kept on Site, in chronological order, and stored in a three-ring binder or electronically for a minimum of 5 years. The records must be kept on Site or electronically accessible from the Site at all times and shall be made available to the City immediately upon request.
- (g) The Operations and Maintenance Plan must be prepared using the template provided as Appendix H to these Rules.

- §20-3-54 Post-Construction BMP Certification and Recording. (a) Owners shall retain and/or hire a Certified Water Pollution Plan Preparer to observe the installation of Treatment Control BMPs during construction. The Certified Water Pollution Plan Preparer shall inspect the installation of post-construction BMPs at least 2 times prior to final stabilization to confirm that the Treatment Control BMPs and Source Control BMPs have been installed in conformance with the approved construction plans and submit the signed Certificate of Completion form provided as Appendix I to these Rules prior to closing the building and/or grading permits. Inspection Reports shall include photographic evidence, visual observation, maps, and test data, to confirm the installation of all required BMPs.
- (b) Approved Permanent Post-Construction BMP Record Drawings and the accepted Operations and Maintenance Plan for projects on privately owned Real property shall be recorded in the State of Hawaii Land Court or Bureau of Conveyances, as appropriate. Post-Construction BMP Record Drawings and Operation and Maintenance Plans for regional BMPs shall be recorded with the land that contains the BMPs. Designated limited common areas or private areas with post-construction BMPs shall be defined in the recorded deed of each affected subdivided lot or CPR with a description of the permanent structural BMPs and the Operation and Maintenance Plan.
- (c) For all Priority Projects, one copy of the drainage connection permit and Operations and Maintenance Plan shall be submitted to the Department and Director and Chief Engineer of the Department of Facility Maintenance prior to closing the building and/or grading, grubbing, or stockpiling permits.
- (d) Modifications to the BMP Plan or Operations and Maintenance Plan after permit closure or after the drainage connection permit has been issued must be approved with the Department of Facility Maintenance. Any modifications to BMP plans or Operations and Maintenance Plans shall not reduce the level of protection from Pollutant Discharges afforded to State Waters or the MS4 when compared to the accepted plans prior to permit closure.
- (e) Facilities with Post-Construction BMPs are subject to annual inspection by an Inspector from the Department of Facility Maintenance and must provide access to the facility for the annual inspections. Failure to comply with this requirement shall be a separate violation of these Rules. In addition, each day the violation continues shall be a separate offense.
- (f) Each failure to comply with the requirements of an Operations and Maintenance Plan approved by the Director and on file at the Department of Facility Maintenance shall be a separate violation of these rules. In addition, each day the violation continues shall be a separate offense.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

# SUBCHAPTER 7 BMPS, STANDARDS, AND SPECIFICATIONS FOR PERMANENT POSTCONSTRUCTION BMPS AND LOW IMPACT DEVELOPMENT

§20-3-55	<b>BMP Selection</b>
§20-3-56	Site Design Strategies
820-3-57	Source Control BMPs

§20-3-58	Treatment Control BMPs Numeric Sizing Criteria
§20-3-59	Infiltration Testing
§20-3-60	Retention BMPs
§20-3-61	Biofiltration BMPs
§20-3-62	Alternative Compliance BMPs
§20-3-63	Feasibility Criteria

§20-3-55 <u>BMP Selection</u>. (a) Post-construction BMPs shall be chosen to address identified POCs for each Project Site and/or the Receiving Water for that Site.

Note: The following table summarizes the pollutants typically associated with the priority project

land uses and more than one category may apply to a project.

Priority Project Categories	Nutrients	Sediment	Trash	Pathogens	Pesticides	Oil & Grease	Metals	Organic Compounds
Priority A: Residential Development > one acre	X	X	X	X	X	X		
Priority A: Commercial Development >one acre	$\mathbf{P}^{(1)}$	$\mathbf{P}^{(1)}$	X	P <sup>(3)</sup>	P <sup>(5)</sup>	X	X	P <sup>(2)</sup>
Priority B: Facilities used or zoned for industrial use		X	X			X	X	X
Priority B: Automotive Repair Shops			X			X	X	$X^{(4)(5)}$
Priority B: Restaurants			X	X	$\mathbf{P}^{(1)}$	X		
Priority B: Parking Lots	$\mathbf{P}^{(1)}$	$\mathbf{P}^{(1)}$	X		$\mathbf{P}^{(1)}$	X	X	X
Priority B: Retail Gas Outlets			X			X	X	X
Priority B: Buildings greater than 100 feet in height	X	X	X	X	X	X		
Priority B: Retail malls	P <sup>(1)</sup>	$P^{(1)}$	X	P <sup>(3)</sup>	P <sup>(5)</sup>	X	X	P <sup>(2)</sup>
(All) Streets, Highways & Freeways	P <sup>(1)</sup>	X	X	X	P <sup>(1)</sup>	X	X	$X^{(4)}$

#### X = anticipated P = potential

- (1) A potential Pollutant if landscaping exists onsite.
- (2) A potential Pollutant if the Project includes uncovered parking areas.
- (3) A potential Pollutant if land use involves food or animal waste products.
- (4) Including petroleum hydrocarbons.
- (5) Including solvents

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

§20-3-56 <u>Site Design Strategies</u>. (a) All Priority A and Priority B Projects shall implement Site Design Strategies. Site Design strategies are LID design techniques that are intended to maintain or restore the Site's hydrologic and hydraulic functions with the intent of minimizing runoff volume and preserving existing flow paths. Site Design Strategies reduce the

amount of storm water runoff that requires treatment, resulting in smaller Treatment Control BMP size. They include:

- (1) Conserve natural areas, soils, and vegetation.
- (2) Minimize disturbances to natural drainages.
- (3) Minimize soil compaction.
- (4) Minimize Impervious Surfaces.
- (5) Direct Runoff to Landscaped Areas and Reduce directly connected impervious areas (DCIA).
- (b) Site Design Strategies may be used to exclude drainage management areas on the Site from requiring additional Treatment Control BMPs if they are Self-Mitigating or Self-Retaining.
  - (1) Self-Mitigating Areas consist of natural or landscaped area, including green roofs, which retain and/or treat rainfall over the footprint of the Self-Mitigating Area but do not accept runoff from other areas. Self-Mitigating Areas may drain directly to the MS4 or other off-site drainage without further treatment and can be excluded in calculation of the WQV or WQF. They must meet all the following criteria to be eligible for exclusion:
    - (i) Vegetation in the natural or landscaped area is native and/or nonnative/non-invasive drought tolerant species that do not require regular application of fertilizers and pesticides.
    - (ii) Soils are undisturbed native topsoil, or disturbed soils that have been amended and aerated to promote water retention characteristics equivalent to undisturbed native topsoil.
    - (iii) The incidental impervious areas are less than 5 percent of the Self-Mitigating Area.
    - (iv) Impervious area within the Self-Mitigating Area should not be hydraulically connected to other impervious areas unless it is a storm water conveyance system (such as brow ditches).
    - (v) The Self-Mitigating Area is hydraulically separate from other drainage areas that contain permanent storm water Pollutant control BMPs.
  - (2) Self-Retaining Areas are areas of a development site that are designed to retain the first 1 inch of rainfall (by ponding and infiltration and/ or evapotranspiration) on itself and from adjacent areas without producing storm water runoff. Self-Retaining Areas may be created by designing concaved landscaped areas at a lower elevation or which are bermed or ditched to accept runoff from adjacent impervious areas. They must meet all the following criteria to be eligible for exclusion:
    - (i) A maximum of 1:1 ratio of impervious area to the receiving pervious area is acceptable. The maximum impervious to pervious area ratio may be increased to 1.5:1 if the soils in the pervious receiving area have been amended by incorporating at least 8 inches of compost/amendments and tilled/aerated to promote water infiltration and retention.
    - (ii) The functional area of the Self-Retaining Area must be flat (less than 5%), designed for sheet flow, and with a minimum of 10 feet from

- inflow to overflow route. Berms or other design features may be required to distribute flow throughout the Self-Retaining Area.
- (iii) Side slopes and flow paths shall be protected from erosion by minimizing concentrated flows into the Self-Retaining Area using appropriate velocity dissipation methods (e.g. riprap or level spreaders).
- (iv) Vegetation should be native and/or non-native/non-invasive drought tolerant species that can tolerate periodic ponding and do not require regular application of fertilizers and pesticides.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-57 <u>Source Control BMPs.</u> (a) Source Control BMPs are required for all Priority A and B Projects for the following activities and areas: Landscaped areas, Automatic irrigation systems, Storm drain Inlets, Vehicle/equipment fueling, Vehicle/equipment repair, Vehicle/equipment washing/cleaning, Loading docks, Outdoor trash storage, Outdoor material storage, Outdoor work areas, Outdoor process equipment operations, and Parking areas. They shall be implemented to the MEP.

- (b) Landscaped areas.
  - (1) Limit runoff from landscaped areas to impervious areas
  - (2) Protect slopes and channels
- (c) Automatic Irrigation.
  - (1) Design irrigation systems to each landscape area's specific water requirements.
  - (2) Implement landscape plans consistent with City water conservation resolutions, which may include provision of drip irrigation, water sensors, or programmable irrigation times (for short cycles)
  - (3) Design timing and application methods of irrigation water to Minimize the runoff of excess irrigation water into the storm water drainage system.
  - (4) Group plants with similar water requirements in order to reduce excess irrigation runoff and promote surface filtration.
- (d) Storm Drain Inlets.
  - (1) Provide stenciling or labeling of all storm drain inlets and catch basins, constructed or modified, within the Project area with prohibitive language.
  - (2) Place the marker in clear sight facing toward anyone approaching the inlet from either side
  - (3) Signage must not be placed on the face of curbs to avoid contact with vehicle tires and sweeper brooms.
  - (4) Post signs with prohibitive language and/or graphical icons, which prohibit illegal dumping at public access points along channels and streams within the Project area.
- (e) Vehicle and Equipment fueling areas.
  - (1) Covering. Include an overhanging roof structure or canopy over fuel dispensing areas. The cover's minimum dimensions must be equal to or

- greater than the area within the grade break. The cover must not drain onto the fuel dispensing area and the downspouts must be routed to prevent drainage across the fueling area. If fueling large equipment or vehicles that prohibit the use of covers or roofs, the fueling island should be designed to accommodate the larger vehicles and equipment and to prevent storm water run-on and runoff.
- (2) Surfacing. Pave fuel dispensing areas with Portland cement concrete (or equivalent smooth Impervious Surface). Extend the paved area a minimum of 6.5 feet from the corner of each fuel dispenser, or the length at which the hose and nozzle assembly may be operated plus 1 foot, whichever is less. The use of asphalt concrete is prohibited. Use asphalt sealant to protect asphalt paved areas surrounding the fueling area.
- Grading/Contouring. Slope the dispensing areas to prevent ponding, and separate it from the rest of the Site by a grade break that prevents run-on. Grade the fueling areas to drain toward a dead-end sump or vegetated/landscaped area. Direct runoff from downspouts/roofs away from fueling areas towards vegetated/landscaped areas if possible.
- (4) Drains. Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/water separator.
- (f) Vehicle and Equipment Repair.
  - (1) Locate repair/ maintenance bays indoors; or design them to preclude runon and runoff.
  - (2) Pave repair /maintenance floor areas with Portland cement concrete (or equivalent smooth Impervious Surface).
  - (3) Provide impermeable berms, drop inlets, trench drain, catch basins, or overflow containment Structures around repair bays to prevent spilled materials and wash-down waters from entering the storm drain system. Connect drains to a sump for collection and disposal. Direct connection of the repair/ maintenance bays to the storm drain system is prohibited.
  - (4) Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/ water separator.
- (g) Vehicle and Equipment Washing and Cleaning. At least one of the following features for vehicle and equipment washing must be incorporated into the Project design:
  - (1) Be self-contained and/or covered with a roof or overhang; or
  - (2) Be equipped with a clarifier or other pretreatment facility; or
  - (3) Have a proper connection to a sanitary sewer; or
  - (4) Install sumps or drain lines to collect wash water. Divert wash water to the sanitary sewer, an engineered Infiltration system, or an equally effective alternative: or
  - (5) Direct and divert surface water runoff away from the exposed area around the wash pad, and wash pad itself to alternatives other than the sanitary sewer; or
  - (6) Cover areas used for regular washing of vehicles, trucks, or equipment, surround them with a perimeter berm, and clearly mark them as a

- designated washing area
- (7) Label all drains within facility boundaries using paint or stencil, to indicate whether flow is to the storm drain, sewer, or oil/water separator.
- (8) Approval for a sanitary connection must be obtained from the City Department of Environmental Services and may require an industrial wastewater Discharge permit.
- (h) Residential Vehicle and Equipment Washing for Condominiums and Apartment Buildings.
  - (1) Designate a car wash area and post signs for area.
  - (2) Divert wash water to a vegetated area where it may percolate into the ground, the sanitary sewer, an engineered Infiltration system, or an equally effective alternative.
  - (3) Direct and divert surface water runoff away from the wash area to alternatives other than the sanitary sewer.
  - (4) Approval for a sanitary connection must be obtained from the City Department of Environmental Services.
    - (d) Loading Docks.
  - (1) Cover all loading dock areas, or design them to preclude run-on and runoff.
  - (2) Do not allow runoff from depressed loading docks (truck wells) to Discharge into storm drains.
  - (3) Drain below-grade loading docks from grocery stores and warehouse/distribution centers of fresh food items through water quality inlets, an engineered Infiltration system, or an equally effective alternative.
  - (4) Grade and/or berm the loading/unloading area to a drain that is connected to a dead-end.
  - (5) Pave loading areas with Portland cement concrete.
- (j) Outdoor Trash Storage.
  - (1) Hazardous waste must be handled in accordance with legal requirements established in Hawaii Administrative Rules Title 11 Chapter 58.1 Solid Waste Management Control, and enforcement by the State of Hawaii Department of Health solid and Hazardous Waste Branch.
  - (2) Berm trash storage areas to prevent run-on from adjoining roofs and pavement, or grade areas towards vegetated/landscaped areas.
  - (3) Reduce/prevent leaking of liquid waste by incorporating at least one of the following: Lined bins or dumpsters, Low containment berm around the dumpster area, or Drip pans underneath dumpsters
  - (4) Prevent rainfall from entering containers with roofs, awnings, or attached lids.
  - (5) Pave trash storage areas with an Impervious Surface to mitigate spills.
  - (6) Do not locate storm drains in immediate vicinity of the trash storage area.
  - (7) Post signs on dumpsters indicating that hazardous material are not to be disposed of therein.
- (k) Outdoor Material Storage may be in the form of raw products, by-products, finished products, and waste products.

- (1) Materials with the potential to contaminate storm water must either be placed in an enclosure that prevents contact with runoff or spillage to the storm water conveyance system, or protected by secondary containment Structures such as berms, dikes, or curbs.
- (2) Pave the storage area with Portland cement concrete (or equivalent smooth Impervious Surface) to contain leaks and spills.
- (3) Slope the storage area towards a dead-end sump to contain spills.
- (4) Direct runoff from downspouts/roofs away from storage areas.
- (5) Cover the storage area with an awning that extends beyond the storage area to Minimize collection of storm water within the secondary containment area. A manufactured storage shed may be used for small containers.
- (l) Outdoor Work Areas may include but are not limited to areas where grinding, painting, coating, sanding, and parts cleaning are performed.
  - (1) Use an impermeable surface such as concrete or asphalt, or a prefabricated metal drip pan, appropriate for the work area.
  - (2) Cover the area with a roof to prevent rain from falling on the work area and becoming polluted runoff.
  - (3) Berm or perform mounding around the perimeter of the area to prevent water from adjacent areas from flowing on to the surface of the work area.
  - (4) Directly connect runoff to the sanitary sewer or other specialized containment system(s). This allows the more highly concentrated Pollutants from these areas to receive special treatment that removes particular constituents. Approval for a sanitary connection must be obtained from the City Department of Environmental Services and may require an industrial wastewater Discharge permit.
  - (5) Locate the work area away from storm drains or catch basins.
- (m) Outdoor Process Equipment Operations may include but are not limited to rock grinding or crushing, painting or coating, grinding or sanding, and degreasing or parts cleaning.
  - (1) Cover or enclose areas that would be the most significant source of Pollutants; or slope the area toward a dead-end sump; or, Discharge to the sanitary sewer system following appropriate treatment in accordance with conditions established by the City Department of Environmental Services.
  - (2) Grade or berm area to prevent run-on from surrounding areas.
  - (3) Do not install storm drains in areas of equipment repair.
  - (4) Provide secondary containment Structures (not double wall containers) where wet material processing occurs (e.g., electroplating), to hold spills resulting from accidents, leaking tanks, or equipment, or any other unplanned releases (Note: if these are plumbed to the sanitary sewer, they must be with the prior approval of the City.)
- (n) Parking Areas that are paved with impermeable material must be graded to direct runoff towards vegetated/landscaped areas or other Post-Construction Treatment Control BMPs.

- §20-3-58 <u>Treatment Control BMPs numeric sizing criteria</u>. (a) Treatment Control BMPs include retention (Infiltration and Harvest/ Reuse) BMPs, Biofiltration BMPs, and manufactured treatment devices and are sized either based on volume, flow, or demand, depending on the BMP.
- (b) Treatment Control BMPs shall be designed off-line from the drainage system, unless a bypass system is provided for the design storm.
- (c) Drainage management areas should be defined based on proposed drainage patterns of the Site and BMPs to which they drain. More than one drainage management area can drain to a single BMP but a single drainage management area cannot drain to more than one BMP unless those BMPs are in series and not parallel. Drainage management area calculations for Treatment Control should not include Self-Mitigating Areas and Self-Retaining Areas.
- (d) De Minimis Areas are very small drainage areas that are not significant contributors of Pollutants. Examples include portions of sidewalks, driveways, and retaining walls at the external boundary of a Project. De Minimis Areas can be excluded from Treatment Control requirements and WQV or WQF calculations if they meet all of the following characteristics:
  - (1) Areas abut the perimeter of the Development Site.
  - (2) Topography or land ownership constraints make BMP construction Infeasible.
  - (3) The sum of all De Minimis areas should represent less than 5 percent of the total Project size.
- (e) Volume based BMPs numeric sizing criteria. Volume based storm water quality facilities include LID retention BMPs: Infiltration Basins, Infiltration Trenches, Subsurface Infiltration Systems, Dry Wells, Bioretention Basins, Permeable Pavement; Biofiltration BMPs: Green Roofs, Vegetated Bio-Filters, Enhanced Swales; and Alternative Compliance BMPs: Detention Basins, and Sand Filters.
  - (1) Volume based BMPs shall be sized for the Water Quality Volume (WQV), which is calculated as follows:

#### $WQV = PCA \times 3630$

Where: WQV = water quality volume (cubic feet)
P = design storm runoff depth (inches)
C = volumetric runoff coefficient
A = drainage management area(s) (acres)

- (2) A design storm runoff depth of 1 inch shall be used for LID retention BMPs. A design storm runoff depth of 1.5 inches shall be used for volume-based Biofiltration and Alternative Compliance BMPs.
- (3) The volumetric runoff coefficient shall be calculated using the following equation as developed by EPA for smaller storms in urban areas:

C = 0.05 + 0.0091

Where: C = volumetric runoff coefficient

I = percent of impervious cover, expressed as a percentage

- (f) Flow-through based BMPs Numeric Sizing Criteria. Flow-through based BMPs include Vegetated Swales, Vegetated Filter Strips, and Alternative Compliance Manufactured Treatment Devices.
  - (1) Flow-through based BMPs shall be sized for the Water Quality Flow Rate

(WQF), which is calculated using the Rational Formula as follows:

## WQF = 1.5 X CiA

Where: WQF = water quality flow rate (cubic feet per second)

C = runoff coefficient

i = peak rainfall intensity (inches per hour)
A = drainage management area(s) (acres)

(2) A peak rainfall intensity of 0.4 inches per hour shall be used.

(3) The runoff coefficient shall be determined from the table below.

(4) For drainage areas containing multiple land uses the following formula may be used to compute a composite weighted runoff coefficient:

$$C_c = \left(\sum_{t=1}^n C_t A_t\right) / A_t$$

Where:  $C_c =$  composite weighted runoff coefficient

 $C_{1,2,...n}$  = runoff coefficient for each land use cover type  $A_{1,2,...n}$  = drainage area of each land use cover type (acres)

 $A_t$  = total drainage area (acres)

(5) The calculated WQF for Vegetated Swales and Vegetated Filter Strips may be reduced by 25 percent if the soil beneath the BMP is classified as Hydrologic Soils Group (HSG) "A" or "B", as reported by the United States Department of Agriculture (USDA) Natural Resources Conservation Service, or if the soil beneath the BMP is amended by incorporating 6 inches of compost/amendments and tilled up to 8 inches.

Note: the following table provides runoff coefficients to be used for Flow-through based BMP calculations

Type of Surface	Runoff Coefficient
Roofs	0.90
Concrete	0.80
Stone, brick, or concrete pavers with mortared joints and bedding	0.80
Asphalt	0.70
Stone, brick, or concrete pavers with sand joints and bedding	0.70
Pervious Concrete	0.10
Porous asphalt	0.10
Permeable interlocking concrete pavement	0.10
Grid pavements with grass or aggregate surface	0.10
Crushed aggregate	0.10
Grass	0.10

Grass over Porous Plastic	0.05
Gravel over Porous Plastic	0.05

Note: These runoff coefficients are only appropriate for small storm treatment design and should not be used for flood control sizing.

- (g) The sizing procedures for BMP size based on the WQV and WQF are based on simple dynamic and static principles and therefore may result in larger BMPs than are necessary. More rigorous sizing methods, such as detailed routing methods or continuous simulation models, may be used with Director approval. Any other sizing method for retention BMPs must retain the first 1 inch of rainfall. Any treat and release BMP must use a design storm depth of 1.5 inches.(h) Demand based BMP Numeric Sizing Criteria. Demand based BMPs include Harvest /Reuse. One of two equivalent performance standards shall be met:
  - (1) Harvest and Reuse BMPs must be designed to capture at least 80 percent of average annual (long term) runoff volume AND meet 80 percent of the annual overall demand. If these criteria are met then no further BMPs are required to retain the WQV for the contributing drainage management area(s).
  - (2) Harvest and Reuse BMPs must be sized to meet ] the 48-hour demand at the Site at a minimum. It is rare that cisterns can be sized to capture the full WQV and use this volume in 48 hours, therefore the BMP should be sized to meet the estimated 48-hour demand and the remaining WQV not captured is required to be retained onsite through Infiltration/evapotranspiration or, if Infeasible, treated with Biofiltration or Alternative Compliance as required in §20-3-49.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-59 <u>Infiltration Testing</u>. (a) The Infiltration rate, or permeability, measured in inches per hour, is the rate at which water passes through the soil profile during saturated conditions. Soil investigations and Infiltration tests are required to accurately determine the local soil characteristics and capacity for Infiltration. For Infiltration basins, subsurface Infiltration systems, dry wells, bioretention basins, and permeable pavement, at a minimum, one permeability test must be performed for every 2,500 square feet. For Infiltration trenches, at a minimum, one permeability test must be performed for every 100 linear feet.
- (b) Design Infiltration Rates. To account for uncertainties and inaccuracies in testing, a correction (i.e., safety) factor shall be applied to the assumed or measured Infiltration rate to produce a design Infiltration rate for BMP sizing calculations. The minimum safety factor shall be 2 for Infiltration facilities.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

§20-3-60 <u>Retention BMPs</u>. Retention BMPs include Infiltration BMPs and Harvest/

Reuse.

- (a) Infiltration Basin. An Infiltration basin is a shallow impoundment with no outlet, where storm water runoff is stored and infiltrates through the basin invert and into the soil matrix.
  - (1) Infiltration Basins shall have a flat invert, interior side slopes (length per unit height) no steeper than 3 horizontal to 1 vertical unless approved by a licensed Engineer with geotechnical expertise, and at least 3 feet from the basin invert to the seasonally high groundwater table. For side slopes greater than 3 horizontal to 1 vertical, permanent Erosion Control using Geotextiles or Rolled Erosion Control Products and grassing is required.
  - (2) The soil Infiltration rate below the basin invert shall be at least 0.5 inches per hour, and drain completely in 48 hours.
- (b) Infiltration Trench. An Infiltration trench is a rock-filled trench with no outlet, where storm water runoff is stored in the void space between the rocks and infiltrates through the bottom and into the soil matrix.
  - (1) Infiltration Trenches shall have no more than 6 inches of a top backfill layer, no more than 12 inches of a bottom sand layer, and 1.5-3.0 inch diameter trench rock.
  - (2) The soil Infiltration rate below the trench invert shall be at least 0.5 inches per hour, the depth from the trench invert to the seasonally high groundwater table shall be at least 3 feet, and the trench shall completely drain in 48 hours.
  - (3) The depth of the Infiltration trench shall not exceed the greater of the trench width and trench length to avoid classification as an Underground Injection Control (UIC) Class V injection well.
- (c) Subsurface Infiltration System. A subsurface Infiltration system is a rock (or alternative pre-manufactured material) storage bed below other surfaces such as parking lots, lawns and playfields for temporary storage and Infiltration of runoff.
  - (1) In addition to applicable manufacturer's guidelines, the soil Infiltration rate below the system invert shall be at least 0.5 inches per hour, the depth from the system invert to the seasonally high groundwater table shall be at least 3 feet, and the system shall completely drain in 48 hours.
  - (2) The depth of the subsurface Infiltration system storage bed shall not exceed the greater of the storage bed's width and storage bed's length to avoid classification as a UIC Class V injection well.
- (d) Dry Well. A dry well is a subsurface aggregate-filled or prefabricated perforated storage facility, where roof runoff is stored and infiltrates into the soil matrix.
  - (1) The soil Infiltration rate below the dry well invert shall be at least 0.5 inches per hour, the depth from the dry well invert to the seasonally high groundwater table shall be at least 3 feet, and the dry well shall completely drain in 48 hours.
  - (2) If the dry well is aggregate-filled, 1.0-3.0 inch aggregate shall be used unless an alternative is approved by a licensed Engineer with geotechnical expertise.
  - (3) The depth of the dry well shall not exceed the diameter to avoid classification as an UIC Class V injection well.

- (e) Bioretention Basin. Sometimes referred to as a Rain Garden, a Bioretention Basin is an engineered shallow depression that collects and filters storm water runoff using conditioned planting soil beds and vegetation. The filtered runoff infiltrates through the basin invert and into the soil matrix.
  - (1) Bioretention Basins shall have a flat invert, interior side slopes (length per unit height) no steeper than 1:1 for single family residential installations and no steeper than 3 horizontal to 1 vertical for all other installations unless approved by a licensed Engineer with geotechnical expertise, and at least 3 feet from the basin invert to the seasonally high groundwater table. For side slopes greater than 3 horizontal to 1 vertical, permanent Erosion Control using geotextiles or erosion mats and grassing is required.
  - (2) The ponding depth shall be no greater than 12 inches, the mulch thickness shall be 2-4 inches, and the planting soil depth shall be 2-4 feet.
  - (3) The soil Infiltration rate below the basin invert shall be at least 0.5 inches per hour, and the basin shall drain completely in 48 hours.
- (f) Permeable Pavement. Sometimes referred to as pervious pavement or porous pavement, permeable pavement refers to any porous, load-bearing surface that allows for temporary rainwater storage in an underlying aggregate layer until it infiltrates into the soil matrix. It includes pervious concrete, porous asphalt, interlocking paver blocks, and reinforced turf grassing and gravel filled grids.
  - (1) Permeable pavement shall have a reservoir layer no thicker than 3 feet and have at least 3 feet from the reservoir invert to the seasonally high groundwater table.
  - (2) The soil beneath the reservoir layer invert shall have an Infiltration rate of at least 0.5 inches per hour, and the reservoir layer shall drain completely in 48 hours.
- (g) Harvest/Reuse. Sometimes referred to as Capture/Reuse or Rainwater Harvesting, Harvest/Reuse is the collection and temporary storage of roof runoff in rain barrels or cisterns for subsequent non-potable use (landscape irrigation, vehicle washing and other uses as allowed by the Building Code).
  - (1) Harvest/ Reuse facilities must be sized according to the sizing criteria in §20-3-58 or other methods appropriate to compute the storage volume.
  - (2) Harvest/ Reuse facilities must not conflict with any applicable building codes.

[Eff December 24, 2018] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

#### §20-3-61 <u>Biofiltration BMPs.</u>

- (a) Green Roof. Sometimes referred to as a Vegetated Roof or Eco-roof, a green roof is a roof that is entirely or partially covered with vegetation and soils for the purpose of filtering, absorbing, evapotranspirating, and retaining/ detaining the rain that falls upon it.
  - (1) Green roofs shall have a slope no greater than 20 percent, at least 2 inches of soil media, and at least 2 inches of drainage layer.
  - (b) Vegetated Bio-Filter. This category of BMPs may be referred to as a Bioretention

Filter, Stormwater Curb Extension, Tree box filter, or Planter Box. A Vegetated Bio-Filter is an engineered or proprietary system that collects and filters storm water runoff using conditioned planting soil beds and vegetation. The filtered runoff Discharges through an underdrain system.

- (1) Engineered vegetated Bio-Filters shall have a relatively flat invert, the ponding depth shall be no greater than 12 inches, the mulch thickness shall be 2-4 inches, and the planting soil depth shall be 2-4 feet.
- (2) Engineered vegetated Bio-Filters planting soil shall have a coefficient of permeability equal to at least 1.0 foot per day, and the WQV shall drain completely in 48 hours.
- (3) Non-vegetated filter media may be used in lieu of planting soil.
- (4) For proprietary systems, the BMP must be certified for general use by the Washington State Department of Ecology Technology Assessment Protocol (TAPE) for Enhanced Treatment (for the treatment of dissolved metals), Phosphorous Treatment, or Oil Treatment, according to the predominant Pollutant(s) of concern at that Site.
- (c) Dry Swale. Sometimes referred to as a Bioretention Swale or Enhanced Swale, a Dry Swale is a shallow linear channel with a planting bed and covered with turf or other surface material (other than mulch or plants). Runoff filters through a planting bed, is collected in an underdrain system, and Discharged at the downstream end of the swale.
  - (1) Enhanced Swales shall have interior side slopes (length per unit height) no steeper than 3 horizontal to 1 vertical unless approved by a licensed Engineer with geotechnical expertise, a bottom width between 2-8 feet, and a longitudinal slope no greater than 2 percent without check dams or 5 percent with check dams. For side slopes greater than 3 horizontal to 1 vertical, permanent Erosion Control using geotextiles or erosion mats and grassing is required.
  - (2) If used, check dams shall be no higher than 12 inches. The maximum ponding depth is 18 inches and the minimum media depth is 18 inches.
- (d) Vegetated Swale. Sometimes referred to as a Grass Swale, Grass Channel, or Biofiltration Swale, a vegetated swale is a broad shallow earthen channel vegetated with erosion resistant and flood tolerant grasses. Runoff typically enters the swale at one end and exits at the other end.
  - (1) Vegetated Swales shall have interior side slopes (length per unit height) no steeper than 3 horizontal to 1 vertical unless approved by a licensed Engineer with geotechnical expertise, a bottom width no greater than 10 feet, and a water depth no greater than 4 inches.
  - (2) The velocity in the swale shall not exceed 1 foot per second, and the hydraulic residence time shall be at least 7 minutes.
- (e) Vegetated Buffer Strip. Sometimes referred to as a Vegetated Filter Strip or Biofiltration Strip, a vegetated buffer strip is a grassy slope vegetated with turf grass that is designed to accommodate sheet flow. They may remove Pollutants by vegetative filtration.
  - (1) Vegetated Buffer Strips shall have a length (in the direction of flow) no less than 15 feet, the depth of flow shall not exceed 1 inch, and the velocity shall not exceed 1 foot per second. The length of the filter strip in the direction of flow may be noncontiguous so long as the minimum length is met for the tributary area.

(2) The flow length of the tributary area discharging perpendicularly onto the strip shall not exceed 75 feet.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

## §20-3-62 <u>Alternative Compliance BMPs.</u>

- (a) Manufactured Treatment Device. A manufactured treatment device is a proprietary water quality structure utilizing settling, filtration, adsorptive/absorptive materials, or other appropriate technology to remove Pollutants from storm water runoff.
  - (1) The device must provide, at minimum, a total suspended solids (TSS) removal rate of 80 percent, certified for general use by the Washington State Department of Ecology Technology Assessment Protocol (TAPE) or verified by the New Jersey Corporation for Advanced Technology (NJCAT) consistent with the New Jersey Department of Environmental Protection (NJDEP) protocols.
  - (2) Systems not meeting the required TSS removal criteria are allowed as pretreatment for other BMPs
- (b) Detention Basin. Sometimes referred to as a Dry Extended Detention Basin, a detention basin is a shallow man-made impoundment intended to provide for the temporary storage of storm water runoff to allow particles to settle. It does not have a permanent pool and is designed to drain between storm events.
  - (1) Detention Basins shall have an invert sloped between 1 to 2 percent, interior side slopes (length per unit height) no steeper than 3 horizontal to 1 vertical unless approved by a licensed Engineer with geotechnical expertise, a minimum length to width ratio of 2 to 1, and a maximum depth of 8 feet.
  - (2) With outlets no smaller than 4 inches in diameter, the basin shall drain completely in 48 hours when full and 24-36 hours when half full.
- (c) Sand Filter. A sand filter is an open chambered structure that captures, temporarily stores, and treats storm water runoff by passing it through an engineered media (e.g., sand).
  - (1) Sand filter beds shall have at least 18 inches of sand with a coefficient of permeability of at least 3.5 feet per day, and shall drain completely in 48 hours.

- §20-3-63 <u>Feasibility Criteria</u>. For compliance with §20-3-49 of these Rules, the following feasibility criteria are established.
- (a) Infiltration Feasibility. Infiltration BMPs are Infeasible and must not be used if any of the following conditions are met:
  - (1) Soils beneath the BMP invert have measured Infiltration rates of less than

- 0.5 in/ hr or are USDA HSG "C" or "D" as reported by the USDA Natural Resources Conservation Service;
- (2) The seasonally high groundwater table is within 3 feet from the BMP invert;
- (3) There is a documented concern that there is a potential onsite for soil Pollutants, ground water Pollutants, or Pollutants associated with industrial activities to be mobilized;
- (4) There are geotechnical concerns at the Site;
- (5) Excavation for the installation of the BMP would disturb iwi kupuna or other archeological resources;
- (6) The BMP cannot be built within the following setbacks:
  - (i) 50 feet from the nearest drinking water well;
  - (ii) 35 feet from the nearest septic system;
  - (iii) 10 feet from the nearest private property line;
  - (iv) 20 feet from the nearest building foundation at the Project Site;
  - (v) 100 feet from the nearest down-gradient building foundation; or
- (7) Infiltration facilities would conflict with the location of existing or proposed underground utilities or easements, or would result in their placement on top of underground utilities, or otherwise oriented to underground utilities, such that they would Discharge to the utility trench, restrict access, or cause stability concerns.
- (b) Harvest/Reuse feasibility. Harvest/Reuse is considered Infeasible for the any of the flowing reasons:
  - (1) The demand is inadequate to reuse the required volume of water;
  - (2) The technical requirements cause the harvesting system to exceed 2 percent of the total Project cost;
  - (3) The Site where a cistern must be located is at a slope greater than 10 percent;
  - (4) There is no available space to locate a cistern of adequate size to harvest and use the required amount of water;
  - (5) The cistern cannot be built within the following setbacks:
    - (i) 10 feet from the nearest septic system;
    - (ii) 5 feet from the nearest private property line;
    - (iii) 5 feet from the nearest building foundation at the Project Site; or
  - (6) The Project includes a reclaimed water system and demand for a harvest/reuse system cannot be met.
  - (c) Biofiltration feasibility.
    - (1) Vegetated Biofilters are Infeasible for any of the following reasons:
      - (i) Excavation would disturb iwi kupuna or other archaeological resources:
      - (ii) The invert of underdrain layer is below seasonally high groundwater table;
      - (iii) The Site does not receive enough sunlight to support vegetation;
      - (iv) The Site lacks sufficient hydraulic head to support BMP operation by gravity; or
      - (v) Unable to operate off-line with bypass and unable to operate in-

line with safe overflow mechanism;

- (2) Green Roofs are Infeasible for any of the following reasons:
  - (i) The roof is for a single family residential dwelling;
  - (ii) Roof space is unavailable due to renewable energy, electrical, and/or mechanical systems; or
  - (iii) Slope on roof exceeds 25 percent (14 degrees);
- (3) Dry Swales are Infeasible for any of the following reasons:
  - (i) Excavation would disturb iwi kupuna or other archaeological resources:
  - (ii) The invert of underdrain layer is below seasonally high groundwater table;
  - (iii) The Site lacks sufficient hydraulic head to support BMP operation by gravity; or
  - (iv) Unable to operate off-line with bypass and unable to operate inline with safe overflow mechanism.
- (4) Vegetated Swales are Infeasible for any of the following reasons:
  - (i) The excavation would disturb iwi kupuna or other archaeological resources:
  - (ii) The Site does not receive enough sunlight to support vegetation; or
  - (iii) Unable to operate off-line with bypass and unable to operate inline with safe overflow mechanism.
- (5) Vegetated filter strips are Infeasible for any of the following reasons:
  - (i) Excavation would disturb iwi kupuna or other archaeological resources;
  - (ii) The Site does not receive enough sunlight to support vegetation; or
  - (iii) Unable to operate off-line with bypass and unable to operate inline with safe overflow mechanism.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1)

## SUBCHAPTER 8 VARIANCES

§20-3-64 Variances

§20-3-64 <u>Variances</u>. (a) Petitions for variances from the requirements of these rules may be submitted to the Director.

- (b) Petitions for a variance must include:
  - (1) The name, address, phone number and email address of the petitioner;
  - (2) A designation of the specific sections and provisions of these rules from which variance is sought;
  - (3) A narrative explanation of the grounds on which the variance may be granted; and

- (4) Engineer certified plans, illustrations, and/or calculations in support of the petition.
- (c) The Director may authorize a petitioner to vary from any requirement established by these rules if the petitioner is able to establish all of the following are true:
  - (1) The variance is necessary to prevent a hardship caused by unique Site conditions on the property that are not ordinarily found in other areas within the City;
  - (2) The unique conditions on the property are not the result of petitioner's own actions or the actions of h/her agents, contractors, consultants, or tenants:
  - (3) Granting a variance will not adversely affect the rights of abutting property owners;
  - (4) The variance requested will not result in an unreasonable threat of Pollutant Discharges to the MS4 or State Waters;
  - (5) The variance requested is the minimum accommodation needed to overcome the hardship caused by naturally occurring conditions on the property; and

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§1-9.1, 14-12.31, 14-12.32) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 14-12.32, 18-4.1, 18-5.1).

#### SUBCHAPTER 9 VIOLATIONS AND ENFORCEMENT

§20-3-65	<b>BMP</b> Deficiencies
§20-3-66	Enforcement
§20-3-67	Penalties

- §20-3-65 <u>BMP Deficiencies</u>. BMP Deficiencies and violations of ESCPs shall be classified as critical, major, and minor deficiencies as follows.
- (a) Critical deficiencies are any BMP deficiencies that result in or pose an immediate threat of Pollutants Discharges to the MS4 or state waters.
- (b) Major deficiencies are non-critical deficiencies that indicate a lack of good-faith efforts to comply with the requirements of these rules and those deficiencies that may reasonably be expected to result in the Discharge of Pollutants to the MS4 or state waters under rain conditions with a 10 year recurrence interval or less.
- (c) Minor deficiencies means those deficiencies that do not pose a threat for Discharge of untreated storm water or Pollutants to the MS4, surface waters, or State waters, but are not in strict conformance with an approved ESCP.

- §20-3-66 <u>Enforcement</u>. (a) If the Director determines that any person is violating any provision of these rules, the Director may issue a notice of violation and order to the person or persons responsible for the violation. The person responsible for a violation of these rules shall be the owner of the Real property on which the violation occurs and the person responsible for implementing the ESCP for the Project. The responsible person or persons may also include all persons who directed, authorized, allowed, or participated in the acts of omissions that cause the violation to occur.
  - (b) The notice of violation shall contain the following:
    - (1) The date of the notice
    - (2) The name and address of the person or persons served with the notice
    - (3) The section of the ordinance or rule that has been violated
    - (4) The nature of the violation; and
    - (5) The deadline for compliance with the notice.
- (c) Contents of the Order. The order may require the person or persons responsible for the violation to do any or all of the following:
  - (1) Cease and desist from the violation;
  - (2) Correct the violation at the person's own expense;
  - (3) Pay and administrative fine; or
  - (4) Appear before the Director at the time and place specified by the order to answer charges and explain why a fine for the violation should not be imposed; and
  - (5) Clean and abate any Discharge to the MS4.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.24, 14-12.26, 14-12.28, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

- §20-3-67 <u>Penalties</u>. (a) Any person violating the provisions of these rules may be ordered to pay an administrative or civil penalty of not less than \$1,000.00 nor more than \$25,000.00 per violation per day, except that in cases where such offense shall continue after due notice, each day's continuance of the same shall constitute a separate offense.
- (b) A civil fine that remains unpaid after all rights to a Contested case hearing have expired or been exhausted may be added by administrative action of the Director to any taxes, fees, or chargers collected by the City, other than charges for residential water and sewer use. Once added to fees or charges collected by the City, no permit, approval, or license shall be issued to a person responsible for the unpaid fine until said fines are paid in full. Taxes, fees, and charges that unpaid civil fines may be added to include, but are not limited to:
  - (1) Building, grading, grubbing, stockpiling, trenching, sign, special management area, shoreline variance, subdivision approval, building relocation, conditional use, and general plan amendment, and state land use district boundary amendment permits issued by the Department;
  - (2) Motor vehicle registration and vehicle weight tax, motor vehicle transfer of ownership fee, driver's license renewal fees, and business license fees collected by the customer services department;
  - (3) Liquor license and liquor license renewal fees collected by the Liquor Commission;

- (4) Refuse collection and disposal fees collected by the Department of Environmental Services; and
- (5) Real property taxes collected by the Department of Budget and Fiscal services. However, fines added to Real property taxes after the effective date of these rules shall be junior to all interests recorded against Real property before the unpaid fines are added to the Real property taxes for the property.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.24, 14-12.26, 14-12.28, 14-12.31) (Imp: ROH §§ 14-12.1, 14-12.23, 14-14.2, 18-4.1, 18-5.1).

#### SUBCHAPTER 10 APPEALS

§20-3-68	Appeals
§20-3-69	Computation of Time
§20-3-70	Mandatory Filing Deadline
§20-3-71	Representation in Contested Case Hearings
§20-3-72	Prehearing Procedure
§20-3-73	Intervention
§20-3-74	Withdrawal of Petition
§20-3-75	Contested Case Hearing
§20-3-76	Decision and Order
§20-3-77	Judicial Remand

- §20-3-68 <u>Appeals</u>. (a) A property owner, permit holder, Discharger, or person that is personally and adversely affected by an action of the Director in the administration of these rules may appeal the Director's action by filing a petition for appeal with the Department of Planning and Permitting within thirty days of the mailing of the Director's action.
- (b) A petition for appeal shall not exceed ten pages in length and must be signed by the petitioner or the petitioner's attorney. A petition for appeal must also include all of the following:
  - (1) The petitioner's name, address, phone number, and interest in the Director's action;
  - (2) All pertinent facts;
  - (3) The provisions of the Director's action that are objected to;
  - (4) The reasons for the objection;
  - (5) The alternate provisions, if any, that petitioner seeks to place in the Director's action; and
  - (6) The reasons why the petitioner believes that the Director's action is based on an erroneous finding of material fact, arbitrary or capricious decision making, or an abuse of discretion.
- (c) Upon receipt of a petition for appeal containing all required information, the Director shall assign a hearings officer to hold a Contested case hearing on the petition.

- (d) A petition for appeal shall only be sustained if the petitioner is able to prove, by a preponderance of the evidence, that the Director's action is based on an erroneous finding of material fact, arbitrary or capricious decision-making, or an abuse of discretion. In all other cases, an appeal shall be denied.
- (e) If an appeal is sustained, the hearings officer shall remand the Director's action or to the Department for further action consistent with the hearings officer's findings and decision.
- (f) The filing of a petition for appeal shall not stay an action of the Director of the requirements of a notice of violation and order.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: HRS §§ 91-2, 91-9, 91-9.5, 91-12, ROH § 14-12.27).

§20-3-69 <u>Computation of Time</u>. Whenever these rules specify a period of days for the completion of an action, the action shall be completed by 4:30 p.m. on the last day specified in the period, except when the specified period of days ends on a weekend, observed holiday, or other day on which the City is not open for business. In such cases, the action shall be completed by 4:30 p.m. on the next business day.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: HRS §91-2).

- §20-3-70 <u>Mandatory Filing Deadline</u>. (a) A petition for appeal must be received by the Department within thirty days of the mailing or personal service of the Director's action. The date of mailing may be established by a postal receipt or official Department records which state the date on which the director's action was placed in the US mail or hand delivered to the petitioner.
- (b) If a petition for appeal is not filed within thirty days, it shall be dismissed upon motion by the Director.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, ROH § 14-12.27).

- §20-3-71 <u>Representation in Contested Case Hearings</u>. (a) A person may appear before the hearings officer in the person's own behalf, a partner may represent a partnership, an officer, trustee, or authorized employee of a corporation, trust, or association may represent the corporation, trust, or association, and an officer or employee of an agency may represent the agency in Contested case proceedings.
  - (b) A person may be represented by counsel in any proceedings under these rules.
- (c) A person may not be represented in proceedings before the hearings officer except as stated in (a) and (b).
- (d) When a person who is not an attorney acts in a representative capacity and appears in person or signs documents or papers in practice before the hearings officer, the person shall provide proof of h/her authority to act on behalf of the represented person upon request of

the hearings officer or the Director.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, ROH § 14-12.27).

- §20-3-72 <u>Prehearing Procedure</u>. (a) Within thirty days of receiving a petition for appeal, the hearings officer shall schedule a prehearing conference with the parties by issuing a notice of prehearing conference. The notice shall be served upon the parties by certified mail, with return receipt requested, no less than seven days prior to the prehearing conference. If the notice is mailed to the address provided by the petitioner in h/her petition for appeal and returned to the hearings officer as unclaimed, notice of the scheduling may then be provided by publishing a copy of the notice in a newspaper published in the State of Hawaii and having a general circulation within the City and County of Honolulu at least once per week in two successive weeks.
- (b) At the prehearing conference, the hearings officer shall establish a date for the Contested case hearing and a schedule for the submission of prehearing motions, prehearing briefs, witness lists, and exhibit lists by the parties.
- (c) Prehearing briefs must contain a statement of relevant facts, the relief sought, and all grounds on which relief is sought. The petitioner's prehearing brief shall be filed with the Department no less than 30 days prior to the Contested case hearing. The Director's reply brief shall be filed no less than seven days prior to the Contested case hearing. Arguments that are not presented in the petitioner's prehearing brief shall not be heard in the Contested case hearing.
- (d) After the conclusion of the prehearing conference, the hearings officer shall issue a notice of Contested case hearing to the parties. The notice shall be served upon the parties by certified mail no less than seven days before the Contested case hearing date and include the following information:
  - (1) The date time, place and nature of the Contested case hearing,
  - (2) The legal authority under which the hearing is to be held,
  - (3) The particular sections of the statutes and rules involved,
  - (4) An explicit statement, in plain language, of the issues involved and the facts alleged by the Director, unless the hearings officer is unable to determine the same and
  - (5) The fact that any party may retain counsel or be represented in accordance with §20-3-71 of these rules.

If the notice is mailed to the address provided by the petitioner in h/her petition for appeal and returned to the hearings officer as unclaimed, notice of the scheduling may then be provided by publishing a copy of the notice in a newspaper published in the State of Hawaii and having a general circulation within the City and County of Honolulu at least once per week in two successive weeks. The last required publication of the notice shall be no less than seven days before the Contested case hearing date.

(e) Any procedure in a Contested case may be modified or waivered by stipulation of the parties and an information disposition of the appeal may be made by agreement, consent order, or default, which shall be entered against any party that fails to appear at two consecutive hearings on the petition for appeal or motion thereon after receiving due notice of the same.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, ROH § 14-12.27).

- §20-3-73 <u>Intervention</u>. (a) Persons with a financial interest in the Real property concerned by the Director's action and persons who will be directly and personally affected by the Director's action may submit a petition to intervene in a Contested case appeal from an action of the Director.
- (b) Petitions to intervene shall only be granted if the petitioner meets the requirements of subsection (a).
- (c) Petitioners who are in support of the petition for appeal shall submit all prehearing documents concurrently with the petitioner-appellant. Petitioners who oppose the petition for appeal shall submit all prehearing documents concurrently with the Director.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, ROH § 14-12.27).

§20-3-74 <u>Withdrawal of Petition</u>. A written request for the withdrawal of a petition for appeal may be filed at any time. A request to withdraw the petition may be approved by the hearings officer shall be approved if submitted with the concurrence of all parties.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, ROH § 14-12.27).

- §20-3-75 <u>Contested Case Hearings</u>. (a) The party initiating the proceedings shall have the burden of proof, which includes the burden of producing evidence and the burden of persuasion. The degree or quantum of proof shall be a preponderance of the evidence.
- (b) Any oral or documentary evidence may be received; however, the hearings officer shall exclude all irrelevant, immaterial, or unduly repetitious evidence and shall give effect to the rules of privilege recognized by law.
- (c) Every party shall have the right to conduct cross-examination as required for the full and fair disclosure of the facts.
  - (d) All parties shall have the right to submit rebuttal evidence;
- (e) The hearings officer may take judicial notice of judicially recognizable facts and generally recognized technical or scientific facts within the specialized knowledge of the Department, provided that the parties shall be given notice of any judicially noticed facts and given the opportunity to dispute or contest the same.
- (f) If any party fails to appear at two consecutive hearings on a matter, their right to a Contested case hearing shall be waived and the petition for appeal shall be dismissed.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.27, 14-12.31) (Imp: HRS §91-2, 91-9, 91-10, ROH § 14-12.27).

§20-3-76 <u>Decision and Order</u>. (a) At the conclusion of the Contested case hearing,

the hearings officer may enter an oral ruling and direct the prevailing party to prepare a proposed findings of fact, conclusions of law, and decision and order for adoption by the hearings officer or take the matter under consideration for a period of time not to exceed 60 days.

- (b) Where the matter is taken under consideration, the hearings officer shall issue a findings of fact, conclusions of law, and decision and order prepared by the hearings officer.
- (c) If the hearings officer requires the prevailing party to prepare a prosed findings of fact, conclusions of law, and decision and order, the other parties to the case may submit written objections or exceptions to the proposed findings of fact, conclusions of law, and decision and order within fourteen days of receiving a copy of the same. A hearing to adopt or modify the proposed order shall be held within thirty days of the filing of exceptions or the expiration of the opportunity to do the same.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: HRS §§ 91-2, 91-9, 91-12, 91-14, ROH § 14-12.27).

- §20-3-77 <u>Judicial Remand</u>. (a) If a matter is remanded to the Department or hearings officer for further proceedings pursuant to HRS §91-14, the judicial record shall be incorporated into the record of proceedings before the hearings officer.
- (b) Upon notice of the remand, the hearings officer shall schedule a public hearing within sixty (60) days of the remand. Notice of the hearing shall be transmitted to the parties by certified mail no less than fifteen (15) days prior to the public hearing
- (c) At the public hearing, the hearings officer shall identify the issues on remand and the scope of the additional testimony or evidence that may be received based on the needs of the case and the order directing remand to the Department or hearings officer.
- (d) The hearings officer shall conduct further proceedings in compliance with the requirements for Contested cases in these rules and may require additional briefs, witness lists, and/or exhibit lists.

[Eff August 16, 2017] (Auth: HRS §91-2, RCH §4-105, ROH §§ 1-9.1, 14-12.31) (Imp: HRS §§ 91-2, 91-9, 91-14, ROH § 14-12.27).

These amendments to the Rules Relating to Water Quality were adopted on September 17, 2018, following a public hearing held on August 31, 2018, after public notice was given on July 31, 2018, in the Honolulu Star Advertiser, State and County Public Notices Section, Honolulu, Hawaii.

These amendments shall take effect fourteen days after filing with the City Clerk.

KATHY K. SOKUGAWA

**Acting Director** 

Department of Planning and Permitting

APPROVED:

KIRK CALDWELL

Mayor

City and County of Honolulu

Dated: 11 70 18

APPROVED AS TO FORM AND LEGALITY:

**Deputy Corporation Counsel** 

BRADT. SAITO

FILED:

Given unto my hand and affixed with the Seal of the City and County of Honolulu this 10th day of December , 2018.

Glen I Takahashi, City Clerk

## **Appendix E**

# A Sample of CDS Unit Operation and Maintenance Guideline

#### **OPERATIONS AND MAINTENANCE GUIDELINES**

#### **CDS Stormwater Treatment Unit**

#### INTRODUCTION

The CDS unit is an important and effective component of your storm water management program and proper operation and maintenance of the unit are essential to demonstrate your compliance with local, state and federal water pollution control requirements.

The CDS technology features a patented non-blocking, indirect screening technique developed in Australia to treat water runoff. The unit is highly effective in the capture of suspended solids, fine sands and larger particles. Because of its non-blocking screening capacity, the CDS unit is un-matched in its ability to capture and retain gross pollutants such as trash and debris. In short, CDS units capture a very wide range of organic and in-organic solids and pollutants that typically result in tons of captured solids each year such as: Total suspended solids (TSS) and other sedimentitious materials, oil and greases, trash, and other debris (including floatables, neutrally buoyant, and negatively buoyant debris). These pollutants will be captured even under very high flow rate conditions.

CDS units are equipped with conventional oil baffles to capture and retain oil and grease. Laboratory evaluations show that the CDS units are capable of capturing up to 70% of the free oil and grease from storm water. CDS units can also accommodate the addition of oil sorbents within their separation chambers. The addition of the oil sorbents can ensure the permanent removal of 80% to 90% of the free oil and grease from the storm water runoff.

#### **OPERATIONS**

The CDS unit is a non-mechanical self-operating system and will function any time there is flow in the storm drainage system. The unit will continue to effectively capture pollutants in flows up to the design capacity even during extreme rainfall events when the design capacity may be exceeded. Pollutants captured in the CDS unit's separation chamber and sump will be retained even when the units design capacity is exceeded.

#### **CDS UNIT INSPECTION**

Access to the CDS unit is typically achieved through two manhole access covers – one allows inspection (and clean out) of the separation chamber (screen/cylinder) & sump and another allows inspection (and cleanout) of sediment captured and retained behind the screen.

The unit should be periodically inspected to determine the amount of accumulated pollutants and to ensure that the cleanout frequency is adequate to handle the predicted pollutant load being processed by the CDS unit. The unit should be periodically inspected for indications of vector infestation, as well. The recommended cleanout of

solids within the CDS unit's sump should occur at 75% to 85% of the sump capacity. However, the sump may be completely full with no impact to the CDS unit's performance.

CONTECH Stormwater Solutions (previously CDS Technologies) recommends the following inspection guidelines: For new initial operation, check the condition of the unit after every runoff event for the first 30 days. For ongoing operations, the unit should be inspected after the first six inches of rainfall at the beginning of the rainfall season and at approximately 30-day intervals. The visual inspection should ascertain that the unit is functioning properly (no blockages or obstructions to inlet and/or separation screen), evidence of vector infestation, and to measure the amount of solid materials that have accumulated in the sump, fine sediment accumulated behind the screen, and floating trash and debris in the separation chamber. This can be done with a calibrated dipstick, tape measure or other measuring instrument so that the depth of deposition in the sump can be tracked.

#### **CDS UNIT CLEANOUT**

The frequency of cleaning the CDS unit will depend upon the generation of trash and debris and sediments in your application. Cleanout and preventive maintenance schedules will be determined based on operating experience unless precise pollutant loadings have been determined.

Access to the CDS unit is typically achieved through two manhole access covers – one allows cleanout of the separation chamber (screen/cylinder) & sump and another allows cleanout of sediment captured and retained behind the screen. For units possessing a sizable depth below grade (depth to pipe), a single manhole access point would allow both sump cleanout and access behind the screen.

#### CONTECH Stormwater Solutions Recommends The Following:

NEW INSTALLATIONS: Check the condition of the unit after every runoff event for the first 30 days. The visual inspection should ascertain that the unit is functioning properly (no blockages or obstructions to inlet and/or separation screen), measuring the amount of solid materials that have accumulated in the sump, the amount of fine sediment accumulated behind the screen, and determining the amount of floating trash and debris in the separation chamber. This can be done with a calibrated "dip stick" so that the depth of deposition can be tracked. Refer to the "Cleanout Schematic" (Appendix B) for allowable deposition depths and critical distances. Schedules for inspections and cleanout should be based on storm events and pollutant accumulation.

ONGOING OPERATION: During the rainfall season, the unit should be inspected at least once every 30 days. The floatables should be removed and the sump cleaned when the sump is 75-85% full. If floatables accumulate more rapidly than the settleable solids, the floatables should be removed using a vactor truck or dip net before the layer thickness exceeds approximately one foot.

Cleanout of the CDS unit at the end of a rainfall season is recommended because of the nature of pollutants collected and the potential for odor generation

from the decomposition of ma terial collected and retai ned. This end of season cleanout will assist in preventing the discharge of pore water from the CDS <sup>®</sup> unit during summer months.

<u>USE OF SORBENTS</u> –The addition of sorbents is **not a requirement** for CDS units to effectively control oil and grease from storm water. The conventional oil baffle within a unit assures satisfactory oil and grease removal. However, the addition of sorbents is a unique enhancement capability unique to CDS units, enabling increased oil and grease capture efficiencies beyond that obtainable by conventional oil baffle systems.

Under normal operations, CDS units will provide effluent concentrations of oil and grease that are less than 15 parts per million (ppm) for all dry weather spills where the volume is less than or equal to the spill capture volume of the CDS unit. During wet weat her flows, the oil baffle system can be expected to remove between 40 and 70% of the free oil and grease from the storm water runoff.

CONTECH Stormwater Solutions only recommends the addition of sorbents to the separation chamber if there are specific land use activities in the catchment watershed that could produce exceptionally large concentrations of oil and grease in the runoff, concentration levels well above typical amounts. If site evaluations merit an increased control of free oil and grease then oil sorbents can be added to the CDS unit to thoroughly address these particular pollutants of concern.

#### Recommended Oil Sorbents

Rubberizer® Particulate 8-4 mesh or OARS ™ Particulate for Filtration, HPT4100 or equal. Rubberizer is supplied by Haz-Mat Response Technologies, Inc. 4626 Sant a Fe Street, San Diego, CA 92109 (800) 542-3036. OARS is supplied by AbTech Industries, 4110 N. Scottsdale Road, Suite 235, Scottsdale, AZ 85251 (800) 545-8999.

The amount of sorbent to be added to the CDS separation chamber can be determined if sufficient information is known about the concentration of oil and grease in the runoff. Frequent ly the actual concentrations of oil and grease are too variable and the amount to be added and frequency of cleaning will be determined by periodic observation of the sorbent. As an initial application, CDS recommends that approximately 4 to 8 pounds of sorbent material be added to the separation chamber of the CDS units per acre of parking lot or road surface per year. Typically this amount of sorbent results in a ½ inch to one (1") inch depth of sorbent material on the liquid surface of the separation chamber. The oil and grease loading of the sorbent material should be observed after major storm events. Oil Sorbent material may also be furnished in pillow or boom configurations.

The sorbent material should be replaced when it is fully discolore d by skimming the sorbent from the surface. The sorbent may require disposal as a spec ial or hazardous waste, but will depend on local and state regulatory requirements.

#### **CLEANOUT AND DISPOSAL**

A vactor truck is recommended for cleanout of the CDS unit and can be easily accomplished in less than 30-40 minutes for most installations. Standard vactor operations should be employed in the cleanout of the CDS unit. Disposal of material from the CDS unit should be in accordance with the local municipalit y's requirements. Disposal of the decant material to a POTW is recommended. Field decanting to the storm drainage system is not recommended. Solids can be disposed of in a similar fashion as those materials collected from street sweeping operations and catch-basin cleanouts.

#### **MAINTENANCE**

The CDS unit should be pumped down at least once a year and a thorough inspection of the separation chamber (inlet/cylinder and separation screen) and oil baffle performed. The unit's inter-nal components should not show any signs of damage or any loosening of the bolts used to fasten the various components to the manhole structure and to each other. Ideally, the screen should be power washed for the inspection. If any of the internal components is damaged or if any fasteners appear to be damaged or missing, please contact CONTECH at 800.338.2211 to make arrangements to have the damaged items repaired or replaced.

The screen assembly is fabricated from Type 316 stainless steel and fastened with Type 316 stainless steel fasteners that are easily removed and/or replaced with conventional hand tools. The damaged screen assembly should be replaced with the new screen assembly placed in the same orientation as the one that was removed.

#### **CONFINED SPACE**

The CDS unit is a confined space environ ment and only properly trained personn el possessing the neces sary safety equipment s hould enter the unit to perform particular maintenance and/or inspection activities beyond normal procedure. Inspections of the internal components can, in most cases, be accomplished by observations from the ground surface.

#### **VECTOR CONTROL**

Most CDS units do not readily facilitate vector infestation. However, for CDS units that may experience extended periods of non-operation (stagnant flow conditions for more than approximately one week) there e may be the potential for vector infestation. In the event that these conditions exist, the CDS unit may be designed to minimize potential vector habitation through the use of physical barriers (such as seals, plugs and/or netting) to seal out potential vectors. The CDS unit may also be configured to allow drain-down under favorable soil conditions where infiltration of storm water runoff is permissible. For standard CDS units that show evidence of mosquito infestation, the

application of larvicide is one control strategy that is recommended. Typical larvicide applications are as follows:

<u>SOLID B.t.i. LARVICIDE</u>: ½ to 1 briquet (typically treats 50-100 sq. ft.) one time per month (30-days) or as directed by manufacturer.

<u>SOLID METHOPRENE LARVICIDE</u> (not recommended for some locations):  $\frac{1}{2}$  to 1 briquet (typically treats 50-100 sq. ft.) one time per month (30-days) to once every  $4-\frac{1}{2}$  to 5-months (150-days) or as directed by manufacturer.

#### RECORDS OF OPERATION AND MAINTENANCE

CONTECH Stormwater Solutions recomme nds that the owner m aintain annual records of the operation and maintenance of the CDS unit to document the effective maintenance of this import ant component of your storm water management program. The attached **Annual Record of Operations and Maintenance** form (see **Appendix A**) is suggested and should be retained for a minimum period of three years.

### **Appendix F**

# HDOT Harbors Division Construction and Post-Construction Program Brochures



#### **CONSTRUCTION PROJECTS DEFINED**

Any activity that results in the disturbance of land, including clearing, grading, excavating and activities that support the project such as stockpiles, washouts, fueling and storage areas.



#### **STORMWATER IMPACTS**

Construction activities may cause pollution and impact stormwater runoff which eventually discharges to the harbor and other surface waters without prior treatment.



### HDOT-HARBORS CONSTRUCTION SITE RUNOFF CONTROL PROGRAM

All construction projects under Harbors jurisdiction are subject to the requirements of this program as well as local, state, and federal environmental laws.



#### **EXEMPT PROJECTS**

Activities that result in no or minimal land disturbance such as:

- Post, pole, sign, and fencing installation
- Parking lot and driveway repair
- Interior improvement
- Maintenance
- Utility repair

#### REPORT SUSPECTED ILLICIT DISCHARGES

Harbors Environmental Hotline: 808-587-1962
Harbor Traffic Control: 808-587-2076

U.S. Coast Guard: 808-842-2600

Hawaii Department of Health, 808-586-4309

Clean Water Branch:

# CONSTRUCTION SITE RUNOFF CONTROL PROGRAM

#### **MAILING ADDRESS**

Hawaii Department of Transportation, Harbors Division
Hale Awa Ku Moku Building
79 South Nimitz Highway
Honolulu, Hawaii 96813-4898





Department of Transportation Harbors Division



- HDOT-Harbors Projects are managed by division personnel.
- Tenant Improvement Projects are managed by the entity authorized to undertake the project. Tenants must obtain consent from HDOT-Harbors Division.

#### PLAN SUBMITTAL AND REVIEW

The following must be submitted to HDOT-Harbors Engineering Branch Environmental Section (HAR-EE) for review. For more information, refer to the Construction Site Runoff Control Program Manual and Post-Construction Stormwater Management Manual at:

http://hidot.hawaii.gov/harbors/malamaikeawakai/

#### PROJECTS LESS THAN ONE ACRE:

- Notification Form
- Site Plan
- Narrative of proposed work and applicable BMPs

#### PROJECTS ONE ACRE OR GREATER:

- Construction Design Review Checklist
- Permanent Post-Construction BMP Plan Checklist
- Construction Drawings and Plans
- Stormwater Pollution Prevention Plan (SWPPP)
- Post-Construction Stormwater Mitigation Plan (if applicable)
- Copies of NPDES Permit Applications
- Other Applicable Permit Applications

#### OTHER REFERENCES:

 CCH Rules Relating to Water Quality & Related Resources at:

https://www.honolulu.gov/dfmswq/rules-relating-towater-quality.html.

2. CCH Stormwater Best Management Practice Manual for Construction (dated November 2011)



#### **ENVIRONMENTAL COMPLIANCE**

All construction projects are required to comply with local, state, and federal environmental laws. Enforcement for non-compliance may include:

- Oral or Verbal Warning
- Written Warning
- Notice of Violation
- Stop Work Order
- Withhold Payment
- ELD and L&M Assessment
- Contract Termination



#### TRAINING REQUIREMENTS

Harbors engineers, inspectors, and consultants who have primary construction stormwater responsibilities will receive initial and annual refresher training.



#### **PERMIT REQUIREMENTS**

# DISCHARGE/CONNECTION PERMIT (TENANT IMPROVEMENT AND NON-HARBOR PROJECTS ONLY):

Complete the Discharge/Connection Permit application and submit to HDOT-Harbors Engineering Branch, Environmental Section for review.

#### **NPDES PERMIT:**

Submit all applicable permit applications to the State of Hawaii Department of Health, Clean Water Branch per Hawaii Administrative Rules, Chapter 11-55 and provide proof of application and issue permit(s) to HDOT-Harbors Engineering Branch, Environmental Section.

HDOH NPDES Permit Applications: https://eha-cloud.doh.hawaii.gov/epermit

#### **HDOT-HARBORS INSPECTIONS**

Conducted by HAR-EE or a designated and qualified inspector and documented on the *Construction Site Best Management Practices Inspection Checklist*.

INITIAL INSPECTIONS: To be conducted prior to the start of construction activities to ensure site-specific BMPs have been properly installed in accordance with the SWPPP or similar. No construction activities will commence until this inspection is conducted and any deficiencies are satisfactorily addressed.

RECURRING INSPECTIONS: To be conducted throughout the duration of the construction phase at the following frequencies to ensure that BMPs are properly maintained:

- October March: Once every two weeks
- April September: Once every two months

**FINAL INSPECTIONS:** To be conducted after construction activities have been completed to ensure the following:

- Disturbed soil is stabilized
- Temporary BMPs have been removed
- Permanent BMPs have been properly installed, where applicable



#### **POST-CONSTRUCTION BMPS**

Designed to minimize water quality impacts following the completion of construction projects while complying with HDOT-Harbors Small Municipal Separate Storm Sewer System (MS4) Permits. Refer to the Post-Construction Stormwater Management Program Manual at:

http://hidot.hawaii.gov/harbors/malamaikeawakai/



#### **LOW IMPACT DEVELOPMENT (LID)**

Systems and practices that mimic a site's natural hydrology to mitigate stormwater runoff and pollution.



#### **SOURCE CONTROL**

Measures to prevent pollutants from coming into contact with stormwater runoff or discharging into HDOT-Harbors small MS4.



#### TREATMENT CONTROL

Measures that treat stormwater runoff that has come into contact with pollutants. Examples include:

- Retention
- Bioinfiltration
- Mechanical methods

#### REPORT SUSPECTED ILLICIT DISCHARGES

Harbors Environmental Hotline: 808-587-1962

Harbors Construction Section: 808-587-1866

Harbor Traffic Control (24/7): **808-587-2076** 

Hawaii Department of Health, 808-586-4309

Clean Water Branch:

#### **MAILING ADDRESS**

Hawaii Department of Transportation, Harbors Division
Hale Awa Ku Moku Building
79 South Nimitz Highway
Honolulu, Hawaii 96813-4898





# POST-CONSTRUCTION STORMWATER MANAGEMENT PROGRAM

Required for all projects that result in land disturbance of one acre or more under HDOT-Harbors jurisdiction unless exempt.

- NEW DEVELOPMENT: New construction or installation of a building or structure, or the creation of impervious surface that disturbs one acre or more; or less than one acre if it is a part of a larger common plan of development or sale that disturbs one acre or more.
- REDEVELOPMENT: Development that would create or add an impervious surface area on an already developed site including, but not limited to, any construction project that requires demolition or complete removal of existing structures or impervious surfaces at a site and replacement with new impervious surfaces.

#### **PROGRAM EXEMPTIONS**

HDOT-Harbors Division may exempt certain types of projects from this program that pose a minimum risk of stormwater pollution including, but not limited to:

- Maintenance activities (e.g., top layer grinding, repaving, and reconfiguring surface parking lots)
- Reroofing
- Interior remodeling and improvement
- Routine maintenance to original line and grade, hydraulic capacity, or original purpose of facility
- Trenching and resurfacing associated with utility work
- Replacement of damaged pavement
- Emergency construction activities

## GENERAL POST-CONSTRUCTION PROJECT REQUIREMENTS

#### **DESIGN PHASE:**

- Incorporate Post-Construction BMPs into design
- Submit the Permanent Post-Construction BMP Plan Checklist
- Apply for Appropriate Permits
- Submit Post-Construction Stormwater Mitigation Plan and other applicable plans
- Wait for concurrence and Notice to Proceed

#### **CONSTRUCTION PHASE:**

- Install Post-Construction BMPs according to approved PSMP
- Monitor and inspect installation and inventory
- Enforcement, if necessary
- Submit O&M Plan for review and acceptance

#### **POST-CONSTRUCTION PHASE:**

- Conduct long-term O&M of Post-Construction BMPs, if applicable
- Inspect Post-Construction BMPs regularly
- For tenant projects, tenant must submit annual O&M and inspection records to HDOT-Harbors, when applicable
- Enforcement, if necessary

#### **OTHER REFERENCES:**

 CCH Stormwater BMP Guide for New and Redevelopment (dated July 2017)

For more information, review the Post-Construction Stormwater Manual located on the HDOT-Harbors website at:

http://hidot.hawaii.gov/harbors/malamaikeawakai/



#### **ENVIRONMENTAL COMPLIANCE**

All construction projects are required to comply with local, state, and federal environmental laws. Enforcement for noncompliance may include:

- Oral or Verbal Warning
- Written Warning
- Notice of Violation
- Stop Work Order
- Withhold Payment
- ELD and L&M Assessment
- Contract Termination



#### TRAINING REQUIREMENTS

Appropriate training is provided to Designers, Plan Reviewers, Engineers, Inspectors, Construction Managers, Contractors, and Operators who have primary responsibilities in the implementation of the Harbors Post-Construction Stormwater Management Program. The training video is available on the HDOT-Harbors Stormwater Management website:

http://hidot.hawaii.gov/harbors/malamaikea wakai/



#### STORMWATER IMPACT

Urban runoff from a developed site may contain pollutants that can enter the MS4 without prior treatment before discharging to the harbor.

#### **BEST MANAGEMENT PRACTICES**

Review HDOT-Harbors Division Construction Site Runoff Control Program Manual and the Post-Construction Stormwater Management Manual for more information on BMPs and required procedures and process at:

http://www.hidot.hawaii.gov/harbors/malamaikeawakai



#### **CONSTRUCTION BMPs ARE:**

- Schedules of activities
- Prohibition of practices
- Maintenance procedures
- Other management procedures



#### **POST-CONSTRUCTION BMPs ARE:**

#### REPORT SUSPECTED ILLICIT DISCHARGES

Harbors Environmental Hotline: 808-587-1962

Harbors Construction Section: 808-587-1866

Harbor Traffic Control (24/7): **808-587-2076** 

Hawaii Department of Health, 808-586-4309

Clean Water Branch:

#### **MAILING ADDRESS**

Hawaii Department of Transportation, Harbors Division Hale Awa Ku Moku Building

79 South Nimitz Highway

Honolulu, Hawaii 96813-4898







#### **CONSTRUCTION BMPs**

A qualified inspector will conduct BMP inspections at the regulated project site to ensure BMPs are properly implemented. There are many different types of BMPs including, but not limited to the following:

#### **EROSION CONTROL:**

- · Preserve existing vegetation
- · Geotextiles and mats
- Slope drains

#### **SEDIMENT CONTROL:**

- Silt fence
- Storm drain inlet protection
- Sediment trap
- Sediment basin

#### WIND EROSION CONTROL:

Dust control

#### **TRACKING:**

Stabilize and maintain ingress and egress

#### **GOOD HOUSEKEEPING:**

- Material management
- Waste management
- Stockpile management
- Vehicle and equipment management
- Paving and grinding operations
- Concrete washout waste management







#### **POST-CONSTRUCTION BMPs**

All new development and redevelopment projects should consider applying post-construction BMPs during the planning and design phase of the project. Post-construction BMPs include:

- 1 LOW IMPACT DEVELOPMENT:
  - Conserve natural areas, soils, and vegetation
  - Minimize disturbances to natural drainages
  - Minimize soil compaction
  - · Minimize impervious surfaces
  - Direct runoff to landscaped areas
- SOURCE CONTROL:
  - Conduct operations indoors or under cover if possible to prevent contact with stormwater runoff
  - Landscaped areas
  - Storm drain inlet signs
- 3 TREATMENT CONTROL:
  - Infiltration basin or infiltration trench
  - Manufactured treatment device
  - Dry well
  - Bioretention Basin
  - Permeable pavement
  - Green roof
  - Swale